

# NcStudio-V15 Laser Tube Cutting Control System (TU2000)

Version: 2023.7.28 1st Version

Author: Software Department

Weihong Corporation All Rights Reserved



## Content

Modify Record.....	1
1 Product Introduction.....	2
1.1 Function Overview.....	2
1.2 Introduce the Main Interface of the Software.....	2
1.2.1 Drawing Area.....	3
1.2.2 Common Toolbar.....	3
1.2.3 Menu Bar.....	4
1.2.4 Show/Hide Button.....	4
1.2.5 Machine Control Bar.....	4
1.2.6 Layer Toolbar.....	9
1.2.7 Machining Information Statistics Bar.....	10
1.2.8 Alarm/Log Information Bar.....	10
2 Quick Start.....	11
2.1 Tube Machining Flow.....	11
2.2 Common Operation.....	12
2.2.1 Set Workpiece Origin.....	12
2.2.2 Calibrate Cutting Head.....	13
2.2.3 Tube Edge Find.....	14
2.2.4 Set Tube Size.....	15
2.2.5 Mark Point.....	16
2.2.6 Set Common Parameter.....	17
2.2.7 Focus Control.....	21
2.2.8 Follow-up Control.....	22
3 Loading or Drawing Tool Paths.....	38
3.1 Overview.....	38
3.1.1 Loading Tool Path.....	38
3.1.2 Draw Part.....	38
3.2 New.....	39
3.2.1 New Tube.....	39
3.2.2 3D Wrapping.....	40
3.2.3 Standard Part.....	42
3.3 Import 3D Part.....	44
3.3.1 Set Tube Intersection.....	46
3.3.2 Set Tube Cutting.....	47
3.4 Insert Part.....	48

3.4.1 Insert File .....	48
3.4.2 Insert 3D Wrapping .....	49
3.4.3 Insert Standard Part .....	50
4 Edit Path File .....	52
4.1 Overview .....	52
4.2 Graphic Operation .....	54
4.2.1 View Operation .....	54
4.2.2 Draw Graphic .....	61
4.2.3 Make Array .....	66
4.2.4 Auxiliary Tool .....	69
4.2.5 Edit Graphic .....	71
4.2.6 Preprocess Graphic .....	76
4.2.7 Quick Edit .....	81
4.3 Machining Technic .....	87
4.3.1 Overview .....	87
4.3.2 Lead Line .....	87
4.3.3 Kerf Compensation .....	89
4.3.4 Corner Chop .....	91
4.3.5 Grid Chop .....	92
4.3.6 Micro Joint .....	93
4.3.7 Chamfer .....	95
4.3.8 Bridge .....	97
4.3.9 Cooling Point .....	98
4.3.10 Unfill/Fill .....	99
4.3.11 Direction .....	99
4.3.12 Centering Mark .....	100
4.3.13 Inner Compensation .....	101
4.3.14 Weld Compensation .....	102
4.3.15 Vertical Intersection .....	102
4.3.16 Over Arris Jiggle .....	103
4.3.17 Truncation Line Setting .....	104
4.3.18 Instant Setting .....	104
4.3.19 Clear .....	105
4.4 Layer Technic .....	106
4.4.1 Overview .....	106
4.4.2 Set Layer Technic .....	106
4.4.3 Apply Layer Technic .....	117
4.4.4 Import Technics .....	117
4.4.5 Save As .....	117
4.5 Arrange Path .....	119
4.5.1 Sort .....	119
4.5.2 Scan .....	123
4.5.3 Tube Array .....	126
4.5.4 Reverse Tube Path .....	127
4.6 Simulation .....	127
5 Machining Related Operation .....	128
5.1 Execute Return to Mechanical Origin or Set Datum .....	128
5.1.1 Execute Return to Mechanical Origin .....	128
5.1.2 Set Datum .....	129
5.2 Axis Adjust .....	130

5.3 To Fixed Point .....	130
5.4 Calibrate B-axis Center .....	131
5.5 Central Compensation.....	133
5.6 Correction Dialog of Tube Face Center.....	134
5.7 Calibrate the Tube Center .....	135
5.7.1 Level and Center .....	135
5.7.2 Manually Set Center .....	135
5.7.3 Auto Leveling and Centering.....	136
5.8 Advanced Tool .....	137
5.9 Technic Library.....	137
5.9.1 Manage Technic Library .....	137
5.9.2 Nozzle Info. Management.....	144
5.9.3 Chuck Technic.....	144
5.10 Machining Mode.....	147
5.10.1 Normal Machining.....	147
5.10.2 Cycle Machining .....	147
5.10.3 Machining Report.....	148
5.10.4 View Log.....	151
6 Set Parameter.....	153
6.1 System Parameter.....	153
6.2 Port Setting .....	154
6.3 Lead Screw Compensation .....	155
6.3.1 Only Backlash Compensation.....	155
6.3.2 Bidirectional Compensation .....	156
6.4 Drive Parameter .....	158
6.5 Laser Device Setting .....	159
6.5.1 Basic Setting.....	160
6.5.2 QCW Mode Setting.....	161
6.5.3 Adjust Laser AVC .....	162
7 System Maintenance .....	164
7.1 Automation .....	164
7.1.1 Set Tube Length .....	164
7.1.2 Tail Material Processing Setting .....	164
7.1.3 Part Collection Setting .....	167
7.2 External Device .....	168
7.2.1 Monitoring.....	168
7.2.2 Laser Monitor.....	168
7.2.3 Lubricate Screw .....	169
7.2.4 Adjust Air Pressure .....	171
7.3 Tool .....	172
7.3.1 Reconnect Manually .....	172
7.3.2 One-click Cutoff .....	172
7.3.3 Custom Instructions Debug .....	173
7.3.4 Disable Action of Flow Edit .....	174
7.3.5 Trial Run .....	175
7.3.6 MDI.....	176
7.3.7 Machine Maintenance Regular Reminder.....	177
7.3.8 Encoder Detection .....	178
7.3.9 Track Error Measurement.....	179
8 System Management.....	181

8.1 Switch Language.....	181
8.2 Switch Unit .....	181
8.3 Switch Theme.....	181
8.4 Modify Password.....	182
8.5 Installation Package .....	182
8.6 System Button .....	184
8.7 Register Board .....	184
8.7.1 Get Register Code .....	184
8.7.2 Use Duration of Register Board .....	186
8.7.3 FAQs .....	186
9 Appendix.....	187
9.1 Instructions for Use of Catch Slag.....	187
9.1.1 Function Background.....	187
9.1.2 Noun Definition .....	187
9.1.3 Overall Debug Process.....	187
9.1.4 Configure Catch Slag Hardware Configuration in NcConfig .....	187
9.1.5 Software Configuration Related Parameters of Catch Slag Position .....	189
9.2 Tube Support Material User Instruction.....	194
9.2.1 Prerequisites for the Use and Effective of Tube Support Material Manual Rise .....	194
9.2.2 Prerequisites for the Use and Effective of Tube Support Material Manual Auto Rise .....	194
9.2.3 Prerequisites for the Use and Effective of Tube Support Material Manual Auto Drop.....	194
9.2.4 The Main Interface of the Servo Tube Support Material Function.....	195
9.2.5 Bracket Debugging Interface .....	196
9.2.6 The Overall Use Process of Tube Support Material.....	197
9.2.7 Troubleshoot Common Alarms .....	197
9.3 Tube Support Material Shield Function Use Instruction .....	198
9.3.1 Function Background.....	198
9.3.2 Function Entry.....	198
9.3.3 Application Process .....	198
9.3.4 Precautions.....	199
9.4 Special Pull Material Function Use Instruction .....	199
9.4.1 Model Classification.....	199
9.4.2 Function Application Background .....	201
9.4.3 Determination of Machine Coordinate System and Direction .....	201
9.4.4 Software Version .....	202
9.4.5 Detailed Explanation of Special Pulling Function.....	202
9.4.6 Precautions for Using the Special Pull Material Function .....	216
10 Shortcut Key List.....	217
Legal Notices .....	218
Requirements of Use.....	218
Intellectual Property Rights Notice .....	218
Termination .....	218



## Modify Record

Version	Data	Description
R1	2023.05	Original release

# 1 Product Introduction

## 1.1 Function Overview

Weihong's **NcStudio-V15 Laser Tube Cutting Control System (TU2000)**, abbreviated as TU2000 includes laser cutting technic processing, common layout function and laser machining control. The main functions include tool path file edit, system parameter set, customized machining process, system maintenance set and cutting control.

The tube type supports circular tube, rectangular tube, oval tube, waist tube, angle steel, channel steel and other special shaped tubes.


The main functional features of **TU2000** are:

- Auto loading and unloading
- Cycle machining
- Adaptive pulling material
- Simple drawing
- Auto nest, manual nesting
- Multi strategy CoEdge nesting
- Porous matrix
- Collision avoidance sorting
- Normal automatic adjustment
- Section editing
- Rotate section
- High power thick plate technic
- Rotary cutting of cutting head
- Heavy tube cutting and speed limit
- Weld seam compensation for section steel

## 1.2 Introduce the Main Interface of the Software

This chapter mainly introduces the main interface of **TU2000**.

The graphic is as follows:




### 1.2.1 Drawing Area


View tubes from different perspectives, preview cutting effects, and select graphics and parts to add technics.

Include the following areas:


- Top left corner area: Display the tube projection section outer contour, view name, tube type and size.



- Bottom left corner area: Display the 3D coordinate system.











- Middle area: Display the base layer or nest result and the added technic.



### 1.2.2 Common Toolbar

Provide common tool buttons:

Button	Description
 <a href="#">Select</a>	Choose any graphic you want.
 <a href="#">Pan</a>	Move the graphic in a straight line direction to change the coordinate position of the graphic without changing the shape and size of the graphic.
 <a href="#">Best View</a>	The adaptive size of the graphic is displayed in the window.
 <a href="#">Zoom by Rect</a>	Enlarge the part of the graphic to the size of the view window.

Button	Description
 <a href="#">Tube Cutting Setting</a>	Check the tube thickness and total tube length, which can be set.
 <a href="#">Tube Intersection</a>	The tube surface perforation can be made by intersecting branch tubes on the tube, and the array can be set.
 <a href="#">Tube Cutting</a>	Cutting graphic is generated on the tube to cut off the tube parts.
 <a href="#">Mark Point</a>	It is used to set the mechanical coordinate of the target position as the mechanical coordinate of the marked point, and move the cutting head back to the marked point when necessary.

### 1.2.3 Menu Bar

The following function tabs are included:

Tab	Function Description
Common	It include file operation, set technic, nest operation, automatic sorting and set common parameters of the machine tool.
View	Select graphics, display technics, and adjust views.
Machining	Machining related settings, including zeroing, centering, technic library management, machining mode selection, viewing production reports, operation reports, and logs.
Set	It is mainly used to set system parameters, ports, drivers and lasers. Lead screw error, feed cutting compensation and special material pulling parameter setting.
Maintain	It include automatic settings, external device maintenance management and common maintenance management tools.
About	It include software language, unit, theme, password and other settings, common shortcut key description, parameter backup, installation package production, etc.

### 1.2.4 Show/Hide Button

Show/Hide CNC Control Bar



Expand/Hide Menu Bar

### 1.2.5 Machine Control Bar


The CNC control bar includes:

- [Coordinate Display Area](#)
- [Manual Control Area](#)
- [Common Function Button](#)
- [Machine Tool Control Button](#)



#### 1.2.5.1 Coordinate Display Area


Display WCS, MCS, feedback coordinates, low speed, rapid and step distance of each axis:

Axis	WCS ↻	Feedback	low speed ⚙
X	0.000	0.000	6000 mm/min
Y	0.000	0.000	6000 mm/min
Z	0.000	0.000	1200 mm/min
B	0.000	0.000	1800 deg/min

After returning to the mechanical origin,  sign will appear in front of each axis.

In this area, the following operations can be performed:


- Click  to switch WCS and MCS.
- Click  to set the low speed, rapid and step of X, Y, Z and B axes.

 Manual Speed Setting ✕

	low speed	Rapid		Step
X:	6000	18000	mm/min	5 mm
Y:	6000	18000	mm/min	5 mm
Z:	1200	1800	mm/min	5 mm
B:	5	16	r/min	5 deg

### 1.2.5.2 Manual Control Area



The manual control area is as follows:















The image shows the manual control interface with the following callouts:




- 1:** Focus position adjustment buttons (- and +).
- 2:** Axis direction buttons (Z+).
- 3:** Override speed slider (0 to 100%).
- 4:** Jog mode buttons (Bwd and Fwd).
- 5:** Jog mode button (Jog).

1. Focus position

Click  /  button to adjust the focus position.






2. Axis direction button

- Click the direction button  (Y+) ,  (Y-) ,  (X+) ,  (X-) ,  ,  to control the positive or negative movement of each axis of the machine tool.
  - Click the direction button  ,  to control the rotation direction of B-axis.
3. Speed progress bar  
Before or during machining, select the following methods to adjust the feed speed.
- Drag the override speed bar with the mouse to adjust the feed speed.
  - Click the target position of the override speed bar.
  - After clicking the override speed bar, press the **PgUp**, **PgDown** or  $\uparrow$ ,  $\downarrow$ ,  $\leftarrow$ ,  $\rightarrow$  keys on the keyboard.
4. Machine tool motion control button  
Click  /  button, the machine tool will continuously move in reverse/forward direction along the tool path.
- In **Jog** mode, release the button to stop the machine.
  - In **Step** mode, the movement stop after setting the step size value.
5. Mode selection button  
According to the actual situation, click  /  to switch mode.

Mode	Description
Jog mode (default mode)	<ul style="list-style-type: none"> <li>▪ Click the single axis direction button, the axis moves at a continuous low speed, and stop after the button is released.</li> <li>▪ At the same time, click multiple axis direction buttons. The selected axis moves at a continuous low speed at the same time and stop at the same time after the button is released.</li> <li>▪ At the same time, click  the rapid button and the single axis direction button. The axis moves in a continuous rapid mode and stop when the button is released.</li> <li>▪ At the same time, click  the rapid button and multiple axis direction buttons. The axis moves in a continuous rapid mode and stop at the same time after the button is released.</li> </ul>
Step mode	<ul style="list-style-type: none"> <li>▪ Click the axis direction button, and the machine tool will stop after moving the set step size (default value is 5mm).</li> <li>▪ To customize the step value, click  in the upper right area of <b>Coordinate Display Area</b>.</li> </ul> <p><b>Note:</b> Do not set the step size too large or click the axis direction button frequently to avoid damage to the machine tool due to incorrect operation or too frequent operation.</p>








### 1.2.5.3 Common Function Button













Common function button:

Button	Description
 Set Zero	Return to the workpiece origin.
 To Zero	Control the feeding axis, laser head horizontal moving axis, laser head follow up axis, rotation axis or focus axis to return to the workpiece origin.
 Go Home	Execute all axes back to mechanical origin.
 Z Home	Execute Z-axis return to mechanical origin.
 Calibrate	Execute the specified action of cutting head.












#### 1.2.5.4 Machine Tool Control Button

Start and stop machining and related operations of laser cutting:

Button	Description
 Start	Start this machining task from the beginning.
 Stop	Stop this machining task.
 Resume	After the machining is stopped, the machining shall be continued from the position where the last machining was stopped under the condition of ensuring the accuracy of the mechanical coordinates.
 Simulate	Enter simulate mode. The system does not drive the machine tool to perform corresponding mechanical and electrical actions, but only simulates the machining path at high speed in the drawing area.
 Dry Run	Enter dry run mode. Run the machine tool without turn on the laser and machining related ports, check whether the machining action is correct. <b>Note:</b> Dry run without part collection action.
 To Center	After the Z-axis avoid to mechanical coordinate -1, the XB axis moves to the position where the workpiece coordinate is 0.
 Centering	Adjust the tube to horizontal and find the center of the tube. The centering method can be selected. Please refer to the buttons below for details.

Button	Description
	<p>Set the centering method. The text on the button indicate the currently selected centering method.</p> <p>You can only select the part of the centering method through this button, and the optional centering method is the centering action available for automatic matching of the current tube type.</p> <p>For more centering methods, see <a href="#">Auto Leveling and Centering</a>.</p>
	<p>The jaws that control the front chuck release. After the chuck control type is selected in the system parameters, the chuck will be controlled by IO/torque/position through the port.</p>
	<p>The jaws that control the front chuck clamp. After the chuck control type is selected in the system parameters, the chuck will be controlled by IO/torque/position through the port.</p>
	<p>The jaws that control the rear chuck release.</p>
	<p>The jaws that control the rear chuck clamp.</p>
	<p>Select graphics during machining, including <b>Machining</b>, <b>Dry Run</b>, <b>Simulate</b> and <b>Resume</b>.</p>
	<p>Press and hold the laser valve until it is released and closed. When machining start, the system automatically open the laser valve.</p>
	<p>Click open shutter, and then click close. The shutter must be manually clicked to open. First open the shutter, then open the laser valve, and finally the laser will come out.</p>
	<p>Click open lead, and then click close, it must be opened manually. The lead is used to indicate the position of the laser on the sheet.</p>
	<p>When clicked, continuously output the corresponding power of the laser according to the burst parameter.</p>
	<p>Click to open the follow up valve. After opening, the distance between the nozzle and the workpiece surface can be adjusted in real time to keep it at a fixed value. At the beginning of machining, the system automatically open the follow up valve.</p>
	<p>Click to manually open the blowing valve, and then click to close it, the blowing gas is air. At the beginning of machining, the button will be highlighted, and the system will automatically open the blowing valve to blow air.</p>







Button	Description
	<p>Click to manually open the blowing valve, and then click to close it, the blowing gas is oxygen. At the beginning of machining, the button will be highlighted, and the system will automatically open the blowing valve to blow oxygen.</p>
	<p>Click to manually open the blowing valve, and then click to close it, the blowing gas is nitrogen. At the beginning of machining, the button will be highlighted, and the system will automatically open the blowing valve to blow nitrogen.</p>
	<p>Start dis tailing. When processing the tailings, it is necessary to ensure that the system is in an idle state, and that the feeding axis, the horizontal moving axis of the laser head, the following axis of the laser head, the clamping axis of the blanking shelf, and the axis that makes the blanking shelf move forward or backward have all returned to the original point.</p>
	<p>Turn on lube.</p>
	<p>Click to manually open the fan power supply, and then click to close. Set the system parameters of <b>External Equipment Control-Exhaust</b> category to control the fan to start or stop automatically when machining start or end.</p>
	<p>Set the system parameter <b>Enable Back Blow</b> or <b>Enable Side Blow</b> to <b>Yes</b>, and click this button to enable slag removal.</p>
	<p>Click this button, and the cutting head will perform a tube edge find.</p>
	<p>Click this button to open the <b>Auto Load</b> dialog box. 5 sets of load parameters can be set for selection. During manual operation, click the corresponding execution button, and the process will be automatically called based on the check box before the load parameters.</p>
	<p>Turn on the lighting.</p>
	<p>Enable the buzzer. When the buzzer has an output, the button can be operated. Click to turn off the buzzer.</p>
	<p>Enable or shield auxiliary support tube.</p>


### 1.2.6 Layer Toolbar

Perform layer related operations.

Including the following parts:

- : set layer parameters.
- : set the selected graphic machining.
- : set the selected graphic not machining. At this time, the graphic is white.
- : set the color of the selected object to the color of the corresponding layer.

### 1.2.7 Machining Information Statistics Bar




The following operations can be performed:

- Click **Report** to pop up the **Report** dialog box [View Run Report](#).
- Click **Machining Count Setting** to pop up the **Work Count** dialog box to view and set the machining count.
- View the current total machining time, the remaining time of re machining (when cycle machining is enabled), the current layer, machining count, speed, system status and other information.

### 1.2.8 Alarm/Log Information Bar

Display machining information and operation error prompt information.



The following operations can be performed:


- Double click **Alarm / Log**, and the **Log** dialog box pop up. [View Log](#) information.
- Double click the corresponding alarm item or log information item to view the time, reason, solution or log details of the alarm in the pop up dialog box.

## 2 Quick Start

### 2.1 Tube Machining Flow

Through this part, you can quickly get familiar with the machining flow of laser cutting tubes by the control machine of the **NcStudio-V15 Laser Cutting Control System**, and control the machine to cut tubes by laser.

The flow chart is as follows:



Process description:

Number	Step	Description
1	Execute return to mechanical origin or set datum	Return to the mechanical origin to synchronize the mechanical coordinate system of the system with the mechanical coordinate system of the machine tool, so must return to the mechanical origin before machining.  For details, see <a href="#">Execute Return to Mechanical Origin or Set Datum</a> .
2	Calibrate cutting head	Calibrate the cutting head to ensure that the relative distance between the cutting head and the plate remains unchanged under the follow up state.  For details, see <a href="#">Calibrate Cutting Head</a> .
3	Set tube size	Set according to the actual situation.  For details, see <a href="#">Set Tube Size</a> .
4	Calibrate the B-axis center	Calculate the mechanical coordinate value of the rotary axis center. It is necessary to use a standard square tube for calibration, and without replacing the mechanical hardware and not wear, there is no need to repeatedly calibrate the B-axis center.  For details, see <a href="#">Calibrate B-axis Center</a> .
5	Calibrate the tube center	For details, see <a href="#">Calibrate the Tube Center</a> .
6	Loading or drawing tool paths	Load the path file.  For details, see <a href="#">Loading or Drawing Tool Paths</a> .
7	Set workpiece origin	Mark sure the actual position of the workpiece origin on the workpiece.  For details, see <a href="#">Set Workpiece Origin</a> .
8	Set automatic centering	Optional step: when the tube is long, the tube will be automatically leveled and divided after cutting a certain length, and the breakpoint resume will automatically after completion.  For details, see <a href="#">Auto Leveling and Centering</a> .
9	Tube edge find	Optional step: move the feeding axis, so that the cutting head is precisely positioned above the tube truncation surface.  For details, see <a href="#">Tube Edge Find</a> .
10	Start machining	The formal machining phase control the start of machining.  For details, see <a href="#">Normal Machining</a> .

## 2.2 Common Operation

### 2.2.1 Set Workpiece Origin

The zero point of each axis in the tool path is the workpiece origin. Before machining, it is necessary to determine the actual position of the workpiece origin on the workpiece.

### Operation Steps:

1. In the machine tool control bar, click **X+ / X- / Y+ / Y- / B+ / B-** button to move the cutting head to the target position.




2. In the machine tool control bar, click **Set Zero** or press the **F5** key to set the current position as the workpiece origin.

### 2.2.2 Calibrate Cutting Head

The purpose of calibrating the cutting head is to measure the capacitance and position relationship between the cutting head and the plate, so as to control the Z-axis up and down floating in real time. To ensure that the relative distance between the cutting head and the plate remains unchanged under the follow up state.

### Operation Steps:

1. In the menu bar, click **Common** → **Follow-up Control** to open the **Follow-up Control** dialog box:




2. Manually move the Z- control cutting head to a distance of 5mm from the tube.




3. Click **Servo Calibrate** to calibrate the servo, solve the problem of servo motor zero drift caused by speed loop control, and the system automatically generate the value of parameter **Servo Compensation**.

4. According to the actual situation, select the following methods, move the cutting head to about 5mm near the plate surface, and keep the plate surface still all the time:

- If the cutting head has not been calibrated, click the Z-axis direction button, move the cutting head to about 5mm on the board surface, and keep the

board still all the time. In the machine tool control bar, click  to calibrate the cutting head.

- If the cutting head has been calibrated, click  **One Key Calibrate** on the **Follow-up Control** page.

The system automatically perform calibration, which take about 20s to complete.

After calibrating the cutting head, view it in the **Calibration Data** area of the **Follow-up Control** dialog box:

- If **Stability** and **Smooth** are higher than **Good**, continue normal machining.
- If **Stability** and **Smooth** are lower than **Good**, need to recalibrate.

### 2.2.3 Tube Edge Find

By moving the feed axis, the cutting head is positioned exactly above the tube section.

The process of edge finding is as follows:

1. Follow to the edge finding height.
2. The feeding axis moves in the negative direction and stop when it reaches the edge of the tube.


**Note:** Set auto edge finding before machining, and after the end of the edge finding, the system will automatically set the position of the edge finding result to the workpiece origin; it should be noted that adding tube edge finding instructions in process editing will not automatically set the workpiece origin after edge finding is completed, and workpiece zeroing needs to be added according to actual needs.

#### Prerequisite:

- Currently calibrated.
- After the feeding axis pushes the material forward, the cutting head is placed on the tube.

#### Operation Steps:

1. In the machine control bar, click  **Edge Find** to open the **Edge Find** dialog box:



2. Check **Manufacturer** and set the following parameters:

Parameter	Description
-----------	-------------

Parameter	Description
Retract distance after edge finding	Retract distance after automatic edge finding. Range: -10~1000.
Compensation for edge finding	Due to factors such as burrs on the cross section of the tube, the light spot is not located at the edge of the tube after edge finding. Manually adjust the compensation value according to the actual situation. Compensation for edge finding range: -10~100.
Material pushing distance	To avoid no tubes when edge finding. Set the retract distance, that is, before edge finding, the distance of material pushing in the positive direction of the feeding axis. Range: 0~10000.
Height of edge finding	Follow the height when edge finding. Range: 0.5~10.


3. Click **Start**, if need stop to click **Stop**.


### 2.2.4 Set Tube Size

Set the type and size of the machining tube in the software according to the actual situation.


This chapter takes rectangular tube as an example.

#### Operation Steps:

1. In the menu bar, click **Common** →  → **Tubes** to open the **Tube Wizard** dialog box:



2. Select **Rectangular Tube** to set the size of the new tube - rectangular tube:



When setting the R corner radius of rectangular tube, it can be about 0.5mm larger than the original radius. Prevent the offset of the tube size from causing poor cutting effect of some edges of the tube.

3. Click **Finish**.

**Related Task:**

To modify the tube size. For details, see [Tube Cutting Setting](#).

**2.2.5 Mark Point**


It is used to set the mechanical coordinate of the target position as the mechanical coordinate of the marked point, and move the cutting head back to the marked point when necessary.

**Prerequisite:**

Make sure that each axis has returned to the machine origin.

**Operation Steps:**

1. In the menu bar, click **Common** → **Mark Point** to open the **Mark Point** dialog box:





- In the machine tool control bar, click the X-axis and Y-axis direction buttons to move the cutting head to the target position.
- Select **M Dot n**. The value range of n is 1~8.
- Click **Mark Coor**.
- After selecting the target position, click **Go Mark**, and the cutting head will automatically return to the marked point position.
- (Optional: )** If the target position is not a mark point and it is necessary to quickly locate to the specified mechanical coordinate position, check **Rapid Positioning**, set the coordinate value and click **Locate**.

### Related Tasks:

In the **Mark Point** dialog box, you can also perform the following operations:


- If you need when to close the mark point dialog box, the drawing area still displays the mark points, check **Display the Mark Point after Interface Close**.
- To display all marked points in the drawing area, click **Show All**.

### 2.2.6 Set Common Parameter

Common parameters include machine param, user habit, gas param, burst param, follow-up control, clean by gas, and unit switch.

### Operation Steps:

- In the menu bar, click **Common** →  to open the **Common Param** dialog box:



2. Check **Manufacturer** to activate **Machine Param**.
3. Set **Parameter**.
4. Click **Confirm**.

**(Optional: )** If to modify system parameters, click **System Param** to open the **System Parameter** dialog box. For details, please see [System Parameter](#).

### 2.2.6.1 Machine Param

Parameter	Description
G00 speed	G00 speed of each axis during machine tool machining. Range: 1~100000mm/s.
G00 acc change time	G00 acceleration change time of each axis during machine tool machining. Range: 1~10000ms.
Max acceleration at corners	The maximum acceleration of feeding movement on adjacent axes, and the recommended value is 1~2 times of the acceleration. Range: 0.1~50000mm/s <sup>2</sup> .
G00 acc	The maximum acceleration of each axis during machine tool machining. Range: 0.001~50000mm/s <sup>2</sup> .
Feedrate acc	The total acceleration of the acceleration phase during machine tool machining. Range: 0.1~50000mm/s <sup>2</sup> .
Feedrate acc change time	Change time of uniaxial acceleration during machining.
Rcircle max s	The maximum allowable speed corresponding to a reference circle with a diameter of 10 mm. Range: 1.667~166.667mm/s.

### 2.2.6.2 User Habit

Parameter	Description
Do piercing at resume	Whether to enable do piercing at resume.
Additional actions after machining	It includes not move, return to marked point, return to fixed point, return to workpiece origin and other additional behaviors of X and Y axes after machining.
Outter fixed height cutting	After checking, the right angle angle steel and right angle channel steel are cut to the outer length using fixed height.
Additional actions begin machining	Includes no actions, auto clear workcoor and automatic tube edge finding.

Parameter	Description
Heavy tube speed	<p>After checking, configure the tube heavy speed limit conditions: Make sure to add and set materials in <a href="#">Manage Material</a> before configuration.</p> <ol style="list-style-type: none"> <li>1. Click <b>Speed Limit Setting</b> to open the <b>Heavy Tube Speed Limit</b> dialog box.</li> <li>2. Enter a value in the <b>Data Array</b> input box and click <b>Confirm</b>.</li> <li>3. In the <b>Data</b> area. Configure speed limit strategy for different tube weights, acceleration and speed of Y-axis and B-axis.</li> </ol> <p><b>Note:</b> Data area, the weight is required to be input in an incremental manner.</p> <ol style="list-style-type: none"> <li>4. Click <b>Update</b>.</li> </ol>
Set tube length	<p>When using external PLC communication for loading, calculate the clamping position of the rear chuck through the length of the tube during loading. Click <b>Set Tube Length</b> to open the <b>Set Tube Length</b> dialog box. For the setting method, see <a href="#">Set Tube Length</a>.</p>
Check ckstatus before machining	<p>If checked, it will be checked whether the status of the front and rear chucks is consistent with that set in <b>Ckstatus Setting</b> before machining.</p>
Ckstatus setting	<p>Configure the chuck or unclamp action of the front and rear chucks for detection before machining.</p> <ol style="list-style-type: none"> <li>1. Click <b>Ckstatus Setting</b> to open the <b>Ckstatus Setting</b> dialog box.</li> <li>2. Check the chuck to be set, and Check <b>Chucking</b> or <b>Unclamp</b> according to the actual situation.</li> <li>3. Click <b>Confirm</b>.</li> </ol>

### 2.2.6.3 Follow-up Control

Parameter	Description
Leapfrog	Whether to enable leapfrog function.
Leaping Min. dis	<ol style="list-style-type: none"> <li>1. When the endpoint of the graph reaches the start point of the next graphic, the Z-axis needs to be lifted up.</li> <li>2. When the distance from the endpoint of the graphic to the start point of the next graphic is less than this value, no leapfrog will be performed, and the cutting head will not be lifted up, but will be moved horizontally to the start point of the next graphic.</li> <li>3. Not effected by the leapfrog enabled state.</li> </ol>
Follow Max. H	<p>When the cutting height/perforation height is less than this value, it directly follows the set height; When the cutting height/piercing height is greater than this value, follow it to 1mm and then lift it to the set height.</p>

Parameter	Description
Z up Pos.	After return to the mechanical origin, close the following or the mechanical coordinate position where the Z-axis stop at the end of machining.
Fixed height	After the fixed height cutting is enabled, the follow-up is not opened during the cutting process, and the Z-axis is fixed at a <b>Fixed Height Position</b> . You can move to the actual height and click <b>Gst Fixed Pos</b> or enter it manually.

#### 2.2.6.4 Gas Param

Parameter	Description
Default gas type	Open the default gas used in the blowing port.
Gas change delay	It is mainly used for progressive pierce and staged pierce. If the cutting gas is different from the pierce gas, the laser is not turned off during the gas switching process after the completion of piercing.
1st point blow delay	Blowing delay after machining start/breakpoint resume.
Blow delay	The blowing port is switched from closed state to open state, and the blowing delay will be executed.
Default gas type	Open the default gas used in the blowing port. When the user select oxygen blowing, the proportional valve can open the port.
Gas change delay	It is mainly used for progressive pierce and staged pierce. If the cutting gas is different from the pierce gas, the laser is not turned off during the gas switching process after the completion of piercing.

#### 2.2.6.5 Clean by Gas

Parameter	Description
Clean by gas	Whether to enable clean by gas function. Clean by gas function is used to blow air before cutting, which is used to clean the nozzle and make the gas more sufficient in the pipeline to ensure the actual cutting quality.
Gas pressure	Percentage of air pressure used for gas cleaning.
Duration	The duration of gas cleaning.
Interval	The time interval between cleaning when the number of clean is greater than 1.
Times before start	Number of times the gas was cleaned when the machining was started.
Times in resume	The number of times the gas is cleaned when the breakpoint resumes.

#### 2.2.6.6 Burst Param

Parameter	Description
-----------	-------------

Parameter	Description
Power	Set the laser intensity at burst.
Frequency	The frequency of light emitted by the pulse during burst.
Duty cycles	The ratio of light output time within a single cycle to the whole cycle.
Delay	Duration of laser on during burst.

### 2.2.7 Focus Control

Cutting different tubes requires different focus; In order to ensure the quality of machining, different focal points should be used during piercing and cutting. **The Focus Control** function is used to automatically adjust the focus during machining.


In the actual machining process, you can click **Layer Setting** and set the cutting parameter **Cutting Focus** or piercing parameter **Focus** in the **Layer Setting** dialog box to use this function.

#### Prerequisite:

Make sure that the system parameter **Enable Focus Control** is set to **Yes**, and restart the software to make the setting take effect.

#### Operation Steps:

1. In the menu bar, click **Common** → **Focus Control** to open the **Focus Control** dialog box:





2. Check **Parameter Setting** and set corresponding parameters.
3. Click the following buttons to control the action of the machine tool:
  - **+ / -**: Adjust the focus position with **Jog Speed**.
  - **Locate**: Locate to the focus position set in the left input box at **Positioning Speed**.
  - **To Mach O**: The W-axis returns to the mechanical origin.
  - **Stop**: The W-axis stops moving.
4. Click **Confirm**.

## 2.2.8 Follow-up Control

### 2.2.8.1 Overview

The corresponding relationship between capacitance value and distance is used to control the Z-axis floating up and down in real time to ensure that the relative distance between the cutting head and the plate is always constant.

In the menu bar, click **Common** → **Follow-up Control** to open the **Follow-up Control** page:



1. [Page Switch Area](#)
2. [Follow-up Control Area / Follow-up Parameter Setting Area](#)
3. [Coordinate Display Area](#)
4. [Manual Control Area](#)
5. [Follow-up Control Button](#)

#### 2.2.8.1.1 Page Switch Area

Tab	Description
System page	Enter the follow-up control area.
Parameter page	Enter the follow-up parameter setting area.


### 2.2.8.1.2 Coordinate Display Area

The mechanical coordinates and workpiece coordinates of each axis are displayed.

Axis	Feedback
X	0.000
Y	0.000
Z	0.000

### 2.2.8.1.3 Manual Control Area

Manually control the machine tool movement.










The manual control area includes:

Control Button	Description
Axis direction button	Click the direction button corresponding to each axis to control the positive or negative movement of each axis of the machine tool.
Continuous rapid mode	<ul style="list-style-type: none"> <li>In the continuous low speed mode, click the <b>Rapid</b> button to highlight and switch to the continuous rapid mode.</li> <li>Press an axis direction button, the machine tool moves at low speed/high speed, and stop after releasing the button.</li> <li>Press several direction buttons at the same time, the selected axis moves at low speed/high speed at the same time, and it stop at the same time after releasing the button.</li> </ul>
Step mode	Click the axis direction button, and the machine tool will stop after moving the set step.

### 2.2.8.1.4 Follow-up Control Button

Control the machine tool to perform follow-up related operations.

Control Button	Description
<b>Follow</b>	Follow the switch, when turn on, according to the calibration data and set the follow height to maintain the relative distance between the cutting head and the tube unchanged. When turn off, the Z-axis returns to the berth position.

Control Button	Description
 <b>Z Home</b>	Z-axis returns to the mechanical origin entrance.
 <b>Stop</b>	The system will stop the current movement and enter the idle state, which is a method for the system to interrupt the task normally in the follow-up control process.
 <b>E-stop</b>	System emergency stop.
 <b>Servo Calibration</b>	It is a special button under the speed loop control mode. The system automatically performs compensation and clear servo zero drift.
 <b>Calibration</b>	The main function is to collect capacitance data, match the distance between the cutting head and the cutting board surface, and the relationship between the cutting head capacitance feedback.
 <b>One Key Calibration</b>	<p>One key calibration is to improve the efficiency of calibration on the basis of calibration, and to calibrate and update data again when it has already been calibrated. One key calibration allows the cutting head to quickly move to a certain height on the board and perform calibration actions.</p> <p>When turning on, follow to the 5mm position first and then perform the calibration action. Note: To perform this function, it is necessary to ensure that there is a tube directly below the cutting head.</p>
 <b>Clear Data</b>	Perform data clearing, and the software will clear the calibration data and reset the touch part capacitance.

### 2.2.8.1.5 Follow-up Control Area

#### 2.2.8.1.5.1 Main Parameter Area

The parameters displayed in this area are divided into:

- Real time monitoring parameters (values cannot be modified):

Parameter	Description
Enable	Used to identify the follow-up on status.
Z speed	Displays the current Z-axis running speed.
Z Pos.	Displays the current Z-axis mechanical coordinate.
Capacitance	Displays the current capacitance value. When the cutting head is closer to the plate, the parameter is smaller; When the cutting head touches the plate, this parameter is 0 (metal plate).

- Part of common follow-up parameters (values can be modified):



Parameter	Description
Follow height	The relative distance value between the nozzle and the tube when following.
Max speed	The maximum speed supported on the physical hardware of the Z-axis.
Sensitivity	Control the sensitivity of follow-up.
Berth pos	After returning to the mechanical origin, turn off the following or when the machining is finished, the berth position of the cutting head's mechanical coordinate.


Click the current value of the parameter and enter the parameter value to be modified in the dialog box. For details, see [Parameter](#).

### 2.2.8.1.5.2 Oscillographic Area

Click the **Calibration Data** button in the upper right corner to switch to the following curve page:

- **Calibration Data**


The curve shows the corresponding relationship for the capacitance and position between the cutting head and the plate when the cutting head is automatically calibrated.



- X-axis: Capacitance value.
- Y-axis: The distance between the cutting head and the plate.

- **Real-time Capacitance**

The curve shows the real-time capacitance change over a period of time.




- X-axis: Time.
- Y-axis: Capacitance value.

While keeping the cutting head and plate stationary, observe the **Max Difference** in the upper left corner, which reflect the difference between the maximum and minimum capacitance during this period. Because the greater the value is, the greater the interference is, and the more unstable the capacitance measurement is, so **Max Difference** is not greater than 30 as the ideal value.

- **Follow Error**

The curve shows the difference between the current **Follow Height** and the set follow parameter **Follow Height**, reflect the dynamic accuracy of the follow effect.



In the **Follow Error** page, pause the waveform: Double click any point in the page to pause the waveform, and the **Auto** sign at the top of Y-axis will become **AutoOff**.

### 2.2.8.1.5.3 Follow-up Parameter Setting Area

Display all parameters related to servo control. For details, see [Parameter](#).

Based on user permissions and identity, the follow-up parameters are divided into operator parameters and manufacturer parameters, and the system displays operator parameters by default.

Select the following method to open the **Parameter Setting** dialog box and enter the parameter value to be modified:

- After moving the cursor to the current value of the parameter, double click the left mouse button.
- Press the direction keys ↑, ↓, ←, → on the keyboard, and then press the **Enter** key.

To view or modify the manufacturer's parameters, check the manufacturer and enter the password.

### 2.2.8.2 Operation

After understanding the layout and application of the follow-up debugging operation interface, start follow-up debugging.

Before the follow-up debugging, do the following operations:

1. [Execute Preparatory Project](#).
2. [Detection Capacitance](#).

Follow-up debugging according to the following steps:

1. [Execute Servo Calibration](#).
2. [Execute Automatic Calibration](#).

After debugging, [Check Follow-up](#) is successfully debugged or not.

#### 2.2.8.2.1 Execute Preparatory Project

##### Operation Steps:

1. Check that the hardware is installed correctly.
2. Check that the drive parameters and follow-up [Parameter](#) have been set.
3. Check and make sure that the movement speed is the set manual low speed value, and use it without collision.
4. Check and ensure that there is no alarm in the software, and the **Current Capacitance** parameter on the interface has a value display.
5. Make sure that the Z-axis direction is adjusted correctly.
6. Move the Z-axis in the positive or negative direction in the step mode, and observe whether the Z-axis coordinates change the corresponding step length. Pay attention to the positive and negative changes. If they are inconsistent, repeat steps 1 to 2.
7. Make sure that the **System Parameter** of the software, the basic movement and coordinate display are correct, and the Z-axis can return to the mechanical origin correctly.

#### 2.2.8.2.2 Detection Capacitance

Check the status of the capacitance sensor when the cutting head is stationary or running.

##### Operation Steps:

1. Contact the plate with the cutting nozzle and ensure that the current capacitance value is 0.
2. Set the follow-up parameter **Z axis Berth**.

3. Move the Z-axis to make the distance between the nozzle and the tube within 5mm, and the capacitance fluctuation should not exceed 50. When blowing is turned on and off, the capacitance fluctuation should not exceed 30.

If it is unstable, the current electrical interference is serious. For details, see [Serious Electrical Interference](#).

### 2.2.8.2.3 Execute Servo Calibration

In non-bus control system, servo calibration solves the problem of servo motor zero drift caused by speed loop control.

#### Operation Steps:



1. Click **Servo Calibration** and the system will automatically generate the value of servo parameter **Servo Compensation Parameter**.

At this time, the cutting head moves back and forth slightly to compensate.

### 2.2.8.2.4 Execute Automatic Calibration

Collect capacitance data, match the relationship between the distance between the cutting head and the cutting board and the capacitance feedback of the cutting head.

#### Prerequisite:

- The follow-up parameter **Non-metal Calibration** has been set to the type of actual calibration material.
- Capacitance detection is 0.

#### Operation Steps:

1. Move the cutting head to about 5mm near the plate surface and keep the plate surface still.



2. Click **Calibration**, the system starts to calibrate, and takes about 20s to complete the calibration.




3. **(Optional: )** Click **One Key Calibration**.

**Note:** If it is not calibrated, one key calibration cannot be used.

The automatic calibration process is as follows:

1. The cutting head slowly moves downward to detect and touch the plate.
2. After touching the plate, move upward for 5mm.
3. The cutting head moves down slowly for the second time to detect and touch the plate.
4. After touching the plate, slowly move up the set calibration distance and acquire the calibration data to obtain the calibration curve:



After calibration, the system automatically estimates the stability and smooth of the calibrated curve:

Index	Description
Stability	<p>It refers to the data difference between falling 5mm to touch the plate and lifting 5mm to touch the plate. The greater the difference, the worse the stability.</p> <p>If the stability is <b>Poor</b>, it may be that the vibration is large or the external interference is strong, and it needs to be recalibrated.</p>
Smooth	<p>Refers to the smoothness of the curve.</p> <p>If the smooth is <b>Poor</b>, it means that the curve is not smooth, has undulations or burrs, and needs to be recalibrated.</p>

#### 2.2.8.2.5 Check Follow-up

##### Prerequisite:

Successfully calibrated.

##### Operation Steps:

1. During the **Follow-up Control** operation, ensure that the cutting head is not oscillated and the following distance is correct.  
After that, you can use a screwdriver or a small piece of iron to move back and forth under the cutting head, and observe whether the cutting head move up and down according to the position of the screwdriver or the small piece of iron, and whether the cutting head is ossification.  
If oscillation, reduce the positioning sensitivity and increase the inposition tolerance parameter to suppress oscillation.



2. In the menu bar, click **Set** → **System Parameter** to find the system parameter **Out Margin Check** and set it to **Yes**.

Enable this feature can effectively improve security.

### 2.2.8.3 Parameter

All follow-up parameters and their descriptions on the **Parameter** page of the **Follow-up Control** dialog box.

#### 2.2.8.3.1 System Setting

Parameter	Description	Range	Value
Axis direction	The direction of the cutting head away from the tube is positive, the parameter can only be set to 1, if the direction is wrong, please modify the value of the driver direction.	<ul style="list-style-type: none"> <li>▪ 1: Positive direction.</li> <li>▪ -1: Negative direction.</li> </ul>	1
Pulse equivalent	The displacement or angle generated by each control pulse on the Z-axis.	0.000001mm/p~999mm/p	0.001mm/p
Workbench stroke upper limit (Z)	Upper limit of soft limit value.	-1000mm~99999mm	0
Workbench stroke lower limit (Z)	Lower limit of soft limit value.	-99999mm~0mm	-1000
Screw pitch (Z)	The screw pitch in the Y-axis direction.	0mm~360mm	10
Coarse positioning direction (Z)	In the process of returning to the mechanical origin, the motion direction of the Z-axis coarse positioning stage.	<ul style="list-style-type: none"> <li>▪ 1: Positive direction.</li> <li>▪ -1: Negative direction.</li> </ul>	1
REF switch positioning speed	In the process of returning to the mechanical origin, the feed speed of the Z-axis coarse positioning stage.	0.1mm/min ~10000mm/min	1800
Retract distance (Z)	The additional travel distance of Y-axis after the end of the fine positioning stage returning to the mechanical origin. A positive value means go back in, a negative value means go out, and a value of 0 means not move.	-100mm~1000mm	2

### 2.2.8.3.2 Follow Setting

Parameter	Description	Range	Value
Stand-off distance	The relative distance between the cutting head and the plate during follow-up control.	0mm~30mm	1
ZUP position	After return to the mechanical origin, turn off the following or the mechanical coordinate where the Z-axis berth at the end of machining.	-100mm~100mm	-10
Safe lift height	The safe height for lift when the Z-axis does not return to the mechanical origin.	0mm~100mm	40
Follow-up to the max height directly	When the following height is greater than this value during processing, it will be followed to 1mm and raised to the corresponding following height to ensure the following accuracy.	0.01mm~16mm	5

### 2.2.8.3.3 Follow-up

Parameter	Description	Range	Value
Positioning sensitivity	Control the sensitivity of follow-up positioning movement.	1~20	4
Follow-up sensitivity	Control the sensitivity of follow-up.	1~5	2
Follow-up feed forward	Control follows change speed. The larger the value, the faster the response speed. If the feed forward is too large, the follow up will follow the oscillation.	0~100	80
Inposition tolerance	When it is detected that the height is <b>Follow height ± Inposition Tolerance Value</b> , it is considered that the follow-up is in place.	0mm~655mm	0.3
Vibration suppressing level	The higher the oscillation suppression level is, the stronger the suppression effect on the occurrence of plate oscillation in the machining process is, and the single follow-up sensitivity will be correspondingly reduced.	0~5	0
Servo compensation parameter	Special parameters in speed loop control mode. The value generated after servo calibration. This value above 100 need to be checked for electrical interference.	-255~255	0
Part touching delay (positioning)	Follow the process of touch part detection delay.	0ms~20000ms	100
Part touching delay (follow-up)	Touch part delay during positioning control.	0ms~20000ms	100

Parameter	Description	Range	Value
Part touching delay (pierce)	Touch part delay during follow-up following status.	0ms~20000ms	200
Enable anti-collision	When it is enabled, the cutting head is automatically lifted up when it is detected that the cutting head may collide during dry running.	<ul style="list-style-type: none"> <li>▪ Yes: ON</li> <li>▪ No: OFF.</li> </ul>	Yes
Speed gain	Special parameters in speed loop control mode. The rated power of the motor divided by 10V matches the speed command input gain in the motor.	10~2000	300
Capacitance threshold to trigger cutting head alarm	Threshold value of capacitance to trigger exception alarm in cutting head.	100Hz ~100000Hz	500

#### 2.2.8.3.4 Calibration Setting

Parameter	Description	Range	Value
Enable non-metal calibration	Whether non-metal calibration is used.	<ul style="list-style-type: none"> <li>▪ Yes: Automatic calibration of metal materials.</li> <li>▪ No: Automatic calibration of non-metal materials, such as wood, plastic, etc.</li> </ul>	No
Touch part capacitance	The capacitance value marked by frequency when touching part. It is calculated automatically during the calibration process.	0Hz -1000000Hz	0
Calibration length	During calibration, the capacitance data within this range shall be recorded. When the Z-axis travel is short, the parameter value can be appropriately reduced.	5mm~50mm	18
Part touching speed	When calibrating, the speed of touch part movement.	0mm/min~10000000mm/min	80
Calibrating speed	Calibration speed.	0mm/min~10000000mm/min	80
Capacitance fluctuation detection	When the capacitance fluctuation is less than the threshold value every 1mm during calibration, the calibration process is interrupted.	-	30



### 2.2.8.3.5 Speed Setting

Parameter	Description	Range	Value
Z G00 speed	The speed of downward and upward movement of the floating head. When the dry running speed is set to a large value, the calibration length needs to be increased so that there is enough deceleration area when following the downward direction to avoid collision with the plate.	0~ Maximum speed of axis	15000
Follow acceleration	Follow the acceleration.	1000mm/s <sup>2</sup> ~50000mm/s <sup>2</sup>	12000
Axis maximum speed (Z)	The maximum speed supported by the hardware is numerically equal to the rated speed of the Z-axis motor * the pitch of the Z-axis.	1mm/min~100000mm/min	30000

### 2.2.8.3.6 Real-time Statue Check

Parameter	Description	Range	Value
Detect out-margin	Whether or not to enable detect out target at any time, and stop moving when it encounters out-margin.	<ul style="list-style-type: none"> <li>▪ Yes: Detection.</li> <li>▪ No: Not detection.</li> </ul>	Yes
Empty leapfrog detection tolerance	Empty leapfrog detection tolerance.	0mm~225mm	3

### 2.2.8.3.7 Z Manual Speed

Parameter	Description	Range	Value
Manual high (Z)	Acceleration of Z-axis in manual mode.	0mm/s <sup>2</sup> ~100000mm/s <sup>2</sup>	5000
Manual low (Z)	The speed of Z-axis during high speed operation in manual mode.	1200mm/min~30000mm/min	1800
Manual continuous low (Z)	Default speed of Z-axis in manual mode.	0.1mm/min~1800mm/min	1200

### 2.2.8.4 Common Problem

Through this section, you can view the problems encountered in the follow-up debugging process and their solutions.

#### 2.2.8.4.1 Serious Electrical Interference

##### Reason

- The position of the servo driver affects the electrical interference.
- The shielding layer is damaged or wound to the external iron frame.
- There is not conductive between pin 4 of M16 three core aviation plug drag chain cable and amplifier.

- There is a gap between the amplifier of the follow-up instrument and the machine tool.
- Radio frequency cable is damaged.
- The machine tool has poor contact with the ground.

**Solution**

- **Methods for Physically Eliminating Interference**
  - Make sure that the servo driver, lambda 5E controller and EX33A expansion terminal board are in good contact with the ground.  
If the contact is poor, drive the ground pile again.
  - Ensure that the cable shield is intact.  
If not, replace the cable shield.
  - Ensure that pin 4 of the M16 three core aviation plug drag chain cable is conductive to the amplifier.  
If not, replace the cable.
  - Make sure that the amplifier of the follow-up instrument is in full contact with the machine tool.  
If not, polish the veneer with sandpaper to remove the oxide layer before installing the amplifier.
  - Test whether the radio frequency cable is intact through the multi-meter.  
If not, replace the radio frequency cable.
  - Make sure that the machine tool is in good contact with the ground.

**2.2.8.4.2 The Set Follow Height Has a Deviation from the Actual Follow Height****Reason**

The ceramic ring or nozzle was not calibrated when it was replaced, or it was not firmly installed. The capacitance fluctuates greatly during blowing, resulting in a certain deviation of capacitance curve.

**Solution**

Follow the steps below to troubleshoot the problem:

1. Ensure the ceramic ring or nozzle is securely installed.
2. Ensure that the capacitance fluctuation is within the set compensation range when blowing.

If the above is normal, recalibrate. For details, see [Execute Servo Calibration](#) and [Execute Automatic Calibration](#).

**2.2.8.4.3 Capacitance Feedback is Normal, Calibration Result is Good, but Cutting Head often Stops Working****Reason**

It may be that the external force generated by the gas of the cutting head causes the poor contact between the internal contact of the ceramic ring and the signal port of the cutting head, triggering the touch part alarm, so that the cutting head will stop working when the nozzle has no direct contact with the plate during the cutting process.

**Solution**

Replace the qualified ceramic ring.

**2.2.8.4.4 When Moving Z-axis or Directly Turning On Follow-up, the System Gives an Alarm of "Follow-up Error Status"****Reason**

- The superposition of the reverse running direction of the Z-axis motor and the **Offset Phenomenon** caused by external interference.
- It is only caused by **Offset Phenomenon**.  
The simple determination method of **Offset Phenomenon** is as follows:
  - a. Switch on the servo.
  - b. Open the cutting software to enable the servo, and observe the servo driver display interface.  
If the value changes back and forth and the amplitude is relatively large, it indicates that the external electrical interference is relatively large.
  - c. Observe that the coupling at the connection between the Z-axis motor and the lead screw rotates back and forth slightly.

### Solution

Recalibrate. For details, see [Execute Servo Calibration](#) and [Execute Automatic Calibration](#).

#### 2.2.8.4.5 Error in Encoder Direction or Axis Direction

##### Reason

Error in encoder direction or axis direction parameter setting.

##### Solution

Do the following:

- Modify the encoder direction and observe whether the alarm is released.  
If it is not released, modify the encoder direction to the value before setting, and change the rotation direction of the driver parameter axis.
- If the axis direction and encoder direction are both reverse, set the driver parameter axis rotation direction machine encoder to the reverse value.

#### 2.2.8.4.6 Follow-up in Place Waiting Timeout

##### Reason

- The parameter **Inposition Tolerance** is set too small.
- Calibrate the data difference.
- During machining, it is affected by external slag spraying.
- Follow-up overshoot.

##### Solution

Do the following:

- Increase the rigidity level of the Z-axis servo.
- Check whether the inposition tolerance is set too small.  
The recommended value is 0.1.
- Recalibrate. For details, see [Execute Servo Calibration](#) and [Execute Automatic Calibration](#).
- Adjust the cutting technic.
- Ensure that the follow-up parameters and servo driver parameters are set correctly.

If not, reset the servo driver parameters.

#### 2.2.8.4.7 The Following Error is Too Large

##### Reason

The following error is greater than the set out margin tolerance value within a time.

##### Solution

Do the following:

- If the error is reported on a flat surface, it may be caused by the follow-up overshoot. Check whether the servo driver gain is too small. If it is too small, increase the servo driver gain.
- If an alarm occurs during climbing, the follow-up sensitivity may be set too small.

#### 2.2.8.4.8 When the System is Idle or in the Process of Machining, Turn On the Following Touch Part Alarm

##### Reason

The capacitance shall not be greater than that of the touch part plate.

##### Solution

Follow the steps below to troubleshoot the problem:

1. Ensure that the set value of the bumper plate capacitance is appropriate. The default value of 0 is recommended.
2. If follow is on, touch part alarms:
  - a. Ensure that the parameters **Pulse Equivalent**, **Feedback Pulse Number** and **Speed Gain** are correct.
  - b. Make sure that the drive gain is correct.
3. Touch part alarm during machining:
  - a. Make sure the manual follow is normal.
  - b. Ensure that the capacitance fluctuation range is within 50 when blowing.
4. If the above is normal, the servo driver gain may be small, and increase the servo driver gain appropriately.

#### 2.2.8.4.9 Touch Part Alarm when the System is Static

##### Reason

The capacitance value when the capacitance is less than or equal to the touch part.

##### Solution

Follow the steps below to troubleshoot the problem:

1. Ensure that the body capacitance value and touch part capacitance are correct. If not, replace the body capacitance value and touch part capacitance. For SE001 above V1.4, the normal value of the body capacitance is about 650000. The capacitance of SE0001 in V1.4 and below is about 1.3 million.
2. Use a multi-meter to measure whether the copper core from the nozzle to the cutting head sensor is conductive. If it is not conductive, it indicates that there is a problem with the cutting head.
3. Use a multi-meter to measure whether the nozzle is conductive to the RF cable copper core. If it is not conductive, it indicates that there is a problem with the RF cable. Replace the RF cable.
4. Measure whether the resistance between terminals 1-2 of SE001 is 4.8~5.3K  $\Omega$  (the error range is allowed to be  $\leq 5\%$ ), and whether the resistance between terminals 2-4 is 0  $\Omega$ ~1  $\Omega$ . If the resistance value is abnormal, SE001 is damaged. Replace SE001.
5. Measure whether the corresponding pins of M16 three core aviation line are conductive. If not, replace the cable.

6. If all the above are normal, replace the EX33A expansion terminal board.

#### 2.2.8.4.10 Follow Overshoot

##### Reason

The servo response cannot follow the command speed.

##### Solution

Follow the steps below to troubleshoot the problem:

1. Ensure that the parameters **Pulse Equivalent**, **Speed Gain**, **Pulses Per Revolution** are set correctly.
2. Increase the servo driver gain.
3. Ensure that the maximum speed supported by Z-axis matches the dry running speed, and the dry running speed of Z-axis can be appropriately reduced.



## 3 Loading or Drawing Tool Paths

### 3.1 Overview

Before machining, the tool path needs to be loaded or drawn.

After loading or drawing a graphic, you can perform the edit tool path file operation.







After operating the graph, you can select the following saving operation in the menu bar to save it as a tool path file in the format of .ncexa:

- Save the tool path file, click .
- To save the new tool path file, click  Save as.

#### 3.1.1 Loading Tool Path

Drag the tool path file or nesting result file to be loaded to the software drawing area for loading, or use the following buttons to load:

**Note:** If the nesting result file (ncexa format) is opened, the nesting result list will be expanded and the nesting results will be added to the nesting list. Open other files without nesting results, they will be added to the base layer of the nesting list, and the nesting results list will not be automatically expanded.

Button	Description
	New tool path file, support: <ul style="list-style-type: none"> <li>▪ <a href="#">New Tube</a></li> <li>▪ <a href="#">3D Wrapping</a></li> <li>▪ <a href="#">Standard Part</a></li> <li>▪ <a href="#">Import 3D Part</a></li> </ul>
	Import tool path files in the format of .igs, .iges, .step, .stp.
	Open the tool path file in the format of .ncex, .ncexa.
	Import the G code format tool path file in the format of .nc, .g.
	Insert a part on the spare tube in the tool path file without covering the tool path. support: <ul style="list-style-type: none"> <li>▪ <a href="#">Insert File</a></li> <li>▪ <a href="#">3D Wrapping</a></li> <li>▪ <a href="#">Standard Part</a></li> </ul>
	Save tool file as .ncexa format file.

#### 3.1.2 Draw Part

Select the following methods to draw the part:

- [Import 3D Part](#).
- Draw graphic manually. For details, see [Draw Graphic](#).


- Generate tool path graphic through tube intersection function. For details, see [Tube Intersection](#).
- Generate tool path graphic through tube cutting function. For details, see [Tube Cutting](#).


## 3.2 New

### 3.2.1 New Tube


Create a new standard tube.

#### Operation Steps:


1. In the menu bar, click **Common** →  → **Tubes** to open the **Tube Wizard** dialog box:



2. Click the corresponding tube type to open the **Set Section Param** dialog box:




3. Set the section parameters. The left diagram shows the meaning of the parameters.
4. Click **Finish** to display the new tube in the drawing area.




### 3.2.2 3D Wrapping

The software support calling six standard tube types and configuring wrapping graphics. The wrapping graphics file support the following formats: . g, .nc, .dxf, .dwg, .plt.


#### Operation Steps:

1. In the menu bar, click **Common** →  → **3D Wrapping** to open the **Tube Wizard** dialog box:








2. Click the corresponding tube type to open the **Set Section Param** dialog box:



3. Set the section parameters. The left diagram shows the meaning of the parameters.
4. Click **Finish** to open the file selection dialog box.



5. Select the wrap file.
6. Set unit in file.
7. Set the stretch direction.
8. Click **Open**, and the drawing area will display the new 3D wrapping tube.




### 3.2.3 Standard Part


The software come with 6 commonly used standard tube type parts, which can be created by wizard to support users to use and modify part parameters.

#### Operation Steps:


1. In the menu bar, click **Common** →  → **Standard Part** to open the **Tube Wizard** dialog box:




2. Click the corresponding tube type to open the **Set Section Param** dialog box:



3. Set the section parameters. The left diagram shows the meaning of the parameters.
4. Click **Next** to open the **Set Part Param** dialog box:



5. Set the section parameters. The left diagram shows the meaning of the parameters.
6. Click **Finish** to display the new tube in the drawing area.




### 3.3 Import 3D Part


Import 3D parts are drawn by setting tube type, section and stretch information, intersecting and cutting tubes after creating new tubes.


When creating a new tube type, specify the tube type and parameters. The tube type supports circular tube, rectangular tube, oval tube, waist tube, channel steel, and angle steel.


After using import 3D part function to draw parts, if you need to add other graphics, use 2D edit function to draw.

#### Operation Steps:


1. In the menu bar, click **Common** →  → **Import 3D Part** to open the **Part Edit** page:




- Click  **New**. The tube diagram pops up in the view, **Scale** and **Section** parameters pop up in the left list bar, as shown in the graphic:




- In the **Scale** and **Section** areas, select the tube type and set the tube size according to the actual needs.
- After setting, click **Apply**, and **Main Tube** will be added to the **Parts** area.



<b>Scale</b>	
Stretch Length	200
<b>Section</b>	
Tube type	Circular tube
Diameter	100
thickness	1.5

- Use the tube intersection and cutting functions to draw as needed. For details, see [Set Tube Intersection](#) and [Set Tube Cutting](#).
- After drawing, click  **Confirm** in the menu bar to return to the main interface, where the new part is displayed.




### 3.3.1 Set Tube Intersection

The intersecting function is to generate tube surface perforation through intersecting branch tube on the tube, and the array can be set. The types of intersecting holes include circular hole, rectangular hole and waist hole.

#### Operation Steps:

1. In the 3D drawing **Part Edit** page, click **Tube Intersection** in the menu bar, and the intersection parameter pops up at the lower left corner, as shown in the following graphic:



2. Set the parameters of translate, tube intersection, rotate, array and branch param.  
 See the following table for detailed parameters:

Parameter	Description
X offset	The distance between the intersecting hole center and the starting point of the main tube in the X-axis direction.
Y offset	The distance between the intersecting hole center and the starting point of the main tube in the Y-axis direction.
Z offset	The distance between the intersecting hole center and the starting point of the main tube in the Z-axis direction.
Pair	The branch tube through the whole tube and generate a pair on the main tube. Yes: generated; No: not generate.
Branch length	The length of the branch tube.
X rotation angle	The included angle between the straight line projected by the intersecting branch tube on the YZ plane and the positive direction of the Z-axis.
Y rotation angle	The included angle between the straight line projected by the intersecting branch tube on the XZ plane and the positive direction of the Z-axis.
Z rotation angle	The included angle between the straight line projected by the intersecting branch tube on the XY plane and the positive direction of the Y-axis.
Array machining	Use intersecting arrays. Yes: enabled; No: not enabled.
Y array number	Number of array branches in Y direction.
Y array dis.	Array branch spacing in Y direction.
X array number	Number of array branches in X direction.
X array by angle	Yes: array by angle; No: array by spacing.
X array dis.	Array branch spacing in X direction. The parameter <b>X Array by Angle</b> takes effect when it is set to <b>No</b> .
X array angle	Array branch angle in X direction. The parameter <b>X Array by Angle</b> takes effect when it is set to <b>Yes</b> .
Branch type	Including <b>Circular Tube</b> , <b>Rectangular Tube</b> and <b>Waist Tube</b> .


3. After setting, click **Apply** to add it to the **Parts** view area.

### 3.3.2 Set Tube Cutting

The tube cutting function is to generate cutting graphics on the tube for cutting tube parts.

#### Operation Steps:

1. In the 3D drawing **Part Edit** page, click **Tube Cutting** in the menu bar, and the cutting parameter pops up at the lower left corner, as shown in the following graphic:



2. Set translate, clipper and rotate parameters. See the following table for detailed parameter descriptions:

Parameter	Description
X offset	The distance between the center of the cutting plane and the start point of the main tube in the X-axis direction.
Y offset	The distance between the center of the cutting plane and the start point of the main tube in the Y-axis direction.
Z offset	The distance between the center of the cutting plane and the start point of the main tube in the Z-axis direction.
Left clipper	Yes: the tube with Y-axis coordinate less than the current cutting surface is scrap; No: the tube with Y-axis coordinates greater than the current cutting plane is scrap.
X rotation angle	The angle between the cutoff plane and the YZ plane.
Y rotation angle	The angle between the cutoff plane and the XZ plane.
Z rotation angle	The angle between the cutoff plane and the XY plane.

3. After setting, click **Apply** to add it to the **Parts** view area.

### 3.4 Insert Part

Insert a part on the spare tube in the tool path file without covering the tool path. support:

- [Insert File](#)
- [3D Wrapping](#)
- [Standard Part](#)

#### 3.4.1 Insert File

In the current tube, insert part tool path file and insert part position is:

- If the current tube has no part tool path, insert from the head of the tube.
- If the current tube has a part path, insert it from the end of the part tool path file.


Insert part file format as .igs、.iges、.step、.stp.




**Note:** The inserted part tube type must be consistent with the current tube type and section size.

### Operation Steps:

1. In the menu bar, click **Common** → **Insert Part** → **Insert File** to open the **Open** dialog box:



- Select the part you want to import.
- Set file unit and stretch direction.
- Click **Open**, and the software will identify whether the tube type of the inserted part is consistent with the current tube type and section size.
  - Consistent: The part is inserted on the current tube.



- Inconsistent: **The Alarm/Log Message Bar** prompts the cause of the error.

### 3.4.2 Insert 3D Wrapping


Insert a 3D wrapping graphic in the current tube at:

- If the current tube has no part tool path, insert from the head of the tube.
- If the current tube has a part path, insert it from the end of the part tool path file.

The supported formats for wrapping graphics files are .g, .nc, .dxf, .dwg, .plt.


## Operation Steps:

1. In the menu bar, click **Common** → **Insert Part** → **3D Wrapping** to open the **Open** dialog box:



2. Select the file to import.
3. Set file unit and stretch direction.
4. Click **Open**.

Effect picture:




### 3.4.3 Insert Standard Part

Insert standard part of the same type of tube in the current standard tube at:


- If the current tube has no part tool path, insert from the head of the tube.
- If the current tube has a part path, insert it from the end of the part tool path file.

1. In the menu bar, click **Common** → **Insert Part** → **Standard Part** to open the **Pipe Wizard** dialog box:



2. Set the part parameters. The left diagram shows the meaning of the parameters.
3. Click **Finish**.

Effect picture:



## 4 Edit Path File

### 4.1 Overview

The tool path file can be edited in the **Software Main Interface** and **2D Edit**. When editing and importing, the main differences between the two pages:

- View display
  - Main interface of software: parts are displayed in 3D.
  - 2D edit: 2D expand the part along the centerline of the 3D view to form a 2D view.

- Edit function


The editing functions supported by the **Software Main Interface** and **2D Edit** are different, as shown in the following table. For some supported functions, see the corresponding chapters for details.

Function	Software Main Interface	2D Edit
<a href="#">View Operation</a>	Support	Support
<a href="#">Draw Graphic</a>	Nonsupport	Support
<a href="#">Make Array</a>	Nonsupport	Support
<a href="#">Auxiliary Tool</a>	Nonsupport	Support
<a href="#">Edit Graphic</a>	Nonsupport	Support
<a href="#">Preprocess Graphic</a>	Nonsupport	Support
<a href="#">Quick Edit</a>	Part support	Support
<a href="#">Layer Technic</a>	Support	Support
<a href="#">Machining Technic</a>	Support	Support
<a href="#">Arrange Path</a>	Part support	Support

- Page layout
  - Software main interface: For details, see [Introduce the Main Interface of the Software](#).
  - 2D edit page: In the **Common** menu bar of the software main interface, click



to open the **2D Edit** page.



Page layout description:

No	Name	Description
1	3D view	View the tube from different perspectives and preview the cutting effect. The tube can be scaled, rotated and translated.
2	Menu bar	Collection of function buttons.
3	Layer toolbar	Layer related operation tool button.
4	Drawing area	Preview and draw graphics in this area.
5	Status bar	Current operation related information: operation steps and significance, operation success, etc. Display coordinate position, adjust view zoom, etc.

Preview 3D view:

- Scale: Scroll the mouse wheel, scroll up to zoom in, and scroll down to zoom out.
- Translation: Press **Ctrl** and click the left mouse button to move the mouse.
- Rapid rotate around the tube stretch direction: Press **Ctrl** and scroll the mouse wheel.
- Slowly rotate around the tube stretch direction: Press **Shift** and scroll the mouse wheel.


- Rotate around the tube stretch direction: Hold down the left mouse button and drag the mouse.
- Rotation in any direction: Hold down the mouse wheel and drag the mouse.

## 4.2 Graphic Operation


### 4.2.1 View Operation

View display operation can be performed on the **Software Main Interface** and **2D Edit** pages, and the operation effect is updated synchronously. This article takes the **Software Main Interface** as an example to introduce the method and effect of view display operation.

Related buttons:



Related buttons for **2D Edit**:



#### 4.2.1.1 Select

Select graphic for easy editing. Two graphic selection methods are supported:

- Manual selection: Manually select any graphic.
- Automatic selection: Automatically select the graphic that meets the conditions.

##### 4.2.1.1.1 Manually Select Graphic

**Operation Steps:**

1. In the common toolbar, click .
2. Select any of the following methods to select graphic:
  - Click the left mouse button to select a single graphic.

- Press and hold the **Ctrl** key, click the left mouse button in turn, and select multiple graphics.
- Press the right mouse button and drag the mouse to select graphics. Select all the graphics that intersect the box and are included in the box.


#### 4.2.1.1.2 Automatically Select Graphic

##### Operation Steps:

1. In the menu bar, click **View** → , select:


- **Select All**: The system automatically selects all graphics.
- **Invert**: Inverts the selection of unselected graphics.
- **Cancel**: The system automatically deselects all graphics.
- **Select Unclosed**: Select all unclosed graphics in the file.
- **Select Tiny**: Select the graphic whose X-axis and Y-axis dimensions are smaller than the set value.

i. Select **Select Tiny** to open the following dialog box:




ii. Enter X size and Y size, and click **Confirm**.

- **Select Similar**: After manually select a graphic, click **Select Similar**, and the system will automatically select the graphic with the same type and size as the selected graphic. This operation does not distinguish between angles.
- **Select Similar (Strict in Angle)**: After manually select a graphic, click **Select Similar (Strict in Angle)**, and the system will automatically select graphics with the same type, size, and angle as the selected graphics. This operation distinguishes angles.
- **Select by Layer**: Select the corresponding layer under the submenu, and the system will automatically select the graphic in the layer.
- **Select by Inner-Outer**: Select the corresponding inner graphic (included graphic) or outer graphic (excluded graphic) in the submenu. The system automatically selects the corresponding graphic, and the effect picture is as follows:



Select by Inner-Outer - Inner Graphic



Select by Inner-Outer - Outer Graphic

## 4.2.1.2 Show

In order to better observe the technic effect, the software provides the display/hiding of various technic effects.

### Operation Steps:

1. Check the technic effect to be displayed in the display area of the **View** menu bar, and display the corresponding technic effect in the drawing area:

- **Show Machining Track**


- Description:

The red line is used to display the machining track, especially in the simulation, the simulated machining track is displayed in real time.



If you want to clear the machining path, click the **Clear Machining Track**.

- Effect picture:




- **Show Start Point**

- Description:

Use white dots to display the machining start point of the graphic.

- Effect picture:




- **Show Part Mark**

- Description:

Display part information in the way of mark.


- Effect picture:






- **Show Cutting Head Mode**

- Description:  
During the simulation, the real time simulation shows the running track of the cutting head.
- Effect picture:




- **Show Order**

- Description:  
Use numbers to indicate the machining sequence.
- Effect picture:




- **Show G00 Path**

- Description:  
G00 path is the cutting head movement path from the end of one part cutting to the new one.  
Use the white arrow to display the moving direction of the machining head.
- Effect picture:




- **Show Direction**

- Description:  
Use the white arrow to display the machining direction of the part.
- Effect picture:




- **Show Normal**

- Description:  
Use the color corresponding to the layer to display the effect of normal adjustment.
- Effect picture:



- **Show Tube Margin**

- Description:  
The distance from the starting cutoff edge of the cutting part to the tube edge and the effect is displayed with unused tube.
- Effect picture:



### 4.2.1.3 View

#### 4.2.1.4 Select View Angle

Select a standard angle to view the graphic.

#### Operation Steps:




1. In the menu bar, click **View** → **Select View** and select the following angles in the **Select View** submenu bar to view the graphic:

- Front view
- Rear view
- Left view
- Right view
- Top view
- Bottom view

#### 4.2.1.5 Hollow

Three hollow modes are supported: solid, hollow out and wireframe. Solid hollow mode is displayed by default.


#### Operation Steps:




1. In the menu bar, click **View** → **Hollow** and select the following hollow modes in the **Hollow** submenu bar:

- Solid
- Hollow out
- Wireframe


Effect picture:



Solid



Hollow out



Wireframe


#### 4.2.1.6 Nest View

Displays or hides the nest result list.




#### Operation Steps:



1. In the menu bar, click **View** → **Nest View** to pop up the **Nest Result**:



## 2. Description of the nest result list operation button:


-  Select: Select all or not select nesting results.
-  Delete: Delete the selected nest result.
-  Base result: Switch to the base view.

### 4.2.1.7 Other Common Operations

#### 4.2.1.7.1 Pan

Relocate the position of graphic in the drawing area, so as to observe different parts of the current graphic.


#### Operation Steps:

1. In the common toolbar, click  to use pan function.
2. Select a point, press the left mouse button, drag to the target location and release the mouse.
3. Press **Esc** or right click to exit the tool.

#### 4.2.1.7.2 Best View

The graphics are adjusted to the starting position and the default size, and all are displayed in the drawing area.

#### Operation Steps:


1. Select one of the following methods to use the best view function:
  - In the common toolbar, click .

- In the drawing area, right click and select **Best View**.

#### 4.2.1.7.3 Zoom by Rect

Enlarge the part of the graphic to the size of the view window.

#### Operation Steps:

1. In the common toolbar, click  to use zoom by rect function.
2. Press the left mouse button to move and select the area to be zoomed in. Release the left mouse button to zoom in.
3. Press **Esc** or right click to exit the tool.

#### 4.2.1.7.4 Zoom View

Zoom in or out to see the added technic effect more clearly.

Scroll the mouse wheel to zoom in and zoom out.

#### 4.2.1.7.5 Rotate View













Rotate the view 360 ° to view the tube more comprehensively.

#### Operation Steps:

1. Select one of the following methods to rotate the view:
  - Press the mouse wheel and drag the mouse to rotate the tube in any direction.
  - Press **Ctrl** and roll the mouse wheel to quickly rotate around the tube stretching direction.
  - Press **Shift** and scroll the mouse wheel to slowly rotate around the tube stretching direction.

### 4.2.2 Draw Graphic


The software supports to draw the following graphics, and the system provides a graphic library function, which provides commonly used graphics for users to use directly.

Tool	Name	Tool	Name	Tool	Name
	Dot		Line		Rectangle
	Polyline		Circle		Arc
	Ellipse		Elliptic arc		Polygon
	Star		Text		Gallery


The following describes how to use drawing tools, which will not be described in subsequent chapters.

#### Operation Steps:

1. In the menu bar, click **Common** →  to open the **2D Edit** page:



2. In the menu bar, click the **Drawing** tab to switch to the drawing menu bar, as shown in the following picture:



3. Click the corresponding drawing tool to use it.

#### 4.2.2.1 Dot

##### Operation Steps:

1. In the **2D Edit** page, click the left mouse button to select a point to add a dot graphic.
2. Click the left mouse button to draw the next dot.

3. Right click to exit the tool.

#### 4.2.2.2 Beeline

##### Operation Steps:

1. In the **2D Edit** page, click the left mouse button to select the start point.
2. Click the left mouse button to select the next point.
3. Right click to exit beeline drawing.

#### 4.2.2.3 Rectangle

##### Operation Steps:

1. In the **2D Edit** page, click the left mouse button to select the start point.
2. Move the mouse to the corresponding position and click the left mouse button to select the end point.
3. Right click to exit the tool.

#### 4.2.2.4 Polyline

Polyline refers to a single object composed of multiple lines and arcs. This software supports the switching between lines and arcs.

##### Operation Steps:

1. In the **2D Edit** page, click the left mouse button to select the start point.
2. **(Optional: )** Right click to draw an arc, and click **Tangent Arc** in context menu. By default, the software draws **Lines**.

**Note:** The initial default for a polyline is to draw **Line**.

3. Click the left mouse button to select the next point and repeat. Click the right mouse button and click **Line** or **Tangent Arc** in context menu to switch the drawing tool.
4. After the drawing is complete, right click the mouse button and select the following operations in the context menu as required:
  - To set the current point as the end point of the polyline and the polyline as an unclosed object, click **Confirm**.


**Note:** To close it, check **Closed** in the information above the view after select the graphic.

- To set the current point as the end point of the polyline and the polyline as a closed object, click **Closed**.
  - To cancel all previous selections and exit polyline, click **Cancel**.
5. Continue to click the right mouse button to exit drawing.


#### 4.2.2.5 Circle

##### Operation Steps:

- Use radius to draw circle:

- a. In the menu bar of the **2D Edit** page, click **Drawing** →  → **Radius Circle**.
- b. Click the left mouse button and select the center of the circle.
- c. Click the left mouse button to select a point, and the distance from the point to the center of the circle is the radius.
- d. Click the right mouse button to exit tool.

- Use three point circle to draw a circle:


- 
- In the menu bar of the **2D Edit** page, click **Drawing** → **Circle** → **Three Point Circle**.
  - Click the left mouse button three times to select three points to form a circle.
 

**Note:** Three points can form a triangle if they are not on a straight line and do not overlap. Draw the intersection of any two vertical centerlines to be the center of a circle.
  - Click the right mouse button to exit tool.


#### 4.2.2.6 Arc

##### Operation Steps:

- Use radius to draw arc:

- 
- In the menu bar of the **2D Edit** page, click **Drawing** → **Arc** → **Radius Arc**.
  - Click the left mouse button and select the center of the circle.
  - Click the left mouse button, select a point as the start point of the arc, and the distance to the center of the circle is the radius.
  - Click the left mouse button to select the end point of the arc. The default machining direction of the tool path generated by the software is counterclockwise.
  - Click the right mouse button to exit tool.

- Use three point arc to draw arc:

- 
- In the menu bar of the **2D Edit** page, click **Drawing** → **Arc** → **Three Point Arc**.
  - Click the left mouse button to select a point, which is the start point of the arc.
  - Click the left mouse button to select the second point.
  - Click the left mouse button to select the third point, which is the end of the arc.
  - Click the right mouse button to exit tool.

#### 4.2.2.7 Ellipse

##### Operation Steps:

- In the **2D Edit** page, click the left mouse button to select the center point.
- Click the left mouse button to select two points respectively. The distance from the two points to the center point is the long and short half axes of the ellipse.
- Click the right mouse button to exit tool.

#### 4.2.2.8 Ellipse Ace

##### Operation Steps:

- In the **2D Edit** page, click the left mouse button to select the center point.
- Click the left mouse button to select the long half axis and the short half axis distance respectively.
- Click the left mouse button twice to select the start point and the end point respectively, and the default machining direction of the generated tool path is counterclockwise.
- Click the right mouse button to exit tool.



#### 4.2.2.9 Polygon

##### Operation Steps:

1. In the **2D Edit** page, click the left mouse button to select the center point.
2. Click the left mouse button to select the end point.
3. Click the right mouse button to exit tool.

#### 4.2.2.10 Star

##### Operation Steps:

1. In the **2D Edit** page, click the left mouse button to select the center point.
2. Click the left mouse button to select the end point.
3. Click the right mouse button to exit tool.

#### 4.2.2.11 Text


##### Operation Steps:


1. In the **2D Edit** page, drag the cursor to determine a rectangular text box.
2. Enter text in the text box.
3. **(Optional: )** Press **Ctrl+Enter** to switch to the next line.
4. Press **Enter** or click **Confirm** to complete the text drawing.
5. Click the left mouse button to exit tool.

#### 4.2.2.12 Gallery

The software provides common graphic templates, and can set graphic parameters and graphic locations.

##### Operation Steps:

1. In the menu bar of the **2D Edit** page, click **Drawing** →  to open the **Gallery** dialog box:



2. Click to select a graphic, and the preview effect of the graphic will be displayed below.
3. Double click the corresponding parameter in the parameter bar as required to set the parameter value.

4. In the **Path Position** area, select any of the following methods to set the position of the graphic.

- Check **Fixed**, set the values of X coordinate and Y coordinate, and click **Confirm**.

**Note:** The X coordinate and Y coordinate values set are the red dot positions on the preview effect picture.

- Check **Set by Mouse** and click **Confirm** to close the **Gallery** dialog box. In the **Drawing Area**, select a place and click the mouse.

### 4.2.3 Make Array

Array is one of the simple nested forms, which can copy the graphic into several identical and neatly arranged graphics to improve the machining efficiency.

Array modes are divided into:

- [Rectangular Array](#)
- [Circular Array](#)
- [Manual Array](#)


#### 4.2.3.1 Rectangular Array

Copy the graph along the rectangular array.

#### Operation Steps:

1. Select one or more graphics in the **2D Edit** page.

2. In the menu bar, click **Drawing** →  to open the **Rectangular Array** dialog box:




3. Set the r count and c count for a rectangular array.

4. In the **Offset** area, set the offset mode:

- **Offset:** Translate based on the center of the graphic.
- **Gap:** Translate based on the graphic frame.

5. Select the row dist(v) and col dist(h) for the rectangular array.

Effect picture:




### 4.2.3.2 Circular Array


Circular array has two modes:

- Array by center: Make the array based on the selected center coordinates.
- Array by radius: Make the array around the currently selected graphic.

#### Operation Steps:

1. Select one or more graphics in the **2D Edit** page.

2. In the menu bar, click **Drawing** →  to open the **Circular Array** dialog box:




3. Set the array mode.

- Array by center: Check **Array by Center**. Set the rotation center point coordinates of the circular array.
- Array by radius: Check **Array by Radius**. Set parameter for **Radius** and **Stating Angle(A)**.

4. Set the parameters of the **Array Param** area.

- **Array Counts**: The total number of copied circles.
- **Array Angle**: Total column offset angle.

Effect picture:





### 4.2.3.3 Manual Array

Manually select the area range of the array, and the graphics in this area are copied as a rectangle array.

#### Operation Steps:

1. Select one or more graphs in the **2D Edit** page.

2. In the menu bar, click **Drawing** →  **Manual Array** to open the **Manual Array** dialog box:



3. **(Optional: )** If need to delete the original graphic, check **Delete the Original Graph**.

4. Set **Row Dist** and **Col Dist**.

- **Row Dist**: Translate left and right based on the graphic frame.
- **Col Dist**: Translate up and down based on the graphic frame.


5. Click **Confirm** and the cursor becomes .

6. Click the left mouse button to select the start position.

7. **(Optional: )** If need to reselect the start position, click the right mouse button.

8. Drag the mouse to select the destination and click the left mouse button.

Effect picture:



#### 4.2.4 Auxiliary Tool

The system provides the following auxiliary tools.


- [Property](#)
- [Measure](#)
- [Catch](#)


##### 4.2.4.1 Property

You can change the size and tiling angle of a graphic by viewing and modifying the properties of a single or multiple graphics.

#### Operation Steps:

1. In the **2D Edit** page, select one or more graphics.
2. Select any of the following methods to open the **Property** page:


- In the menu bar, click **Drawing** →  **Property**.
- Right click and select **Property**.



3. Modify property parameters:

- Geometry graphic:
  - The X and Y values show the X-axis and Y-axis coordinates of the start point of the selected graphic.
  - The width and length of the rectangle are the width and length of the selected graphic.



- Tilting angle is the angle of the graphic relative to the X-axis.
- Others:
  - You can view and modify the scale value to scale the size of the selected graphic.
  - The values of width and height change with the set scaling.
  - Scale center can be set center, left, right, up, bottom, left top, left bottom, right top, right bottom.
  - The R angle can be set manually.


4. After the modification is complete, click  to close the **Property** page.

#### 4.2.4.2 Measure

Measure the specified distance between two points, the X/Y offset, and the angle forward to the X-axis.

#### Operation Steps:

1. In the menu bar of the **2D Edit** page, click **Drawing** →  and  will appear behind the mouse.
2. Click the left mouse button to select the start point.
3. Move the cursor to the measurement end point, and the measurement results will be displayed under the mouse according to the position of the cursor.




4. Right click to exit the tool.


#### 4.2.4.3 Catch

The feature points of existing graphics can be located more accurately when drawing objects.

When the mouse is close to the feature point, the system can easily catch it, which convenience the accurate connection between graphics.

#### Operation Steps:


1. In the menu bar of the **2D Edit** page, click **Drawing** → click  → **Catch Options** and open the **Catch Options** dialog box:



2. Select the required options and set **Sensitivity**.  
The higher sensitivity can easier to catch feature points.
3. After setting, click **Confirm**.

**Note:** If **Customized** is checked, follow the steps to set the incremental angle:

- a. In the **Tools** bar, click  to open the **Polar IncAngle** dialog box:











- b. Set incremental angle.

**Note:** The system will catch at the preset **Incremental Angle**. For each **Incremental Angle** rotation, the system will give the corresponding auxiliary line prompt.

- c. Click **Confirm**.

#### 4.2.5 Edit Graphic


In the software can not only copy, paste, cut and delete the graphic, but also the following editing operations:

Tool	Name	Tool	Name
 Translate	<a href="#">Translate</a>	 Align	<a href="#">Align</a>
 Scale	<a href="#">Scale</a>	 Join	<a href="#">Join</a>
 Rotate	<a href="#">Rotate</a>	 Explode	<a href="#">Explode</a>
 Mirror	<a href="#">Mirror</a>	 Break	<a href="#">Break</a>

##### 4.2.5.1 Translate

Translate the graphic means moving a graphic in a straight direction, changing its coordinate position without changing its shape or size.


##### Operation Steps:

1. In the **2D Edit** page, select the graphic.
2. Select any of the following methods to translate graphic:
  - In the menu bar, click **Drawing** → , then click anywhere in the graphic, and click the left mouse button to select the target location.
  - Hold down the left mouse button to drag the graphic.

##### 4.2.5.2 Scale

Scale the graphic means to scale the graphic equally and change the size of the graphic.





##### Operation Steps:

1. In the **2D Edit** page, select the graphic.
2. In the menu bar, click **Drawing** → .
3. Click the left mouse button to select the scale center point.
4. Click the left mouse button to select the target point.
5. Move the cursor to adjust the scale ratio.
6. Click the left mouse button to confirm.

### 4.2.5.3 Rotate

Rotate the graphic means to rotate the graphic in any direction by any angle with a certain point as the selected center.

#### Operation Steps:




1. In the **2D Edit** page, select the graphic.
2. Select the following operations as required:
  - Follow these steps to rotate the graphic around any point:
    - i. In the menu bar, click **Drawing** →  **Rotate**.
    - ii. Click the left mouse button to select the rotate center point.
    - iii. Move the cursor to adjust the rotation angle.
    - iv. Click the left mouse button to confirm.
  - Hold down the **Ctrl** key and drag the rectangle point on any of the four corners of the node edit box.
  - If you want to rotate 90 deg CW, click  **Rotate** → **Rotate 90 deg CW** in the **Menu Bar**.
  - If you want to rotate 90 deg CCW, click  **Rotate** → **Rotate 90 deg CCW** in the **Menu Bar**.
  - If you want to rotate 180 deg, click  **Rotate** → **Rotate 180 deg** in the **Menu Bar**.

### 4.2.5.4 Mirror

Mirror includes the following three modes:

- Mirror horizontal: With the vertical central axis of the graphic as the center, the left and right parts of the figure interchanged.
- Mirror vertical: With the horizontal axis of the graphic as the center, the upper and lower parts of the figure are interchanged.
- Mirror any angle: Take a line at any angle of the graphic as its axis, the left and right parts of the graphic can be interchanged and rotated by any angle.


#### Operation Steps:

1. In the **2D Edit** page, select the graphic.
2. Select the following operations as required:
  - If you need mirror horizontal, click **Drawing** →  **Mirror** → **Mirror Horizontal** in the menu bar.
  - If you need mirror vertical, click **Drawing** →  **Mirror** → **Mirror Vertical** in the menu bar.
  - If you need mirror any angle, complete the following steps:
    - i. Click **Drawing** →  **Mirror** → **Mirror any Angle** in the menu bar.
    - ii. Click the left mouse button to select the mirror center.
    - iii. Move the cursor to adjust the rotation angle.
    - iv. Click the left mouse button to confirm.

### 4.2.5.5 Align

Change the relative position of multiple graphics to align them.


#### Operation Steps:

1. In the **2D Edit** page, select multiple graphics.
2. Click **Drawing** →  **Align** in the menu bar and select the alignment in the submenu:
  - Left aligned



- Right aligned
- Align top
- Align bottom
- Align center point
- Align midline
- Align vertical midline
- Distribute horizontally
- Distribute vertically

The system automatically performs the alignment. Effect picture:




#### 4.2.5.6 Join


Join graphics are used to join unconnected graphics into a single graphic.

This function applies only to unclosed objects, non-text, and groups.


It is advised to open catch before use. For details, please click [Catch](#).

**Operation Steps:**

1. In the **2D Edit** page, select multiple graphics.
2. Select any of the following methods to open the **Join** dialog box:
  - In the menu bar, click **Drawing** →  **Join**.
  - Click the right mouse button and click **Join**.



3. Enter the value in the **Tolerance** settings box.  
Tolerance is the maximum value of spacing between graphics that needs to be satisfied for joining.  
Defaults merge tolerance range: [0.01, 10] mm.
4. To set join **Strategy**, click **Dis First/ Len First/ Dir First**.  
When more than three endpoints in the same join position meet the join tolerance, the graphic with the closest join distance/longest join length/same direction is preferred. Graphics will preferentially join nearest/longest/same direction.  
Effect picture:



5. (Optional: ) If need to join two lines on different layers, check **Join Among Different Layers**.

#### 4.2.5.7 Explode


Delete redundant lines to achieve the purpose of modifying tool path, mostly used for polylines.

When used together with [Join](#), it can correct the errors in drawing graphics and ensure the quality of machining.

**Explode** has the following characteristics:

- When the object is a graphical group, **Explode** is equivalent to **Dissolving the Group**.
- When the object is text, **Explode** is equivalent to **Turning Text into Graphics**.

**Operation Steps:**

1. In the **2D Edit** page, select the graphic.
2. In the menu bar, click **Drawing** → .

### 4.2.5.8 Break


Used to break the graphic into multiple polylines. There are two methods to break graphic:


- Auto: Break the selected object automatically based on the value set.
- Manual: Manually select the break location to perform the break on single graphic at one time.

Common usage scenarios:

- Break can make the cut part connected with the surrounding material, which has the same effect as micro joint.
- When drawing the graphic, remove the excess graphic to facilitate the appearance of the ideal shape.


### Operation Steps:


1. In the **2D Edit** page, select the graphic.
2. In the menu bar, click **Drawing** → .




3. Perform the following operations based on the break mode selected:
  - Automatic break mode:
    - i. Click **Auto**. Enter **Counts** and **Length**.
    - ii. Click **Confirm**.

Effect picture:



- Manual break mode:
  - i. Click **Manual**. Enter **Length**.
  - ii. Click **Confirm**, the cursor will become .
  - iii. Click the left mouse button to select the break location.
  - iv. Click the right mouse button to manually break.

Effect picture:



#### 4.2.6 Preprocess Graphic


The preprocessing operation of the graphics makes the graphics achieve better processing effect.

The system supports single pretreatment of drawings and batch pretreatment of multiple projects.


##### 4.2.6.1 Delete Overlap Lines

Objects of overlap lines can be deleted as follows:


- Two completely coincident graphics:



- The overlap between a line segment and the graphic:





- The overlap of the graphic itself:



### Operation Steps:

1. Select multiple graphics in the **2D Edit** page.


2. In the menu bar, click **Common** →  → **Delete Overlap lines** to open the **Delete Overlap Lines** dialog box:



3. Set the following:

- **Tolerance**: The distance between the two lines is within the maximum tolerance range.
- **Min Length**: The coincidence length of two lines is greater than the minimum length.

Effect picture:




#### 4.2.6.2 Simplify Curve


A single object consisting of many lines and arcs in which nodes control and adjust the shape of the curve.

Simplify curve means that the system automatically reduces the excess part in the graphic within the tolerance range, to speed up the response speed of the graphic operation.

### Operation Steps:

1. Select the graphic in the **2D Edit** page.

2. In the menu bar, click **Common** →  → **Simplify Curve** to open the **Simplify Curve** dialog box:



3. Enter **Tolerance** value in the box and click **Confirm**.  
**Curve Simplifying Successful** will appear in the **Information Bar**.


#### 4.2.6.3 Smooth Curve

Smooth a number of polylines to ensure smooth machining.

##### Operation Steps:

1. Select the graphic in the **2D Edit** page.

2. Select either of the following to smooth curve:

- In the menu bar, click **Common** →  → **Smooth Curve**.
- Click the right mouse button and click **Smooth Curve**.

**Curve Smoothing Successful** will appear in the **Information Bar**.

#### 4.2.6.4 Convert Text to Graphic

It is used to convert text into polylines, and technics can be added later.

##### Operation Steps:

1. Select the graphic in the **2D Edit** page.

2. Select either of the following to convert text to graphic:

- In the menu bar, click **Common** →  → **Convert Text to Graphic**.
- Click the right mouse button and click **Convert Text to Graphic**.

The number of graphics selected in the **Information Bar** will increase.

#### 4.2.6.5 Convert Polyline to Circle


Used to convert a closed polyline that looks like a circle to a circle.

##### Operation Steps:


1. Select the graphic in the **2D Edit** page.

2. Select either of the following to open the **Convert Polyline to Circle** dialog box:


- In the menu bar, click **Common** →  → **Convert Polyline to Circle**.
- Click the right mouse button and click **Polyline to Circle**.



3. Enter **Max Tolerance** and **Max Relative Error** in the box.
4. Click **Confirm** and the following dialog box will pop up after the conversion is successful:



Effect picture:




#### 4.2.6.6 Trim Self-intersection

Split the self-intersecting polyline graphic and cut out the excess lines.


#### Operation Steps:

1. Select the graphic in the **2D Edit** page.
2. In the menu bar, click **Common** → **Instant Preprocess** → **Trim Self-intersection** to open the **Trim Self-intersection** dialog box:



3. Set the length and click **Confirm**. The software will automatically cut out the lines within the length range.

Effect picture:




#### 4.2.6.7 Instant Preprocess

The instant preprocess function sets error-prone items in the common graphics machining process. Users can automatically process the graphics by selecting the items to be processed according to their needs, so that the graphics can achieve better machining effects.

The instant preprocessing function items mainly include: simplify curve, delete overlap lines, join, delete dots, delete tiny circles, delete tiny curves, inter trim, polyline to circle, auto set fill/unfill, etc.

#### Operation Steps:

1. Select the graphic in the **2D Edit** page.
2. Select either of the following to open the **Instant Preprocess** dialog box:

- In the menu bar, click **Common** → .
- Click the right mouse button and click **Instant Pre-process**.

Instant Preprocess ×

<input checked="" type="checkbox"/> Simplify Curve		Tolerance: <input type="text" value="0.005"/>
<input checked="" type="checkbox"/> Delete Overlap Lines	Min Length: <input type="text" value="0.2"/>	Tolerance: <input type="text" value="0.1"/>
<input checked="" type="checkbox"/> Join	<input type="checkbox"/> Different Layers	Dir First <input type="text" value="Dir First"/> Tolerance: <input type="text" value="0.2"/>
<input checked="" type="checkbox"/> Delete dots		
<input checked="" type="checkbox"/> Delete tiny circles		Max Dia. < <input type="text" value="0.001"/>
<input checked="" type="checkbox"/> Delete tiny curves		Max Scale < <input type="text" value="0.001"/>
<input checked="" type="checkbox"/> Inter Trim		Length < <input type="text" value="0.1"/>
<input type="checkbox"/> Hole		Hole Diameter: <input type="text" value="2"/>
<input checked="" type="checkbox"/> Polyline to Circle	Relative Error: <input type="text" value="0.01"/>	Tolerance: <input type="text" value="0.01"/>
<input checked="" type="checkbox"/> Auto Set Fill/Unfill		
<input checked="" type="checkbox"/> Highlight Unclosed Obj		
<input checked="" type="checkbox"/> Auto Sort		
<input checked="" type="checkbox"/> Apply when import		
Part insertion interval on	<input type="text" value="10"/>	
		<input type="button" value="Confirm"/> <input type="button" value="Cancel"/>



3. Check the desired option and enter a value.
4. If you want to automatically process graphics when importing files according to the above options, select **Apply When Importing**.
5. Set the **Part Insertion Interval On**. When inserting a part with the base layer of **Nest Result List**, the distance between the part and the existing part.
6. Click **Confirm** and use instant preprocess function.

#### 4.2.7 Quick Edit

In the **2D Edit** page, the **Quick Edit** function button gathers common functions. The function entries are as follows:

**Quick Edit** refers to the collection of common editing functions for the convenience of users. It provides the following functions:

- [Tube Intersection](#)
- [Tube Cutting](#)
- [Tube Partition](#): The function entry is in the **2D Edit** page.
- [Tube Cutting Setting](#)
- [Part Mark](#): The function entry is in the **2D Edit** page.

The function entries are as follows:


- At the entrance of **Software Main Interface**

In the common toolbar of **Software Main Interface**, click  **Tube Intersection** /  **Tube Cutting** /  **Tube Cutting Setting**.



- At the entrance of the **2D Edit** page

In the menu bar of the **2D Edit** page, click **Common** →  **Quick edit** → **Tube Intersection** / **Tube Cutting** / **Tube Partition** / **Tube Cutting Setting** / **Part Mark**.






#### 4.2.7.1 Tube Intersection

Generate intersecting hole tool path on tube, including circular hole and rectangular hole. This section takes the intersection of circular tube as an example.

#### Operation Steps:

1. Select any of the following methods to open the **Tube Intersection** dialog box:

- In the common toolbar of **Software Main Interface**, click  **Tube Intersection**.
- In the menu bar of the **2D Edit** page, click **Common** →  → **Tube Intersection**.



2. Select hole type and set hole param:

Parameter	Description
Circular	Type of cut hole.
Rect	Type of cut hole.

Parameter	Description
Primary dia	The diameter of the main tube, that is, the diameter of the tube to be cut. <ul style="list-style-type: none"> <li>When the cutting type is selected as <b>Single</b> or <b>Pair</b>, it cannot be set. The fixed value is the tube diameter.</li> <li>It can be set when the cutting type is selected as <b>Auxiliary</b>.</li> </ul>
Auxiliary dia	The diameter of the branch tube, that is, the diameter of the tube that needs to run through the main tube. The setting shall meet the following requirements: branch tube diameter ≤ main tube diameter. <ul style="list-style-type: none"> <li>It can be set when the cutting type is <b>Single</b> or <b>Pair</b>.</li> <li>When the cutting type is selected as <b>Auxiliary</b>, it cannot be set. The fixed value is the tube diameter.</li> </ul>
Eccentricity	The distance between the main tube centerline and the branch tube centerline. The maximum value should be $\pm (\text{Main Tube Diameter} - \text{Branch Tube Diameter})/2$ .
Angle	The inclination angle when the main tube intersects the branch tube. Setting range: 5 °~175 °.


3. In the **Primary or Auxiliary** area, set the following parameters:

Parameter	Description
Hole type	You can select to generate <b>Single</b> , <b>Pair</b> or <b>Auxiliary</b> circular holes.
Rotary	The rotation angle of the cutting graphic relative to the workpiece origin.
Feeding axis	The feed axis distance of the cutting graphic relative to the workpiece origin.

4. Click **Confirm**.

Effect picture:


- Single



- Pair



- Auxiliary






### 4.2.7.2 Tube Cutting

Generate a cutoff path on the tube.

This section takes rectangular tube cutting as an example.

#### Operation Steps:

1. Select any of the following methods to open the **Rectangular-cutting** dialog box:
  - In the common toolbar of **Software Main Interface**, click  **Tube Cutting**.
  - In the menu bar of the **2D Edit** page, click **Common** →  → **Tube Cutting**.



2. Set parameters for angle and feeding axis:


Parameter	Description
Angle	The angle between the cutting surface and the tube centerline. Setting range: 5 °~175 °.
Feeding	Feed axis coordinates of the cutting position on the tube.


3. Click **Confirm**.

### 4.2.7.3 Tube Partition

Generate intersecting and cutting array tool paths on tubes.

#### Operation Steps:

1. In the menu bar of the **2D Edit** page, click **Common** →  → **Tube Partition** to open the **Tube Partition** dialog box:



2. In the **Tube Basic Param** area, set the following parameters:

Parameter	Description
Tube length	Set the length of the tube.
Part num	The number of parts set on the tube.
Hole num	Number of holes per part.
Part margin	The distance reserved between parts.

**Note:** Clear range: After setting the **Tube Partiton** parameter, you need to ensure that the clear range is less than 0.

3. In the **Intersection Param** area, set the following parameters:

Parameter	Description
Hole type	Select <b>Circle</b> or <b>Rect</b> .
Auxiliary dia	<b>Circle</b> parameter, the diameter of the branch tube, that is, the diameter of the tube that needs to run through the tube.
Length	<b>Rect</b> parameter, the length of the rectangular hole.
Width	<b>Rect</b> parameter, the width of the rectangular hole.
Distance	The distance between the tube centerline and the branch centerline.
Type	Optional when the cutting type is <b>Circle</b> . You can select to generate <b>Single</b> or <b>Pair</b> circular holes.
Angle	The inclination angle when the tube intersects the branch tube.

Parameter	Description
Rev axis	The rotation angle of the cutting graphic relative to the workpiece origin.



- Check the following options in the **Truncation Setting** area as required:
  - Lowest truncation line
  - Highest truncation line
- Check **Delete All Objects Firstly** as required.
- Click **Confirm**.


#### 4.2.7.4 Tube Cutting Setting

Set the type and size of the machining tube in the software according to the actual situation.

This section takes rectangular tubes as an example.

#### Operation Steps:

- Select any of the following methods to open the **Tube Cutting Setting** dialog box:
  - In the common toolbar of **Software Main Interface**, click  **Tube Cutting Setting**.
  - In the menu bar of the **2D Edit** page, click **Common** →  → **Tube Cutting Setting**.






- Modify the tube length.
- Click **Confirm**.


#### 4.2.7.5 Part Mark

Modify the part name.

#### Operation Steps:

- In the menu bar of the **2D Edit** page, click **Common** →  to check **Show Part Mark**.
- Click  → **Part Mark** to open the **Part Mark** dialog box:



3. Set the part name.
4. Click **Confirm**, and the mouse becomes to .
5. Click the line marked with the part to change the corresponding part name.
6. Click the right mouse button to exit the function.

## 4.3 Machining Technic

### 4.3.1 Overview

The machining technic can be set on the **Software Main Interface** and **2D Edit** pages. This chapter will introduce all the machining technic functions. If the function entries supported by the two pages are the same, it will not be emphasized in which page to set.


### 4.3.2 Lead Line


It is used to avoid machining errors or damage to the workpiece caused by laser staying above the start position for a long time, so as to improve machining accuracy.

The types of lead line are divided into:


- **Lead-in**: consisting of line lead line, arc lead line and hook lead line.
- **Lead-out**: consisting of line lead line and arc lead line.

#### Operation Steps:

1. Select one or more graphics.
2. Select any of the following methods to open the **Lead Line** dialog box:
  - In the **Tech** area of the **Common** menu bar, click  → **Set**.
  - Right click, and click **Lead Line** → **Set** in the shortcut menu.





3. In the **Lead-in** and **Lead-out** areas, set the lead-in and lead out types and related parameters. The parameters are described as follows:
  - **Angle:** For a line-type lead line, it refers to the angle between the lead line and the tangent line of the intersection; for an arc-type lead line, it refers to the central angle.
  - **Length:** For a line-type/arc-type lead line, it refers to the length of the line/arc; for a hook-type lead line, it refers to the sum of the radius of the arc and the length of the line.
  - **Radius:** For a hook-type lead line, it refers to the radius of the arc.
  - **Add Tiny Circle in Start Point:** Add a tiny circle at the start point of the lead-in line, so as to solve the problem that the accumulation of slag influences cutting effect during piercing a thick tube.
  - **Circle Radius:** The radius of the hole at the start point of the lead line.
4. **(Optional: )** If the target object is a closed object, in **Seal** area, select one of the following.
  - **Gap:** The lead line is unclosed and the cutting head will not cut through at the sealing position.
  - **Over:** The lead line is closed and the cutting head will cut at the sealing position.


In the menu bar, click  → **Seal** → **Notch / Overcut** to edit or delete gaps and overcut separately.

5. Set the position of the lead line:
  - If you check **Auto Set Position**, do one of the following:
    - **Corner First:** Add lead line at the corner first.



- **Edge First:** Add lead line at the longest edge first.
  - If **Set by Total Length (0 ~100)** is selected, set the percentage of the position from the start point of machining to the lead line in the total side length of the graphic.  
Available only for closed graphics.
  - If you click **By Mouse**, the cursor will become to . Click the graphic edge to manually specify the position of the lead line. After setting, right click or press **Esc** to exit the tool.
6. In the **Advanced Area**, select as needed: **Retain Leads Type, Change Position / Retain Position, Change Leads Type**.
  7. **(Optional: )** To manually modify the lead line position, perform the following steps:
    - a. Select the following methods to use the manual set start point function.
      - In the menu bar, click  → **Set Start Point**.
      - Right click and click **Lead Line** → **Start Point**.
    - b. Click the left mouse button on the graphic edge to modify the position of the lead line without modifying the angle and length.
    - c. Right click or press **ESC** to exit the start point function.


Effect picture:



Beeline lead line  
Angle: 60deg  
Length: 30mm

Arc lead line  
Angle: 60deg  
Length: 30mm

Hook lead line  
Angle: 60deg  
Length: 30mm



Beeline lead line  
Angle: 60deg  
Length: 30mm  
Circle radius: 5mm

Arc lead line  
Angle: 60deg  
Length: 30mm  
Circle radius: 5mm

Hook lead line  
Angle: 60deg  
Length: 30mm  
Circle radius: 5mm

### 4.3.3 Kerf Compensation

Laser cutting has kerf (the part of loss during cutting), which makes the size of the part actually cut deviate from the theoretical size of the part. This operation can compensate the geometric dimension of the deviation.

The type of kerf compensation includes the following:


- **All Shrink:** Shrink the cutting area for all selected parts.
- **All Expand:** Expand the cutting area for all selected parts.
- **Unfill: Shrink, Fill: Expand:** Shrink the cutting area for parts with unfill attribute, and expand the cutting area for parts with fill attribute.


**Prerequisite:**

Before compensating the kerf, ensure the following:

- The text has been turned into polylines.
- It is not dot, auxiliary line, over tangent, over arris, scan, self intersection and co-edge graphic.


**Operation Steps:**

1. Select one or more graphics.
2. In the **Tech** area of the **Common** menu bar, click  **Kerf Compensation** to open the **Kerf Compensation** dialog box:



3. Click the **Type** drop-down box to select a compensation type.
4. Set the inner width and outer width.
5. **(Optional: )** To save the commonly used inner width and outer width for later use, do the following:

- a. In the drop-down box of **Configuration**, select **Add**. **Configuration** dialog box pops up:




- b. Click **Add**, set a name in **Description** column, set the inner width in **Inner Width** column, and set outer width in **Outer Width** column.
- c. For later use, in the drop-down box of **Configuration**, select the name set in the **Description** column. The system automatically fills in the inner width and outer width.

Effect picture:

Original machining trace

Actual machining trace after compensating



Shrink

Expand

#### 4.3.4 Corner Chop



It is mainly used for graphics spanning 2~3 faces. In actual cutting, this kind of tool path is difficult to fall off after cutting, and it is automatically marked before cutting to facilitate the waste falling off.


#### Prerequisite:

Before corner chop an object, ensure the object meets the following requires:

- Unfill.
- Non text.
- Over aris closed graphic spanning 2~3 sides.
- Micro joint and chop are not added.
- No other graphics are included.

#### Operation Steps:


1. Select one or more graphics.
2. The path to open the **Corner Chop** dialog box varies according to the interface:
  - In the **Software Main Interface**, in the **Tech** area of the **Common** menu bar, click  → **Corner Chop**.
  - In the **2D Edit** page, in the **Tech** area of the **Common** menu bar, click .



3. Set parameters. The parameters are described as follows:
  - **Chop Line Offset:** The distance between the start point of the chopping line and the hole.
  - **Chop Line Distance:** The distance between the chopping line and the arris.
  - **Chop Line Number:** Select 1 or 2.

4. Click **Confirm**.

Effect picture:



#### 4.3.5 Grid Chop

Divide the selected graphic into multiple blocks, that is, chop the machining waste to facilitate the waste falling off.



#### Prerequisite:


Before chop an object, ensure the object meets the following requires:

- Non text.
- Non over arris graphic.
- Unfill.
- Close graphic.
- Large graphics, and the minimum distance between the chop line and the entity frame is 0.3mm, and the minimum length of the chop line is 1mm.

- No micro joint was added.
- No other graphics are included.


### Operation Steps:

1. Select one or more drawings.
2. The path to open the **Chop** dialog box varies according to the interface:
  - In the **Software Main Interface**, in the **Tech** area of the **Common** menu bar, click  → **Grid Chop**.
  - In the **2D Edit** page, in the **Tech** area of the **Common** menu bar, click .



3. Set the chop space.

Effect picture:



### 4.3.6 Micro Joint


Micro joints can be used to connect parts with surrounding materials, so that materials do not fall and sorting is not required. At present, the section steel does not support micro joint of the cutoff line.


The following two micro joint settings are supported:

- Set automatic micro joint: The system automatically adds micro joint to the selected objects according to the set values.
- Set manual micro joint: Select the micro joint position by yourself.

#### 4.3.6.1 Automatic Joint

### Operation Steps:


1. Select the object.
2. In the **Tech** area of the **Common** menu bar, click  to open the **Micro Joint** dialog box:



3. In the **Auto** area, select by counts or space to micro joint.  
The system automatically executes micro joints on the selected objects according to the set values.
4. **(Optional: )** Check **Skip Tiny Objects** and set the perimeter.  
Small graphics within the perimeter will not be micro joints.
5. Check **Corner Evading** and set the following parameters:
  - **Length:** In the range of evade length, the corner cannot be added micro joint.  
Range: 0.001 mm ~10 mm.
  - **Angle:** Range: 90 ° ~180 °.

If **Corner Evading** is not checked, all points support micro joint.


When **By Counts** micro joint is selected and the set quantity is **5**, the effect before and after the automatic micro joint is as follows:




#### 4.3.6.2 Manual Joint


##### Operation Steps:

1. You do not need to select an object. In the **Tech** area of the **Common** menu bar, click **Micro Joint** to open the **Micro Joint** dialog box:



2. In **Manual Operating** area, select **Manual Joint**, and set parameter **Length**.
3. Check **Corner Evading** and set the following parameters:
  - **Length**: In the range of evade length, the corner cannot be added micro joint. Range: 0.001 mm ~10 mm.
  - **Angle**: Range: 90 ° ~180 °.
 If **Corner Evading** is not checked, all points support micro joint.
4. Click **Confirm**, and the cursor becomes to .
5. Move the mouse to select the micro joint position, and click the left mouse button to add micro joint.
6. Right click or press **Esc** to exit the manual micro joint function.

Effect picture:



#### 4.3.7 Chamfer

Perform arc chamfer on all corners within the set angle range in the graphic to improve the cutting effect of inflection points when cutting thick materials.


Select the following methods to add chamfers:


- Automatically add chamfer: Automatically chamfer the selected and qualified objects according to the set value.

- Manually add chamfer: Manually select chamfer position based on your need. Angle range: (0, 180) °.

### 4.3.7.1 Automatic Chamfer


#### Operation Steps:

- Select the object.
- In the **Tech** area of the **Common** menu bar, click  to open the **Chamfer** dialog box:




- Set parameter angle and radius.
- (Optional: )** To automatically add chamfer for closed objects according to the attribute of fill/unfill, check **Create Chamfer by Fill or Unfill**.
- Click **Confirm**. After setting, the system will automatically add chamfers to the qualified corners.


Taking the following as an example, set parameter **Angle** between 45° and 90° and check **Create Chamfer by Fill or Unfill**. The effect picture is as follows:




### 4.3.7.2 Manual Chamfer

#### Operation Steps:


- You do not need to select an object. In the **Tech** area of the **Common** menu bar, click  to open the **Chamfer** dialog box:



- Set the radius of the chamfer.
- (Optional: )** Check **Create Chamfer by Fill or Unfill**.
- Click **By Mouse**, and the cursor becomes to .
- Move the mouse to the target position and left click to select an adding position.
- Right click to exit manually add chamfer function.



When **Create Chamfer by Fill or Unfill** is not checked, effect picture:




#### 4.3.8 Bridge


When a part is composed of multiple parts, use this function to connect these parts, so that they will not fall off after cutting, and reduce the number of pierces. Using the **Bridge** function for many times can achieve the effect of completing all graphics at one time. It is mostly used to connect text strokes.

#### Operation Steps:

1. In the **Software Main Interface**, select the graphic.


**Note:** If the bridged object is text, make sure that the text has been converted to graphics.

2. In the **Tech** area of the **Common** menu bar, click  **Bridge** to open the **Bridge** dialog box:



3. Set parameter **Max Space** and **Width**.
4. Click **Confirm**.
5. Click the left mouse button to select the two ends of the bridge.
6. Right click or press **Esc** to exit bridge function.

Effect picture:



### 4.3.9 Cooling Point

Add a cooling point at the inflection point of the graphic, and only blow air without turn on the laser. Avoid slowing down at the corners of the graphic during machining, resulting in excessive local laser energy. If continuous machining occurs, such phenomena as corner burning and excessive slag will occur.

The following two methods to add cooling points are supported:


- Automatically add cooling point: Automatically add cooling points to selected and qualified objects according to the set value.
- Manually add cooling point: The position of inflection point shall be selected by yourself. Angle range: 0 °~180 °.

**Note:** Cooling point cannot be added at the start point of machining.

#### 4.3.9.1 Automatic Cooling Point

##### Operation Steps:


1. Select the object.
2. In the **Tech** area of the **Common** menu bar, click  **Cooling Point** to open the **Cooling Point** dialog box:



3. Check **Sharp Corner** and set the angle range for sharp corner.
4. **(Optional: )** To add a cooling point at the position of lead-in line without being limited by the range of the angle of sharp corner, check **Lead Point**.


After setting, the system will automatic add cooling points at the inflection points that meet the conditions.


When **Sharp Corner** is set to 15 ° ~90 °, effect picture:




#### 4.3.9.2 Manual Cooling Point


To manually add cooling points without selecting objects, follow the steps:

1. In the **Tech** area of the **Common** menu bar, click  **Cooling Point** to open the **Cooling Point** dialog box:



2. Click **By Mouse**. The cursor becomes .
3. Move the mouse to select a cooling position, and click the left mouse button to add a cooling point.
4. Right click or press **Esc** to exit manually add cooling point function.


Effect picture:



#### 4.3.10 Unfill/Fill

**Unfill** is used to keep the outside of the closed graphic during machining. **Fill** is used to keep the inside of the closed graphic during machining.

##### Operation Steps:


1. Select the closed graphic.
2. Select one of the following methods to set the unfill and fill cutting:
  - In the **Tech** area of the **Common** menu bar, click  → **Unfill / Fill**.
  - Right click and click **Unfill/Fill** → **Unfill / Fill / Auto Setting**.


**Note:** Automatic setting refers to the setting of unfill or fill according to the nesting relationship of the selected graphic.


#### 4.3.11 Direction

Used to change the original machining path direction in the tool path.

##### Operation Steps:

1. Select the object.
2. Select the following method to open the **Machining Direction** dialog box:
  - In the **Tech** area of the **Common** menu bar, click  → **Auto Setting**.
  - Right click and click **Machining Direction** → **Set**.




3. In the **Machining Direction** area, select the machining direction.  
If you only need to reverse the machining direction, select the following method:
  - In the **Tech** area of the **Common** menu bar, click  **Direction** → **Reverse**.
  - Right click and click **Machining Direction** → **Reverse**.
  - In the **Machining Direction** dialog box, click **Reverse**.
4. **(Optional: )** If need is setting the machining direction, the primitive machining direction in the group remains unchanged. Check **Skip Groups**.

After setting, the machining direction is automatically generated.


#### 4.3.12 Centering Mark

When the tube is long, there will be some bending deformation in the middle of the front and rear chucks, resulting in that after cutting a section of length, the centering data executed before machining cannot continue to apply. This operation can eliminate this error. After cutting a certain length, the tube will be automatically leveled and divided, and then the breakpoint resume will be automatically performed.

#### Operation Steps:

1. In the **Tech** area of the **Common** menu bar, click  **Centering Mark** → **Manually** / **Manually (Single Face)** / **Automatically**:
  - Manually: Specify the centering position of the tube section at this position.
  - Manually (single face): Specifies the centering position of the pipe single face.
  - Automatically: After setting the centering mark interval, the system automatically adds the leveling center mark according to the set interval.

After selecting the marking method, the system automatically adds the centering mark and centering at the specified place. Effect picture:





### 4.3.13 Inner Compensation

When performing the intersection with a certain angle of inclination, it is impossible to ensure the insertion of the inner diameter of the main tube because the laser head is cut vertically. The **Inner Compensation** function ensures that the inner diameter of the inserted main tube and the weld are as small as possible.

Note that 2D editing and drawing graphics cannot add inner compensation.

#### Operation Steps:

1. Select the object.
2. Select any of the following methods to open the **Inner Compensation** dialog box:
  - In the **Tech** area of the **Common** menu bar, click  **Inner Compensation**.
  - Right click and click **Inner Compensation**.



3. Click the **Compensation Type** drop-down box to select a compensation type. According to the compensation method, the effect diagram of setting inner diameter compensation is as follows. The red line is the cutting path:

- **Max Clip:**



- **Inner Clip:**




- **Min Clip:**




#### 4.3.14 Weld Compensation

Used to compensate for weld shrinkage caused by welding.

##### Operation Steps:

1. Select any of the following methods and use the **Weld Compensation** function:
  - In the **Tech** area of the **Common** menu bar, click  drop down box.
  - Right click and click **Weld Compensation**.
2. Select the setting method in the submenu:
  - To set the selected break line, click **Compensation Select**.
  - To set all break lines, click **Compensation All**.

Effect picture:



#### 4.3.15 Vertical Intersection

During cutting, the general intersecting cutting may cause the outside of the cutting hole to be large and the inside to be small, and it is impossible to insert the tube that conforms to the outside frame of the hole. The function of **Vertical Intersection** can ensure the consistency of the size of internal and external cutting holes.

The following methods are supported:


- Vertical angle intersection: According to the normal cut of the vertical intersection of the respective primitives, set the intersection angle by custom.
- Set angle intersection: Primitive is cut by normal intersection at the same angle, and the following settings can be selected:
  - Vertical intersection: Automatic setting of intersection angle, 0 ° or 180 ° intersection.
  - Horizontal intersection: Automatic setting of intersection angle, 90 ° or 270 °.
  - Custom intersection: Custom angle, parameter range: 0°-360°.


##### Prerequisite:

Mark sure:

- The current cutting tube is rectangular tube, circular tube, elliptical tube or waist tube.
- The target object is non dot, text, scan group, and primitive that bypasses the entire tube by 180 °.

### Operation Steps:

1. Select the object.
2. Select one of the following methods to set the vertical intersection.
  - a. In the **Tech** area of the **Common** menu bar, click  → select the intersection method.
  - b. Right click and click **Vertical Intersection** → select the intersection method.
3. Perform different operations according to different intersection methods.
  - If you select **Set Vertical Angle Insert**, the selected graphics will become white.
  - If you select **Set Regular Angle Insert**, then in the pop-up dialog box, check the strategy as required:




If **Show Normal** is not checked in the view page, a prompt will pop up indicating whether to show the normal.


### 4.3.16 Over Arris Jiggle

By adjusting the over arris start stop position. To solve the problem that the actual thickness of the over arris area needs to be cut becomes larger and cannot be completely cut to the deviation between the tube drawing and the actual size of the tube or the deformation of the actual tube during machining.

Before setting over arris jiggle, you can click **View** → **Show Normal** in the **View** area of the menu bar.

### Operation Steps:

1. In the **Tech** area of the **Common** menu bar, click  to open the **Over Arris Jiggle** dialog box:




2. Set parameters **Over Arris Jiggle** and **Jiggle Ratio**.

#### 4.3.17 Truncation Line Setting

Set the selected truncation line, where the upper truncation line represents the part, and the lower truncation line represents the scrap.

#### Operation Steps:

1. In the **2D Edit** interface, select one or more truncation lines.
2. In the **Tech** area of the **Common** menu bar, click **Set Truncation** → select function.



#### 4.3.18 Instant Setting

It is used to set unfill/fill, lead line, machining direction, machining order and kerf compensation with one click, so as to improve machining efficiency.

#### Operation Steps:

1. Select one or more objects.
2. Select any of the following methods to open the **Instant Setting** dialog box:
  - In the **Tech** area of the **Common** menu bar, click **Instant Setting**.
  - Right click and click **Instant Setting**.



Instant Setting
✕

**Fill/Unfill**

Fixed   
  Fill   
  Unfill   
  Auto Setting

**Machining Direction**

CW   
  CCW for Fill while CW for Unfill  
 CCW   
  CW for Fill while CCW for Unfill

**Lead line**

**Lead-in line:**

Type:  ▼

Angle:  deg

Length:

Radius:

Add Tiny Circle in Start Point

Radius:

Seal:

Gap:

Over:

**Lead-out line:**

Type:  ▼

Angle:  deg

Length:

Set by positin of Y offset

Near     Far

Set by corner or side

Corner first     Midpoint of long side

Set by Total Length(0~100)

%

**Sort Strategy:**

Bottom-Top Based on Feeding Axis  
 Top-Bottom Based on Feeding Axis  
 Based on Surface     步长内最后截断    Step:   
 Cut shapes within the cutoff line region    Safe area(S):

**Kerf Compensation**

Type:  ▼    Shrinked Width:

Configuration:  ▼    Expanded Width:

3. Set as required.

#### 4.3.19 Clear


It is used to clear some set technics.

The clearing items include the following:

- Micro joint
- Chop
- Lead line
- Cooling point
- Kerf compensation
- Inner compensation
- Weld compensation
- Vertical intersection
- Corner chop
- Centering mark

#### Operation Steps:

1. Select one or more objects.
2. Select the following methods to clear the technic:

- In the **Tech** area of the **Common** menu bar, click  **Clear** to select the items to be cleared.
- Right click and click **Clear** to select the items to be cleared.

## 4.4 Layer Technic

### 4.4.1 Overview

The layer function is mainly used to set the layer process. That is, parameters such as cutting and piercing, so as to ensure the cutting effect.

The system provides seven color layers. Each layer can be set with different layer technics. By default, the layer technics of the same color object are the same.


The system provides the management function of layer technic library, which can create new layer technics, modify, backup, restore and delete existing layer technics, and add and delete material types.

### 4.4.2 Set Layer Technic

#### 4.4.2.1 Layer Parameter



In the layer bar of the **Software Main Interface** or **2D Edit** page, click  to open the **Layer Setting** dialog box:



The screenshot shows the 'Layer Setting' dialog box with the following components:

- 1**: Layer selection box (left sidebar) showing 'Large' selected.
- 2**: Parameter setting page (main area) with tabs for 'Film Cutting Param', 'Technic Parameter', 'Over-arris Param', 'Piercing Param', and 'Accurate Machining'. The 'Technic Parameter' tab is active, showing fields for Pre laser off/on, Post laser on, Cut speed, Peak Power, Cut frequency, DutyCycles, Up height, Pre-pierce up height, Cut gas, Cut pressure, Cut Height, and Cut focus.
- 3**: Technic operation bar (bottom) with buttons for 'Save As', 'Import Technics', 'Confirm', and 'Cancel'. A 'TechnicRemark' field shows 'UnFilled'.
- 4**: Unit switch (left sidebar) with dropdowns for Speed (mm/s), Acc (mm/s^2), Time (ms), and Pressure (bar).

1. Layer selection box 2. Parameter setting page 3. Technic operation bar 4. Unit switch

- **Layer Selection Box**

The following operations can be performed in the layer selection box:

- Click the layer: Set the layer technic of the target layer.
- Click to select the target layer, select a layer in the **Copy From XX** drop-down box, copy and apply the layer parameters to the target layer.

**Note:** When this operation is performed, multiple layers must exist in the current tool path.

- Set **Show All** to **ON** status: The system display all layers; otherwise, only the layers contained in the current path file are displayed.

- **Parameter Setting Page**

Click the page switch button above to switch to the corresponding parameter setting page, including:

- **Film Cutting Param**

Page: Set the film cutting parameters of the layer (pre laser on, post laser on) and the over aris parameters (power, frequency, etc.).

For details, see [Set Film Cutting Parameter](#).

- **Technic Param**

Page: Set the technic parameters of the layer (pre laser off, up height, etc.) and special technic parameters (side blow, fixed cut, etc.).

For details, see [Set Technic Parameter](#).

- **Over-arris Param**

Page: Set the over-arris parameters of the layer (peak power, pressure, etc.).

For details, see [Set Over-arris Parameter](#).

- **Piercing Param**

Page: Set piercing parameters (increment speed, peak power, etc.).

For details, see [Set Piercing Parameter](#).

- **Accurate Machining**

Page: Set accurate machining parameters (slowly start and slowly stop).

For details, see [Set Accurate Machining](#).

- **Technic Operation Bar**

Operation: Save as technic, import technic, save or cancel modification of current layer parameters.

- **Unit Switch**


Switch the unit of the parameter here as needed.

#### 4.4.2.2 Set Operation

This includes the operations of assigning and setting layers and setting layer technics.

#### Operation Steps:

1. In the layer bar of the **Software Main Interface** or **2D Edit** page, click  to open the **Layer Setting** dialog box:



2. **(Optional: )** If the target technic file needs to be imported from the technic library, execute the import technic operation. For details, see [Import Technic](#).
3. Click the layer to be set in the **Layer Selection Box**.
4. **(Optional: )** If the layer parameters currently set are similar to other layers, select a layer in the **Copy From XX** drop-down box, copy and apply the layer parameters to the target layer.
5. **(Optional: )** In the **Unit Switch** area, switch the unit of the parameter as required.
6. In the **Parameter Setting Page** area, set the technic parameters. For details, see the following:
  - [Set Film Cutting Parameter](#).
  - [Set Technic Parameter](#), it includes setting technic parameters and editing power curve.
  - [Set Over-arris Parameter](#).
  - [Set Piercing Parameter](#).
  - [Set Accurate Machining](#).
7. After setting the parameters, repeat steps 3 to 6 as needed to set the parameters of the next layer.
8. Click **Confirm** to close the **Layer Setting** dialog box and complete the layer technic setting.

#### Related Tasks:


- Save as technic: Save the current technic to the technic library. For details, see [Save As](#).
- Apply layer technic: For details, see [Apply Layer Technic](#).
- Technic library management: For details, see [Manage Technic Library](#).

#### 4.4.2.2.1 Set Film Cutting Parameter

It is used to select the film cutting type and cut the protective film on the tube surface.

## Operation Steps:

1. In the **Layer Setting** dialog box, click **Film Cutting Param** to switch to the **Film Cutting Param** page:



2. Set parameters. The parameters are described as follows:  
Parameter description of film cutting parameter area:

Parameter	Description
Film cutting type (single cut)	A single graphic is cutting first, and then the graphic is machined.
Pre laser on	Turn on the laser before delay. It can be set to a negative number to turn off the laser in advance to solve the problem of over burning at the end of the thin tube.
Post laser on	After turned on the laser, continue to set the time before performing the next step.
Pre laser off	Turn off the laser before delay.
Speed	The actual speed of film cutting.
Gas type	The type of gas used of film cutting.
Pressure	When cutting the film, the gas pressure should be used with the proportional valve.
Power	Peak power when cutting film.
Frequency	When cutting the film, the carrier frequency of the PWM modulation signal is also the number of light output in one second.
Duty ratio	The duty ratio of cutting film is setting by adjusting the laser with PWM.
Height	The height of the nozzle from the tube when cutting film.

Parameter	Description
Focus	This takes effect after focus control is enabled. Position of focal point when cutting film.
Up height	The height of the laser head when switch cutting film.

Parameter description of over-arris parameter area:

Parameter	Description
Power	Peak power when over-arris cutting.
Frequency	When over-arris cutting, the carrier frequency of the PWM modulation signal is also the number of light output in one second.
Duty ratio	The duty ratio of over-arris cutting.
Across-edge height	The height of the nozzle from the tube when over-arris cutting.
Sensitivity	Follow the torch lifter dynamic sensitivity when over-arris cutting.
Speed	The speed of the axis of rotation used when over-arris cutting. (In case of over arris, the rotation axis speed is controlled separately. In other cases, the rotation axis speed is planned together with other axes according to the cutting speed).
Pressure	The gas pressure of over-rris cutting should be used with proportional valve or multi-valve.

Parameter description of advanced area:

Parameter	Description
Gas on after film cutting	The gas output port is always open during the film cutting process and the film cutting to cutting process.
Fixed film cutting	The film will be cut at the <b>Fixed Height Position</b> in the common parameters.

3. **(Optional: )** If the film needs to be cut at a fixed Z-axis coordinate at all times, select the **Fixed Film Cutting**.
4. **(Optional: )** If the gas output port should always be open during the film cutting process and the film cutting to cutting process, select the **Gas On after Film Cutting**.


#### 4.4.2.2.2 Set Technic Parameter

Used to set technic parameters, special technic parameters and edit power curve.

By editing the power curve, the problems such as over-burning of sharp corners and inconsistency of cutting effect with different thickness in laser cutting can be solved. The cutting power can be adjusted to change with the cutting speed, so as to ensure that the heat power absorbed per unit area is the same and the ideal cutting effect can be achieved.

#### Operation Steps:

1. In the **Layer Setting** dialog box, click **Technic Param** to switch to the **Technic Param** page:



2. Set parameters. The parameters are described as follows:  
Parameter description of technic parameter area:

Parameter	Description
Pre laser off	Turn off the laser before delay.
Pre laser on	Turn on the laser before delay.
Post laser on	After turned on the laser, continue to set the time before performing the next step.
Cut speed	The actual cutting speed.
Peak power	Adjust the laser by analog quantity, set the laser intensity when cutting.
Cut frequency	The carrier frequency of PWM modulation signal is also the number of light output in one second when cutting.
Duty cycles	The duty ratio of cutting is setting by adjusting the laser with PWM.
Up height	The height of the laser head when switch cut graphics.
Pre-pierce up height	In pre-pierce, the height of the cut head is raised after each hole is pierced. If the total number of tool path pierce is 1, this parameter does not take effect.
Cut gas	The type of gas used to cut.
Cut pressure	The gas pressure of cutting should be used with proportional valve.

Parameter	Description
Cut height	The height of the nozzle from the tube when cutting.
Cut focus	This takes effect after focus control is enabled. Position of focus point when cutting.

Parameter description of special technic parameter area:


Parameter	Description
Ignore this layer	Do not machining all graphics in the current layer.
Gas keeps on for this layer	Do not close the blowing port during the machining of the graphics in this layer.
Side blow at pierce	When piercing, open the side blowing port.
Side blow at cut	When cutting, open the side blowing port.
Fixed cut	Whether the cutting has been kept in the fixed Z axis coordinates for cutting.
Pre-piercing	All machined objects in the current layer are enabled pre-piercing so that all tool paths are perforated before the actual machined objects.
Micro joint at high speed	The laser is not opened at the micro connection, and the cutting head continues to move without slowing down.
Cut film	Enabled when cutting the metallic material of the top film.
Coolant	Gas used for cooling.
Cool delay	When the machining to the cooling point is blowing cooling time.

3. In the power curve area, select **Enable Speed Power Adjustment** and **Enable Speed Frequency Adjustment** as required. The following table describes the parameters:

Parameter	Description
Enable speed power adjustment	When cutting, the cutting power will change with the cutting speed, and the specific value is determined by the speed power curve.
Enable speed frequency adjustment	When cutting, the cutting power will change with the cutting speed, and the specific value is determined by the speed frequency curve.

4. Using **Enable Speed Power Adjustment** as an example, click **Edit** to open the **Speed-power Curve** dialog box:





5. Select the following methods to edit the power curve:

- Edit in curve box:
  - Double-click the target position to add a curve node.  
The more nodes you add, the more accurate the curve will be.
  - Double-click the location of the added node to delete it.  
As nodes are added or deleted, the corresponding speed and power values will added or deleted in the list on the right.
- Edit in the list on the right:
  - Click **Add** and the list will automatically add a set of speed power values. Then double-click to change the value and click on the blank area.

**Note:** The speed power curve is in increasing mode. The values added must increase in ascending order, and **0** and **100** cannot be modified.

- Select a set of speed power values and click **Delete** to delete the set of values.  
The left curve box adds or deletes the corresponding nodes synchronously.  
To restore the curve to the default curve, click **Clear**.

During machining, the system will automatically adjust the speed and power/frequency matching relationship according to this curve, without other manual operation.

#### 4.4.2.2.3 Set Over-arris Parameter

Used to set the **Peak Power**, **Pressure** and other over-arris parameters.

#### Operation Steps:

1. In the **Layer Setting** dialog box, click **Over-arris Param** to switch to the **Over-arris Param** page:



2. The parameters are described as follows:

Parameter	Description
Peak power	By adjusting the setting of the laser with the analog quantity, the peak current and peak power during over-arris cutting can be corresponding.
Pressure	When over-arris cutting the film. The gas pressure of cutting should be used with proportional valve or multi-valve.
Frequency	When over-arris cutting the film, the carrier frequency of the PWM modulation signal is also the number of light output in one second.
Follow height	The height of the nozzle from the tube when over-arris cutting.
Duty cycles	The duty ratio of over-assis cutting.
Sensitivity	Follow the torch lifter dynamic sensitivity when over-arris cutting.
Speed	The speed of the axis of rotation used when over-arris cutting (In case of over arris, the rotation axis speed is controlled separately. In other cases, the rotation axis speed is planned together with other axes according to the cutting speed).

3. Select **Enable Speed Power Adjustment** and **Enable Speed Frequency Adjustment** as required. The following table describes the parameters:

Parameter	Description
Enable speed power adjustment	When cutting, the cutting power will change with the cutting speed, and the specific value is determined by the speed power curve.
Enable speed frequency adjustment	When cutting, the cutting power will change with the cutting speed, and the specific value is determined by the speed frequency curve.

#### 4.4.2.2.4 Set Piercing Parameter

Used to select the piercing mode and set the piercing parameters.

#### Operation Steps:

1. In the **Layer Setting** dialog box, click **Piercing Param** to switch to the **Piercing Param** page:

Film Cutting Param	Technic Parameter	Over-arris Param	Piercing Param	Accurate Machining
<b>Piercing Param</b>				
<input checked="" type="radio"/> None <input type="radio"/> 1th Seg. <input type="radio"/> 2th Seg. <input type="radio"/> 3th Seg.				
Increment speed:	<input type="checkbox"/> 16.667	<input type="checkbox"/> 16.667	<input type="checkbox"/> 16.667	mm/s
Peak Power:	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	%
Frequency:	<input type="text" value="5000"/>	<input type="text" value="5000"/>	<input type="text" value="5000"/>	Hz
DutyCycles:	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	%
Gas:	<input type="text" value="Air"/>	<input type="text" value="Air"/>	<input type="text" value="Air"/>	
Pressure:	<input type="text" value="10"/>	<input type="text" value="10"/>	<input type="text" value="10"/>	bar
Height:	<input type="text" value="3"/>	<input type="text" value="5"/>	<input type="text" value="10"/>	mm
Focus:	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	mm
Delay:	<input type="text" value="200"/>	<input type="text" value="200"/>	<input type="text" value="200"/>	ms
OFF Delay:	<input type="checkbox"/> <input type="text" value="200"/>	<input type="checkbox"/> <input type="text" value="200"/>	<input type="checkbox"/> <input type="text" value="200"/>	ms
OFF Gas:	<input type="text" value="Air"/>	<input type="text" value="Air"/>	<input type="text" value="Air"/>	
OFF Press.:	<input type="text" value="10"/>	<input type="text" value="10"/>	<input type="text" value="10"/>	bar

2. Select the method of piercing as follows:
  - **None**
    - The system automatically performs the following processing actions:
    - a. Open the follow-up valve and blow valve.
    - b. After the cutting head moves down to the **Cutting Height**, wait for the **Blowing Delay** time set in **Common Parameters**.
    - c. Open the laser valve and start cutting.
  - **1st Segment / 2nd Segment**
    - The system automatically performs the following processing actions:
    - a. Open the follow-up valve and blow valve.
    - b. After the cutting head moves down to the **Cutting Height**, wait for the **Blowing Delay** time.
    - c. Open the laser valve and start pierce. The duration is the **Pierce Delay** time.
    - d. Select the method of piercing as follows:
      - **Increment Pierce:** Without closing the laser valve, start the cutting process at the **Increment Speed** to the **Cutting Height**.
      - **Section Pierce:** Close the laser valve, control the cutting head to move down to the **Cutting Height**, then open the laser valve to start cutting.
  - **3rd Segment**
    - The system automatically performs the following processing actions:
    - a. Perform 3rd segment.
    - b. Perform 2nd segment.
    - c. Perform 1st segment.
3. The parameters are described as follows.

Parameter	Description
Increment speed	Sets the speed at which the piercing height descends to the cutting height when using increment pierce.
Peak power	The laser intensity during piercing is set by adjusting the laser by analog quantity.
Frequency	In piercing, generally adopts a low PWM modulation signal carrier frequency to avoid mistakes.
Duty cycles	The duty ratio of piercing.
Gas	The type of gas used to pierce.
Pressure	The gas pressure of cutting should be used with proportional valve.
Height	The height of the pierce from the tube.
Focus	This takes effect after focus control is enabled. Position of focal point when piercing.
Delay	The time that increment pierce and section pierce turn on the laser at the piercing height.
Off delay	The interval time between blowing after the laser is turned off.
Off gas	Air,nitrogen,oxygen.
Off pressure	The air pressure value when blowing.


- (Optional: )** If click the **Increment Speed**, the cutting head will move from the piercing height to the cutting height at that speed when increment piercing is used. If not selected, the cutting head follows to the **Cutting Height**.
- (Optional: )** If click the **Off Delay**, **Off Delay**, **Off Gas** and **Off Pressure** can be set. If not clicked, the corresponding pierce will not stop blowing after the end.

#### 4.4.2.2.5 Set Accurate Machining

Used to set slowly start and slowly stop, and select whether to enable slowly start and slowly stop.

#### Operation Steps:

- In the **Layer Setting** dialog box, click **Accurate Machining** to switch to the **Accurate Machining** page:



2. Check **Enable Slowly Start** and **Enable Slowly Stop** as required, and set the parameters. The parameter description follows.

Parameter	Description
Enable slowly start	The speed, frequency, duty cycle, power and pressure used when cutting a short distance from the starting point.  If you do not enable accurate adjustment, the effect is equivalent to the original slow start.
Enable slowly stop	Speed, frequency, duty cycle, power and pressure used for a short distance before the end of cutting.  If you do not enable accurate adjustment, the effect is equivalent to the original speed.

#### 4.4.3 Apply Layer Technic

When drawing parts, the default is to use the large graphics layer technique. This section describes how to apply the layer technic.

##### Operation Steps:


1. Select the graphic or part.
2. Click the layer's color in the **Layer** to set the selected object as the layer's technic.

#### 4.4.4 Import Technics

Import the target technic file from the technic library, that is, quickly apply the layer technic parameter information to the system.

##### Operation Steps:

1. In the **Layer Setting** dialog box, click **Import Technics** to open the **Import Technics** dialog box:




2. Click the technic to be imported and it becomes highlighted, click **Confirm**, and a confirmation prompt box pops up. Click **Confirm**.

#### 4.4.5 Save As

Save the current technic to the technic library.

### Operation Steps:

1. In the **Layer Setting** dialog box, click **Save As** to open the **Technics Info.** dialog box:



2. Set the technic information parameters. The parameters are described as follows:

Parameter	Description
New material	<p>New material button.</p> <ul style="list-style-type: none"> <li>▪ When the button is set to OFF, the new material function is not enabled.</li> <li>▪ When the button is set to ON, the new material function is enabled.</li> </ul>
Materials	<p>The material of the tube. Perform different operations according to the status of the new material button.</p> <ul style="list-style-type: none"> <li>▪ When the button is set to OFF, select the existing material from the <b>Materials</b> drop-down box.</li> <li>▪ When the button is set to ON, a new material needs to be created, and the parameter <b>Materials</b> becomes</li> </ul> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <span style="border: 1px solid black; padding: 2px;">Shorthand</span> <span style="border: 1px solid black; padding: 2px;">Material Name</span> </div> <p>to fill in the shorthand and material name.</p>
Material thickness	You can manually set the thickness of the tube in millimeters (mm).
Nozzle type	Select the nozzle type. If there is no suitable type, you can add it in <b>Nozzle Information Management</b> and then select it. For details, see <a href="#">Nozzle Info. Management</a> .
Laser power	The power of laser cutting can be manually set in watts (W).

Parameter	Description
Mach gas	The cutting gas air, nitrogen N <sub>2</sub> and oxygen O <sub>2</sub> can be selected.
Mach type	S, H, Q can be selected.
Customize	Additional information can be added manually.
Remark	Notes are automatically generated according to the parameters of technic information. Naming rules: Material name - material thickness - laser power - machining type - nozzle type (type+diameter) - gas type. It is named Chinese with unit.
File name	The file name is automatically generated according to the parameters of the technic information. Naming rules: Material abbreviation - material thickness - laser power - machining type - nozzle type (type+diameter) - gas type - custom. Named in English or abbreviated without units.

3. Click **Confirm** to finish saving to the technic library.

## 4.5 Arrange Path

### 4.5.1 Sort

It is used to specify the machining order of each graphic in the tool path file.

To display the original machining sequence in the tool path, click **View** → **Show Order** in the **View** area of the menu bar.

The system supports the following sorting methods:

- [Auto Sort](#)
- [Manual Sort](#)
- [Specify Sort](#)
- [Sort List](#)
- [Sort to Top/Bottom](#)
- [Mach Order](#)

**Note:** Manual sort methods, such as specify sort, sort list, sort to top/bottom, and mach order can only be edited in 2D edit mode.


#### 4.5.1.1 Auto Sort


According to the selected sorting strategy, the software automatically arranges the machining sequence.

#### Operation Steps:


1. Select multiple objects.
2. Open the **Auto Sort** dialog box by using the following methods:

○ In the menu bar of the **Software Main Interface**, click **Common** →  **Auto Sort**.

○ In the menu bar of the **2D Edit** page, click **Common** →  **Sort** → **Auto Sort**.



3. Select sorting strategy:
  - Bottom-top based on feeding axis
  - Based on surface: Currently only applicable to rectangular tube.
4. **(Optional: )** Check **Cut Shapes within the Cutoff Line** and set safe area(S).  
Effect picture:




- S: Safe area, which is the shortest distance along the tube between the chuck and laser cutting head. Shapes within the safe area can be machined normally. The recommended value is 0.
- R: Risk area. When machining graphics in this area, there is a risk that the fixture may be holding on the cutoff line. Graphics in this area need to be cut first before the cutoff line.


5. Click **Confirm**.

#### 4.5.1.2 Manual Sort


Use the mouse to specify or adjust the serial number to adjust the machining sequence of single or multiple graphics. The software will verify the parts, including the verification of the machining sequence of the part graphics, and check whether the part cutting line is in the first and last machining sequence. If it is not the first and last, it will automatically adjust to the first and last, and the rest of the part graphics will automatically adjust in turn.

#### Operation Steps:

1. In the menu bar of the **2D Edit** page, click **Common** →  → **Manual Sorting**.

The cursor becomes , which indicates the sequential number of the object to be clicked.

2. Click the left mouse button to select the target line to be set as the first.

The cursor becomes , the machining sequence on this line becomes 1. And so on.



3. To change the sequence of the last line, right-click on the area and click **Previous Order** in the context menu.
4. Right click and select **Exit** from the shortcut menu.


#### 4.5.1.2.1 Specify Sort

Manually specify the machining sequence of an object.

##### Operation Steps:

1. In **2D Edit** page, select the object.

2. In the menu bar, click **Common** →  → **Specify Sort** to open the **Specify Sort** dialog box:




3. Enter the specified sequence in the **Number** input box.  
N represents the maximum sequential number in the tool path file.


#### 4.5.1.2.2 Sort List

The system automatically numbers each object. This operation is used to manually check the object number to change the machining sequence of its corresponding object.

##### Operation Steps:

1. In **2D Edit** page, select the object.

2. In the menu bar, click **Common** →  → **Sort List** to open the **Sort List** dialog box:



3. After checking the object, select the following method to sort:
  - Click **Move Up** and **Move Down** to move the selected object.

- Double click an unselected object to place the selected object before it.  
If **Sort Behind** is checked, double click an unselected object to place the selected object behind it.

### 4.5.1.2.3 Sort to Top/Bottom

Change the machining sequence of the selected single object to the first or last.

#### Operation Steps:

1. In **2D Edit** page, select the single object.



2. In the menu bar, click **Common** → **Sort** → **Sort to Top / Sort to Bottom**.

### 4.5.1.3 Mach Order


Manually connect graphics, that is, adjust the number of the next graphic according to the number of the previous graphic.

#### Operation Steps:

1. In the drawing area, right-click and select **Mach Order**. The empty path of the part will be displayed automatically. When the mouse passes over the graphic, the outline of the graphic will be highlighted.



2. Click to select a graphic, and click to select the next graphic. At this time, the number of the selected graphic  $n$  will be changed to  $n+1$ .  
For example, change the number 9 in the following picture to 4.



3. Right click to exit the function.

### 4.5.2 Scan

The scanning functions allow the system to re-arrange the machining path for better efficiency and do not have the tool lifting and lowering steps required when switching between shapes during common laser cutting. During scanning machining, only laser ON or OFF operations will be performed.


If scanning parameters have already been set for the selected object(s), you need to [Clean Scan](#).


#### 4.5.2.1 Line Scan

Straight lines can be recognized and scanned by group.

#### Operation Steps:


1. In **2D Edit** page, select the object.

2. In the menu bar, click **Common** →  → **Line Scan** to open the **Line Scan** dialog box:




3. Select the cut start position and set the following parameters:
  - **Max Scan Space S:** If the distance between two graphics with shared edges is larger than this value, the two shapes will be scanned in two groups.
  - **Collinear Tolerance T:** If the distance between two parallel lines is smaller than this value, the two shapes are considered to have a shared edge.
4. To execute scanning by group, check **Scan After Group** and set **Length of the X axis** and **Length of the Y axis**.
  - **Group:** From the cut start position, graphics that within the **Length of the X axis** and **Length of the Y axis** will be counted as one group. The next group starts from the end of the first group.
  - **Scan:** Scan by group, that is, scan the objects in the group first, and then scan the objects in the next group.
5. **(Optional: )** To further improve machining efficiency after scanning, you can check **Sort After Scan** to re-arrange the machining path and reduce dry run distance.

Effect picture:



Ungrouped scanning



Grouped scanning

#### 4.5.2.2 Arc Scan


Arcs can be recognized and scanned by group, standard circles, and non-standard circles. Non-standard circles are commonly oval or other graphics formed by arc tube intersection.

## Operation Steps:

1. In **2D Edit** page, select the object.




2. In the menu bar, click **Common** → **Scan** → **Arc Scan** to open the **Arc Scan** dialog box:




3. To execute scanning by group, check **Scan After Group** and set **Length of the X axis** and **Length of the Y axis**.
  - Group: From the start position, graphics that within the set **Length of the X axis** and **Length of the Y axis** will be counted as one group. The next group starts from the end of the first group.
  - Scan: Scan by group, that is, scan the objects in the group first, and then scan the objects in the next group.
4. If the selected objects are not standard circles, check **Scan Quasi Circle**.
5. **(Optional: )** Check **Sort** and select a sorting strategy to scan the selected objects based on the strategy.


Effect picture:



Ungrouped scanning of standard circles



Grouped scanning of standard circles



Ungrouped scanning of non-standard circles

### 4.5.2.3 Clear Scan

Clear the tool path generated during scanning.

## Operation Steps:


1. In **2D Edit** page, select the object.


- In the menu bar, click **Common** → click  → **Clear Scan**.

### 4.5.3 Tube Array

Tube array is used to copy multiple or full tubes for a single standard part according to the strategy, which is convenient for machining. Standard parts must meet the requirement that there are only two upper and lower cutoff lines, and the lower cutoff line is closer to the starting surface of the tube than the upper cutoff line.

#### Operation Steps:

- Select a part that contains two cutoff lines.
- In the menu bar, click **Common** →  **Tube Array** to open the **Tube Array** dialog box:



- Select array method:
  - Array: The selected single part is arrayed according to the set quantity and strategy.
  - Tube cover: Cover the selected single part in the whole tube array according to the set strategy.
- Set the count of array or the tube length and array space.
- Select strategy:
 

When switching strategy, schematic diagrams of each strategy are visible on the left side of the dialog box.


Parameter	Description
Rotation	It refers to the rotation and translation array of tubes in the Y direction. Supported angles: 0 °, 90 °, 180 °, 270 °.
CCW	It means that the tube is turned 180 ° in the Z direction.

- (Optional: )** If the cutoff line that can be regarded as the same object within an allowable error, to reduce overlapped edge, check **Common Edge**.
- After setting, click **Confirm**. The system starts array nest, and the graphic is automatically generated to the drawing area.

#### 4.5.4 Reverse Tube Path

Rotate the drawing 180°. Note that the remaining tubes will also rotate synchronously. Pay attention to the length of the remaining tube after rotation.

##### Operation Steps:

1. In the menu bar, click **Common** →  Reverse Tube Path, after success, a prompt will pop up:

Warning: If sorting it by "Objects cut first in truncation zone", or "Last Truncate within Step", Tube Reversing may cause falling without cutting. Reordering is recommended.

#### 4.6 Simulation

Simulation is used to check whether the machining area and tool path are proper before formal machining.

The simulation is divided into:

- **Simulation:** Used to check the toolpath in real time without running the machine tool. It provides a fast but lifelike simulation machining environment. During simulation, no actual machining occurs, and only the moving track of the cutting head at high speed shows in drawing window.
- **Dry Run:** Control the machine tool to run the program without turning on the laser and machining related ports, and check whether the machining path is correct.

##### Prerequisite:


Ensure that the machining file has been saved and the current system status is **Idle**.

##### Operation Steps:

- **Simulation**

1. In the machine control bar, click  Simulate. The software automatically executes high speed simulation machining from the first segment of the machining program.

Effect picture:



- **Dry Run**

2. In the machine control bar, click  Dry Run.

## 5 Machining Related Operation

### 5.1 Execute Return to Mechanical Origin or Set Datum

When installing the software, if it is configured as bus, it can return to the mechanical origin or set the datum; If it is configured as non bus, it can only execute back to the mechanical origin. Take the bus as an example.

Encoder type:

- Incremental encoder: [Execute Return to Mechanical Origin](#)
- Absolute encoder: [Set Datum](#)

The encoder type can be set by finding the parameter **Encoder Type** in **System Parameter**.

#### 5.1.1 Execute Return to Mechanical Origin

The mechanical coordinate origin of the machine tool is the mechanical origin, or called the mechanical zero point. The mechanical coordinate system of the machine tool is unique and has been determined when the machine tool leaves the factory.


Return to the mechanical origin to synchronize the mechanical coordinate system of the system with the mechanical coordinate system of the machine tool, so you must return to the mechanical origin before machining.


**Note:** When B-axis returns to the mechanical origin, only one signal is detected and the chuck clamping state is detected before Y/B returns to the origin.

#### Prerequisite:

Before returning to the mechanical origin, ensure that all servo alarms have been cleared.

#### Operation Steps:

1. In the menu bar, click **Machining** →  → **Homing Setting** to open the **To Machine Origin** dialog box:





The dialog box pops up after the software starts by default. If you need to cancel the setting, uncheck **This Dialog Box Pops Up when Cycle Starts**.

2. **(Optional: )** Check the following parameters as required:
  - The B-axis returns to the machine origin only use single axis signal: if checked, the B-axis returns to the mechanical origin with only one position signal of the B-axis mechanical origin.
  - Check the chuck clamping state before making axis Y/B go to origin: if checked, check chuck clamping state before Y/B returns to the original point, and do not return to the mechanical original point when the chuck is clamped.
3. Select one of the following methods:
  - Click **All Axes** to automatically return to the mechanical origin in the order of Z-axis first, then X, Y, W axis.



In the machine tool control bar, click **Go Home** to execute all axes return to mechanical origin.

- Click the button corresponding to a single axis to return to the mechanical origin for each axis.




In the machine tool control bar, click **Z Home** to execute Z-axis return to mechanical origin.

- If the mechanical coordinate of the current position is consistent with the actual mechanical coordinate of the machine tool, and the machine tool has not been turned off or has not experienced any abnormal conditions such as servo alarm, click **Direct Set** to set the current point as the mechanical origin.



- In the machine tool control bar, click **To Machine Origin** to select the method of returning to the mechanical origin.


After executing returning to the machine origin, sign  appears in front of each axis in the machine tool control bar.

### 5.1.2 Set Datum

The motor of absolute encoder can set the current cutting head position as the mechanical origin position through reference.

#### Prerequisite:

The encoder type of the corresponding axis in the system parameters is 1: absolute value.



### Operation Steps:

1. In the menu bar, click **Machining** → **Axis Datum Setting**.
2. Select one of the following methods:
  - Click **All Axes** to automatically set the datum.
  - Click the button corresponding to a single axis to set the datum for each axis.

You can select **Cancel(All)** to cancel datum setting.

After setting datum, sign appears in front of each axis in the machine tool control bar. And after starting the software or releasing E-stop, the system automatically updates the machine coordinate and feedback coordinate according to feedback pulses to make the current machine coordinate match with the actual coordinate.

### 5.2 Axis Adjust

For absolute type encoders, after the mechanical origin mark disappears, the encoder data can be obtained through the axis adjust function, and the mechanical coordinates of the axis can be synchronized to the software.

### Operation Steps:

1. In the menu bar, click **Machining** → **Adjust**.
2. Select one of the following methods:
  - Click **All Axes** to automatically set adjust.
  - Click the button corresponding to a single axis to adjust each axis.

### 5.3 To Fixed Point

Set the fixed point, and select to move the cutting head to return to the fixed point after the machining.

### Prerequisite:

The fixed point position parameters in the **4.1 Fixed Point** have been set. For details, see [System Parameter](#).

### Operation Steps:

1. In the menu bar, click **Machining** → .

### 5.4 Calibrate B-axis Center

Calculate the mechanical coordinate value of the rotation shaft center through the calibration action. This function is only needed to recalibrate the B-axis center after initial use or mechanical deviation.

Because different machining actions require different centers, the system provides two calibration methods and can use up to two B-axis centers at the same time:

- Standard: It is used to calibrate the B-axis center during ordinary machining.
- Special: It is used to calibrate the B-axis center for special machining actions. Multiple commonly used B-axis centers can be set and named. When in use, it can be configured according to requirements.


### Prerequisite:


Before calibrate the B-axis center, ensure that:

- The X-axis has returned to the mechanical origin. For details, see [Execute Return to Mechanical Origin](#).
- The tube size parameter settings are the same as the actual tube. For details, see [Set Tube Size](#).

### Operation Steps:

1. Clamp a standard rectangular tube without chamfer.
2. Ensure that the clamping state of the rectangular tube is close to horizontal, and move the cutting head to the upper part of the tube.


3. In the menu bar, click **Machining** →  to open the **Calibrate B-axis Center** dialog box:




4. In the **Standard** area, click **Calibrate**. After calibration, the calibration results will be displayed in the **Standard** area.  
If you are not satisfied with the measurement results, click **Center (Z-axis)** or **Center (X-axis)** in the **Standard** area to manually enter the coordinates.
5. **(Optional: )** If there are special B-axis center requirements, perform the following operations:
  - a. In the **Special** drop-down box, select the item to be set.
  - b. **(Optional: )** Click **Rename** to modify the name. Click **Rename** to rename the set item for easy identification.
  - c. In the **Special** area, click **Calibrate**. After calibration, the calibration results will be displayed in the **Special** area.  
If you are not satisfied with the measurement results, click **Center (Z-axis)** or **Center (X-axis)** in the **Special** area to manually enter the coordinates.  
You can also click **Copy** to copy the calibration center in the standard area to the special area, and then modify it.
  - d. Click **Advanced Setting** to set the rotation center of **Normal** and **Feed Cutting** in the pop-up **Advanced Setting** dialog box.
  - e. Check **Special B-axis Rotary Center**. During machining, the center of B-axis adopts the strategy in **Advanced Setting**.  
If it is not checked, the center of B-axis uses the coordinates set in the **Standard** area during machining.
6. Input the edge exit speed followed by the cutting head in the **Out-margin Speed** input box.
7. Click **Confirm**.

The system starts to perform the calibration action:

1. Leveling tube:






2. Find the B-axis center:  
Take one side of the tube as an example:




### 5.5 Central Compensation

There is a deviation between the tube center and the actual rotation center. With the center compensation function, the tube machining accuracy is higher.

#### Operation Steps:

1. Perform the tube centering operation.
  - a. In the **Machine Tool Control Bar**, click  to open the **Centering Mode** dialog box.
  - b. Select the centering mode and click **Confirm**.
  - c. In the **Machine Tool Control Bar**, click .
2. In the menu bar, click **Machining** →  to open the **Pivot Compensation** dialog box:





3. Set the following parameters in the **Pivot Compensation** area:
  - Offset X: Offset of tube center in X direction.
  - Offset Z: Offset of tube center in Z direction.
  - Automatic compensation: Turn center compensation on or off.
4. Set the following parameters in the **Light Spot Compensation** area:  
Laser comp: Used when all four face shapes are offset in the same direction.  
Negative values are left and positive values are right.
5. Click **Confirm**.

## 5.6 Correction Dialog of Tube Face Center

Manual correction of B-axis center and center compensation.

### Operation Steps:

1. In the menu bar, click **Machining** →  to open the **Correction Dialog of Tube Face Center** dialog box:



2. Set the following parameters:
  - Center offset of the first surface A

- Center offset of the second surface B
- Center offset of the third surface C
- Center offset of the fourth surface D
- Optional B-axis center

**Note:** For the description of the center offset of each axis, see the schematic diagram of the **Tube Circle Center Correction** dialog box. The calculation method of center offset is (right margin left margin)/2.

3. Click **Save**.

## 5.7 Calibrate the Tube Center

### 5.7.1 Level and Center

Before using the level and center function, calibrate the B-axis center. For details, see [Calibrate B-axis Center](#).

The process of levelling and centering the tube differs in the tube type.

This section takes rectangular tubes as an example.

#### Operation Steps:



Click in the machine tool control bar **Centering** to level and center the tube by centering the tube through five points, finding the tube center and doing center compensation for the tool path:


1. Turn on follow-up separately on the left and right of the first face and level the tube according to the difference between the two results of follow-up height.
2. Rotate the tube 90°, and turn on follow-up on the center of the current face.
3. Repeat process **2** twice.
4. According to the five results of follow-up height and chuck center from calibrating B-axis, automatically calculate the center compensation for each face.

### 5.7.2 Manually Set Center

It is used to set the current position as the tube center for short tubes. It is mainly used when the result of levelling and centering the tube is not incorrect.

#### Operation Steps:

1. In the menu bar, click **Machining** → **Manually Set Center** to open the **Manually Set Center** dialog box:



2. Rotate the tube so that it is horizontal.
3. Move the cutting head to the center of the first surface.
4. In the **Manually Set Center** dialog box, click **Set Pos As Center**.


### 5.7.3 Auto Leveling and Centering


When the tune is long, there will be some bending deformation in the middle of the front and rear chucks, resulting in that after cutting a section of length, the centering data performed before machining cannot continue to apply. This operation can eliminate this error. After cutting a certain length, the tube will be automatically leveled and centered, and then the breakpoint will continue automatically.

If it is necessary to add the marking process of the center position in the tube. See [Centering Mark](#).

#### Operation Steps:

1. In the menu bar, click **Machining** → **Auto Leveling and Centering** to open the **Auto Leveling and Centering** dialog box:



2. Check **Automatically Do Leveling and Centering when Machining Starts** as required, and automatically perform a leveling and centering action before each machining.
3. Check **Automatically Do Leveling and Centering when Machining Truncated Line** as required, that is, when cutting the truncated line, centering first and then cutting.
4. Select a method from the **Type** drop-down button.
  - Auto match: Automatic matching center method from machine control bar  button. The text on the button indicates the currently selected centering method.
  - Single side leveling
  - 5 point seek center
  - 4 point seek center
  - Ellipse seek center
  - L steel seek center (clock wise)
  - L steel seek center (anticlock wise)
  - Multi edge seek center
  - Out edge seek center
  - Laser seek center
5. Click **Confirm**.





## 5.8 Advanced Tool

Manually debug the action of the centering method, that is, to find the deviation between the tube center and the mechanical center. The following centering methods can be debugged:

- Single side leveling
- 5 point seek center
- 4 point seek center
- Ellipse seek center
- L steel seek center
- Multi edge seek center
- Out edge seek center

### Operation Steps:

1. In the menu bar, click **Machining** →  **Advanced Tools** → select a centering method, such as **5 Point Seek Center**, to open the **5 Point Seek Center** dialog box:



2. Follow the requirements of the **Procedure; Step** area.
3. Click **Start**. After centering, the center deviation feedback is in the **Result** area. If you need to stop centering, click **Stop**.

## 5.9 Technic Library

### 5.9.1 Manage Technic Library

With the manage technic library function, you can modify, import, backup, restore and delete the parameters of existing layer technics, and add and delete material types.


If it is necessary to add a layer technic. For details, see [Set Layer Technic](#).

#### 5.9.1.1 Modify Technic

Reset layer parameters.

### Operation Steps:

1. In the menu bar, click **Machining** →  **Technic lib** to open the **Manage Technic Library** dialog box:



2. Check **Manufacturer** to activate the button.
3. Click a technic and it becomes highlighted. Click **Edit** to open the **Technic Info** dialog box.


**Note:** If there are too many documents in the technic document list, you can filter through the condition drop-down boxes in the **Filter** area below.


4. Modify layer parameters. For details, see [Set Operation](#).
5. After modification, click **Confirm**, and the modified technic will be automatically updated to the manage technic library list.
6. **(Optional: )** If need to delete a technic, select the technic and click **Delete**.
7. **(Optional: )** If need to view all technic files, click **Show All**.

### 5.9.1.2 Import Technic


Import the local technic to the technic library.

#### Operation Steps:


1. In the menu bar, click **Machining** →  to open the **Manage Technic Library** dialog box:



2. Check **Manufacturer** to activate the button.
3. Click **Import Technics** to open the **Import Technics** dialog box:



4. Click **Select Path**, select the source file, and the **Import Technics** dialog box displays the technic information, analysis results, and import status:



**Note:** There are two kinds of parse results:

- Success: The technic information of the file to be imported is different from that of the file in the technic library.
- Technic film names conflicts: The technic information of the file to be imported is identical to that of the file in the technic library.


5. **(Optional: )** If the analysis result is a technic conflict, select the following methods as needed to resolve the conflict:
  - Rename: Rename the file to be imported and save it in the technic library.
  - Cover: Replace the technic information of the file in the technic library.
  - Skip: Keep the files to be restored and the files in the technic library respectively. That is, the restore operation is not performed.


6. Check the technic file to be restored and click **Import Technics** to view the import status list.
7. Click **Exit**.

### 5.9.1.3 Backup Technic

Save the selected technic in the technic list to the specified storage path.

#### Operation Steps:

1. In the menu bar, click **Machining** →  to open the **Manage Technic Library** dialog box:





2. Check **Manufacturer** to activate the button.
3. Check one or more technics and click **Technics Backup** to open the **Technics Backup** dialog box.
4. Modify the file name and select the saved path.
5. Click **Save**.

### 5.9.1.4 Restore Technic


Restore the stored backup technic to the technic library.

#### Operation Steps:


1. In the menu bar, click **Machining** →  to open the **Manage Technic Library** dialog box:



2. Check **Manufacturer** to activate the button.
3. Click **Restore Technic Backup** to open the **Restore** dialog box:



4. Click **Select Path**, select the source file, and the **Select Backup Technic** dialog box displays the technic information, parse results, and restore status:



**Note:** There are two kinds of parse results:

- Success: The technic information of the file to be imported is different from that of the file in the technic library.
- Technic film names conflicts: The technic information of the file to be imported is identical to that of the file in the technic library.

5. **(Optional: )** If the analysis result is a technic conflict, select the following methods as needed to resolve the conflict:
  - Rename: Rename the file to be imported and save it in the technic library.
  - Cover: Replace the technic information of the file in the technic library.
  - Skip: Keep the files to be restored and the files in the technic library respectively. That is, the restore operation is not performed.
6. Check the technic file to be restored and click **Restore** to view the restore status list.
7. Click **Exit**.


#### 5.9.1.5 Manage Material

You can add or delete material types of tubs.


#### Operation Steps:



1. In the menu bar, click **Machining** → **Technic lib** to open the **Manage Technic Library** dialog box:



2. Check **Manufacturer** to activate the button.
3. Click **Manage Material** to open the **Manage Material** dialog box:




4. Enter the corresponding information in the **Material Name**, **Shorthand**, **M-Density** input boxes.
5. Click **Add**, and the material information will be displayed in the left list.
6. **(Optional: )** To delete a material, click the target material to highlight it, and then click **Delete**.
7. Click **Confirm** to close the **Manage Material** dialog box.


### 5.9.2 Nozzle Info. Management

You can view, add, and delete nozzle information. After the nozzle information is updated, the corresponding nozzle type will be added in [Layer Technic](#).

#### Operation Steps:

- View nozzle information


1. In the menu bar, click **Machining** →  to open the **Nozzle Info. Management** dialog box:



2. Select the nozzle type you want to view from the drop-down key in the **Nozzle Type** area, and it will be displayed after filtering according to the nozzle type on the left.

- Add nozzle

1. Select the nozzle type to add from the drop-down key in the **Nozzle Type** area.

If there is no suitable nozzle type, you need to add a new nozzle type: click , in the pop-up **Nozzle Information** dialog box, fill in the nozzle shorthand and name, and click **Confirm**.

2. Fill in the information of **Nozzle Dia.**.
3. Click **Add**.

- Delete nozzle information

1. Select the nozzle information to highlight it.
  2. Click **Delete**.
- Close the **Nozzle Info. Management** dialog box
1. Click **Confirm**.

### 5.9.3 Chuck Technic

The technic library is established, according to the tube shape, tube material, thickness, and diameter (or width and height) of the held tube, the torque and pressure of the front/back chuck, and the clamping/unclamping time of the chuck, so as to achieve the precise torque holding control of the chuck over tubes according to the technic library.


Tubes with the same shape, material, thickness and diameter shares the same torque holding solution.




### 5.9.3.1 New Chuck Technic

#### Operation Steps:

1. In the menu bar, click **Machining** →  to open the **Chuck Technics** dialog box:



2. Click **New** to open the **New** dialog box:



3. Set the type, material, thickness, and diameter of the tube, or width and height.
4. Click **Confirm** to add the chuck technic to the **Technic List**.

**Note:** The technic name will be automatically generated according to the set tube type, material, thickness and other related information.

If you need to rename the technic name, select the technic in the **Technic List**, right click to select the **Rename**, modify the name, and click **Confirm**.

#### Related Tasks:

For the **Technic List** area, you can also perform the following operations:

- Delete: Select one of the following methods to delete the chuck technic.
  - a. Select a technic in the **Technic List** and right click to select **Delete**.
  - b. Select a technic in the **Technic List** and click **Delete**.
- Filter:
  - a. In the **Technic List**, click **Filter** to open the **Filter** dialog box.

- b. Set the type, material, thickness, and diameter of the tube, or width and height.
  - c. Click **Filter**.
- Import:
  - a. In the **Technic List**, click **Import** to open the **Open** dialog box.
  - b. Select the imported file. The file format is.ctp.
  - c. Click **Open** to pop-up ‘Imported parameters will overwrite current parameters. Continue or not?’.
  - d. Click **Yes**.
- Export:
  - a. In the **Technic List**, click **Export** to open the **Save As** dialog box.
  - b. Select the path to save.
  - c. Click **Save**.


### 5.9.3.2 Apply Chuck Technic

Set the chuck technic information as the default chuck technic.

#### Operation Steps:

1. In the menu bar, click **Machining** →  to open the **Chuck Technics** dialog box:
 

 Chuck Technics
×



Note: Technics name will be generated automatically according to tube type, thickness, material and other related information.

2. Select the clamped tube technic in the **Technic List** area, and then view the information in the **Tech** area.
3. Select the unit by pressing the **Voltage** drop-down button in the **Unit Switch** area.
4. In the **Front Claw** area, debug the front claw.
  - a. Input voltage.
  - b. Select the clamping direction.
  - c. Click **Unclamp/Chucking** to debug the front claw.
  - d. If the debugging is not satisfactory, repeat the above actions and continue debugging.
5. In the **Back Claw** area, debug the back claw.
  - a. Input voltage.
  - b. Select the clamping direction.
  - c. Select the clamping type.

- d. Click **Unclamp/Chucking** to debug the back claw.
- e. If the debugging is not satisfactory, repeat the above actions and continue debugging.
6. Click **Apply** and 'The default chuck technic is set successfully' will pop up.
7. Click **Confirm**.
8. Click **Save**.

## 5.10 Machining Mode




### 5.10.1 Normal Machining

The formal machining of a single document controls the start of machining. The system is in normal machining mode by default.

#### Prerequisite:

- Make sure that the machining file has been saved.
- Ensure no emergency stop and alarm.

#### Operation Steps:

1. In the machine tool control bar, click  **Start**.  
The system automatically starts machining from the first line of the machining file.
2. After start machining, the following operations can be performed:
  - Stop machining: In the machine tool control bar, click , make the machine stop machining and terminate the entire machining task, and the system enters the **Idle** state.
  - Resume: In the machine tool control bar, click  **Resume** to enable the system to automatically control the machine tool to continue machining from the position where the last machining stopped.

**Note:** Before resuming, make sure that the mechanical coordinates are accurate. If not, return to the mechanical origin first.


### 5.10.2 Cycle Machining

Set the number and interval of cycle machining, and view the current number of machined times.


Cycle machining is applicable to formal machining and dry run.

#### Operation Steps:

1. In the menu bar, click **Machining** →  to open the **Cycle Machining** dialog box:



2. Check **Enabled** to set **Cycle Times** and **Interval**.  
Check **Infinite** to set the time of cycles to infinite.

3. Check **Show Cycle Tip** as required, that is, when starting cycle machining, a prompt box will pop up, prompting the current number of cycles and the total number of cycles, and whether to continue machining.
4. Click **Confirm**.
5. In the machine control bar, click , the system automatically counts according to the rules set above:
  - If the machining is suspended or stopped before the set number of cycles is reached, it indicates the current actual number of cycles.
  - The program completely executes one cycle at a time.
6. In the **Finished** parameter of the **Cycle Machining** dialog box, view the current completion times.
7. After the set number of times of machining, if you want to reset the number of times of completion, click **Clear**.

### 5.10.3 Machining Report

It is divided into production report and operation report. The generated report can be exported to a file in PDF format or printed directly.

#### 5.10.3.1 View Production Report

Before machining, the statistical information or machining is charged. The number of perforations, machining length, machining time and machining cost can be estimated before actual machining. At the same time, it supports the setting and display of vendor name, client name, task number, vendor logo, QR code and other information.


#### Prerequisite:

Ensure that the target tool path file has been machined or simulated at least once.

#### Operation Steps:

1. In the menu bar, click **Machining** →  to open the **Report Information** page. 

2. According to the actual material information and display information, click **Confirm** to generate **Production Report**.




### 5.10.3.2 View Run Report

After the target files (single or multiple) are machined, check the count of hole, hole time, cutting length, G00 length, cutting time, total time, and cycle time. At the same time, it supports the setting and display of vendor name, client name, task number, vendor logo, QR code and other information.

#### Operation Steps:

1. Select any of the following methods to open the **Report** dialog box:
  - In the report bar, click **Report**.

- In the menu bar, click **Machining** → **Report**.



2. View statistics.
3. As needed, do the following:
  - Charging
    - a. After checking the machining item to be charged, click **Charging** to open the **Charging** dialog box:

The screenshot shows a 'Charging' dialog box with the following fields and values:

- Hole count: 0 PCS
- Unit price: 0.0 ¥/PCS
- Working Hours: 0.015 h
- Working Cost per Hour: 0.0 ¥/h
- Pipe Price: 0.0 ¥/PCS
- Calculate button: 0.0 ¥

- b. Enter each unit price, click **Calculate**, and the system will automatically calculate the total cutting cost.
- Output report
  - a. Check the target machining item and click **Report** to generate a report of each statistical information:

The screenshot shows a 'Production info' window with the following content:

2022-12-05

Statistical Data			
Pierce Count	0	Piercing Time	00:00:00.000
Cut length	0.902(m)	G00 len. (m)	0.161(m)
Cutting time	00:00:54.258	Total Time	00:00:55.343
Cycle Times	1	Part Count	1

**1. 4.ncexa(Base Result)**

Part Name	Cut length (m)	Cutting time	Pierce Count	Piercing Time	Part Count
P1	0.628	00:00:37.780	0	00:00:00.000	1

- b. Click the corresponding button as required. The button description is as follows:

Button	Description
	Click this button to print the report.
	Click this button to zoom in the report.
	Click this button to zoom out the report.

Button	Description
	Click this button to display the report in 100% proportion.
	Click this button to display the report width according to the page width.
	Click this button, and the report will be completely displayed in the page according to the whole page.
	Click this button, and the report will be completely displayed in the page according to two pages.
	Click this button to save the report locally in the format of .pdf.
<input type="text" value="Type text to find..."/>	In this input box, enter keywords to find text.


### 5.10.4 View Log

The log records important user operations, system events and time, including information and historical information after the system is started.



When the log file is greater than 20M, a backup log file (NcStudio\_xxxx.log) is automatically generated in the **User** folder (path), and the original log content is cleared.

#### Operation Steps:

- Select any of the following methods to open the **Log** dialog box and view the log:
  - In the operation information bar, double-click **Alarm / Log**.
  - In the menu bar, click **Machining** → **Log**.



- Select the log type to view:
  - Turn on the **Show Info.** button to display software operation information with the icon .

- Turn on the **Show Warning** button to display the warning information with the icon .
- Turn on the **Show Error** button to display the error information with the icon .
- Turn on the **All Logs** button to display all the corresponding log information since the system was started.

All buttons are on by default.

3. To view more log information, click **Query History** and select the viewing date. You can view log information within 1 year at most.
4. To delete all log information, click the **Clear** button.

**Note:** Please clear the system log regularly! Otherwise, when the system log file is too large, the system performance and response time will be affected.





## 6 Set Parameter

### 6.1 System Parameter

This section describes how to find and modify system parameters by taking the modification of parameter **Fixed Point Position (X)** as an example.

#### Operation Steps:


1. In the menu bar, click **Set** →  to open the **System Parameter** dialog box:



Name	Value	Unit	Effective
<b>2.0.0 Jog Speed</b>			
Manual Low(X)	6000	mm/min	Immediately
Manual Low(Y)	6000	mm/min	Immediately
Manual Low(Z)	1200	mm/min	Immediately
Manual Low(B)	5	r/min	Immediately
Manual Low(W)	120	mm/min	Immediately
Manual High(X)	18000	mm/min	Immediately
Manual High(Y)	18000	mm/min	Immediately
Manual High(Z)	1800	mm/min	Immediately
Manual High(B)	16	r/min	Immediately
Stepping speed(X)	6000	mm/min	Immediately
Stepping speed(Y)	6000	mm/min	Immediately
Stepping speed(Z)	1200	mm/min	Immediately
<b>2.2.0 Machining Accuracy</b>			
CurveError	0.05	mm	Immediately
<b>3.1 Lubricate</b>			
Lube Type	0		Immediately
LubricateTime	10	s	Immediately
Auto Lube Interval for Solid O	100	h	Immediately
Auto Lube Dist.	1000	m	Immediately
Enable Lube Pressure Detectic	No		Immediately
Lube Pressure Detection Dela	5	s	Immediately

Operator: [Dropdown]  
Name: Manual Low(X)  
Value: 6000 mm/min  
Description: XThe default axis speed in manual mode.

2. Use any of the following methods to find the **Fixed Point Position (X)**:
  - Search: In the search box, enter **Fixed Point Position (X)**, click **Go To**, and the search results will be displayed on the right.
  - Find through the node tree on the left: In the node tree, click **View All** → **Advanced Function** → **4.1 Fixed Point**, and the parameters in the **4.1 Fixed Point** node will be displayed on the right. Find the **Fixed Point Position (X)**.
- Double click the parameter **Fixed Point Position (X)** to pop up the **Input Box**:



- Enter value.
- Click **Confirm**.

## 6.2 Port Setting

Monitor the condition of the machine tool by controlling the input and output ports, including conducting simulation tests, modifying port polarity, and setting port attributes.

General port settings are used to detect whether each port is effective during debugging, and change the port polarity according to actual needs.

The relationship between the machine tool condition and the input and output ports is as follows:

- Input port:  With single;  No single.
- Output port:  With single;  No single.


When the port is in the test state, there is a T in the lower left corner of the signal, such as:



### Operation Steps:



1. In the menu bar, click **Set** → **Port Setting** to open the **Port Setting** dialog box:




2. Select the port, and select the following operations according to the actual situation:

Operation	Description
Click <b>Test On</b> or <b>Test Off</b>	Carry out simulation test, simulate opening or closing the port, and judge whether there is output by testing the port signal. The mark T in front of the port indicates that the port is testing.
Click <b>Cancel Test</b>	Cancel the test of the port.
Click <b>Cancel All</b>	Cancel the test of all ports.
Click <b>Filtering</b>	Set the filtering duration, and the system will exclude the signals whose occurrence time is less than this duration.
Click <b>Modify Polarity</b>	The polarity of the port changes to the opposite polarity.

### 6.3 Lead Screw Compensation


When the machine tool itself has errors and cannot reach the expected accuracy, compensate the lead screw error to improve the machining accuracy.


Before using the lead screw compensation, click **Set** in the menu bar →  **System Parameter**, to find and set the manufacturer's parameter **Lead Screw Compensation Mode**. There are three methods of lead screw error compensation:

Value	Description
0	No compensation
1	Only backlash compensation, use the parameter <b>Backlash</b> to compensate.
2	Backlash compensation and unidirectional compensation. The compensation is made by printing the one-way data of the laser interferometer and the backlash value (printed by the dial indicator) set in the system parameters.
3	Bidirectional compensation. Compensate according to the bidirectional data of laser interferometer.

#### 6.3.1 Only Backlash Compensation

##### Operation Steps:

1. In the menu bar, select **Manufacturer** permission, click **Set** →  **System Parameter** → **1.2 Error Compensation**:



2. Set parameters:
  - Lead screw compensation mode: set it to 1, select only backlash compensation mode.
  - Backlash: [Reverse error value - Forward error value].

### 6.3.2 Bidirectional Compensation


#### 6.3.2.1 Generate Screw Error Compensation File

##### Prerequisite:

- It has returned to origin, and the position of the origin switch has been adjusted.
- The parameter **Lead Screw Compensation Mode** has been set to 0.

##### Operation Steps:

1. In the menu bar, click **Set** →  to open the **Screw Comp.** dialog box:




2. Follow the steps below to get the actual measurement data of the machine tool:
  - a. In the **Locate Axes** area, select the locate axis.
  - b. Set the relevant parameters of the positioning program in the **Laser Interferometer** area. The set parameters need to be consistent with the laser interferometer.
  - c. Click **Generate**, the result will automatically written into the **Locator Program** area.
  - d. Click **Execute**, the machine tool starts to move according to the generated positioning program, and records the position data at the measuring point.
  - e. In the laser interferometer side, save the recorded position data as a RTL or LIN format lead screw error compensation file.

### 6.3.2.2 Execute Compensation

#### Operation Steps:

1. Close the software and double-click **NcTune** under the file installation directory C:\Program Files\Weihong\NcStudio\Bin to enter the **NcTune** software.
2. Click **Screw Error** to enter the **Screw Error Compensation** page.
3. Click **Import** to import the lead screw error compensation file **NcTune** generates curves from files:



Red curve: positive error; Blue curve: reverse error.

4. Click **Apply** to automatically save the compensation data to the corresponding configuration file.
5. Test the accuracy of screw rod error compensation.
  - a. Restart **NcStudio** software.
  - b. Turn on the lead screw error compensation function, and set the parameter **Lead Screw Compensation Mode** to 3, that is, the bidirectional compensation method.

**Note:** If use **Backlash and Unidirectional Compensation** method, then set the **Lead Screw Compensation Mode** to 2, and set the parameter **Backlash**.

- c. X, Y return to machine origin.
- d. Use a laser interferometer to test the accuracy of the screw error compensation.

## 6.4 Drive Parameter


Display the parameter value, unit, effective time and value range of driver parameters according to each axis, and support import, export and restore initial value settings.

Generally, during debugging, it is necessary to set basic driver parameters to drive the machine tool.

### Operation Steps:



1. In the menu bar, click **Set** → **Drive Param** to open the **Drive Param** dialog box:



2. Perform the following as needed.

If...	So...
View drive parameters	1. In the drop-down key of axis, select the axis to view. 2. In the <b>Show All</b> drop-down button, select <b>Show All</b> or <b>Show Common</b> .
Import drive parameters	1. Check <b>Manufacturer</b> permission. 2. Click <b>Import</b> to import a file in the format of .dat.
Export drive parameters	1. Check <b>Manufacturer</b> permission. 2. Click <b>Export</b> to save all drive parameters locally in the file format of .dat.
Factory reset	1. Check <b>Manufacturer</b> permission. 2. Click <b>Factory Reset</b> .
Refresh	Click <b>Refresh</b> .

## 6.5 Laser Device Setting

The laser device settings are divided into:

- [Basic Setting](#): According to the type of laser driver, set the basic parameters, spot parameters and communication parameters of the laser driver.
- [QCW Mode Setting](#): If the peak power is much greater than the average output power of the laser driver, set the QCW mode to pulse mode.

### Note:

- If only basic settings are made, the QCW mode is continuous.
- When the QCW mode is pulse mode, the cutting parameter speed power and speed frequency curve functions will be shielded.

- [Adjust Laser AVC](#): Make the analog target output value of the laser consistent with the actual voltage.


The communication methods supported by each laser driver type include:

Communication Mode	Raycus	IPG-YLR	YL-RK	Maxphotonics	SPI	IPG(US)	IPG(DE)	SUPER	Feibo	GW	JPT	Trupf
Serial port	√	√	√	×	√	×	×	×	×	×	×	×
Internet port	×	√	√	×	×	√	√	×	×	×	×	×
Terminal board IO	√	√	√	√	√	√	√	√	√	√	√	√

## 6.5.1 Basic Setting

### Operation Steps:

1. In the menu bar, click **Set** →  → **Basic Setting** to open the **Basic Setting** dialog box:



2. Check **Manufacturer** to activate the **Basic Parameters** area and **Communication Param** area.
3. In the **Basic Parameters** area, set the following basic parameters:
  - Device type
  - Max power
  - Min pulse width
4. In the **Communication Param** area, select the communication mode.
5. In the **Burst Param** area, set the following click parameters:
  - Power
  - Frequency
  - Duty cycle
  - Delay



6. **(Optional: )** To reset the current laser driver service time, click **Clear** in the **Laser Device** area.
7. Click **Confirm**.


## 6.5.2 QCW Mode Setting


The continuous mode is the default mode. The QCW laser driver can switch the working mode of the laser driver to the pulse mode on this page.

### Prerequisite:

Make sure that the relevant parameters have been set on the **Basic Setting** page.

### Operation Steps:

1. In the menu bar, click **Set** →  → **QCW Mode** to open the **QCW Mode** dialog box:



**Parameters Setting Steps**

1. Set Laser Device Work Mode to QCW
2. Set Peak Power, it can confirm the maxValue of Duty Cycle
3. Set Duty Cycle, it can confirm the maxValue of Frequency\*Pulse Width
4. Set Repetition Frequency or Pulse Width, Repetition Frequency\*Pulse Width  $\leq$  Duty Cycle\*10

**Laser Device Work Mode**

Jog     pulse

**QCW Parameters Setting**

Peak Power:  %    Repetition Frequency:  Hz

DutyCycles:  %    Pulse Width:  ms

**Pulse Duration & Duty Cycle vs. Peak Power**

Constant Average Power/  
Constant Pulse Energy

Confirm    Cancel

2. In the **Laser Device Work Mode** area, check **Pulse**.
3. Set parameters in the **QCW Parameters Setting** area:
  - **Peak Power**
  - **Duty Cycle**
  - **Repetition Frequency**

- **Pulse Width**


Among:


- Maximum input duty cycle=1000 ÷ peak power
- Repetition frequency × pulse width ≤ duty cycle \* 10

4. Click **Confirm**.

### 6.5.3 Adjust Laser AVC

**Operation Steps:**


- In the menu bar, click **Set** →  → **Adjust Laser AVC** to open the **Adjust Laser AVC** dialog box:



- In the **Set** area, set the number of data groups and click **Confirm**.  
By default, the number of data groups is 10. In the **Data** area, there are 0 to 9 rows of data.
- Perform different operations according to different ways of filling **DA Output** column data.
  - Auto fill-in: Check **Auto Fill-in** and click **Confirm**.
  - Fill in manually: In the **DA Output** column, fill in the values in turn.

Perform different operations according to the method to fill in the **Real Voltage** column data.

- Automatically output analog quantity according to the set time interval: Click the **Space** input box to input the set value, and click **DA Output in Order** in turn.

- Fill in manually:
  - a. In the **Data** area, select the target data and turn on .
  - b. Fill the actual measured voltage into the corresponding **Real Voltage** column.
- 1. **Enable.**
  - Check: Perform voltage correction. When the DA output data is inconsistent with the actual voltage data, it is recommended to check.
  - Uncheck: No voltage correction is performed.
- 2. Click **Update.**

**Related Tasks:**

- Export: Click **Export** to save the current data locally.
- Import: Click **Import** to import the locally saved data into the current **Adjust Laser AVC** dialog box.

## 7 System Maintenance

### 7.1 Automation


#### 7.1.1 Set Tube Length

Set the current tube length for auto load, calculate the clamping position of the rear chuck, and set the maximum tube length, that is, the distance from the end position of the tube clamped by the rear chuck to the lower part of the cutting head when the pull axis machine is 0.

The tube length setting requires the manufacturer's password.

#### Operation Steps:

1. In the menu bar, click **Maintain** → **Set Tube Length** to open the **Set Tube Length** dialog box:



2. Check **Manufacturer**.
3. Set the parameters **Largest Length** and **Current Length**.
4. Check **Enabled**.
5. Click **Apply**.

#### 7.1.2 Tail Material Processing Setting


The user can set the length of different tails and execute different unloading actions. Up to 6 tail lengths can be set.

Tail material processing action and enable need to be edited in **NcConfig** →

**Configuration** → **Flow Edit**.

**Operation Steps:**


1. In the menu bar, click **Maintain** →  **Tail material processing setting** to open the **Tail Material Processing Setting** dialog box:



2. Set the tail material length.  
The length of the tail material is calculated based on the maximum YMAX of the Y soft limit minus the length of the layout tube, which is the Y-axis mechanical coordinate where the last cutting line of the part is located. The relative length of the two subtracted is the tail material length.
3. Check the items that need to be enabled.
4. Click **Confirm**.


**Related Tasks:**

An example is shown in the following diagram:



Save, at this time the tail material processing is turned on, and different unloading actions are used according to different tail material lengths.

Click batch machining end in extensions of processing procedure. Then click automatic loading, and the tailings will be automatically processed according to the demand during the machining.




**Precautions:**


1. If you only use the same tail material process action, you can set the length to be the same as the upper limit of the Y-axis.
2. Automatic unloading needs to be called in flow edit, if it is not called, even if it is configured, it will not be executed automatically.
3. If the Y-axis G00 speed is set during tail material processing, it is necessary to set the G00 speed of the recovery system after the end.

### 7.1.3 Part Collection Setting

Users can set the length of different parts, and perform different part collection actions. Up to 6 tail lengths can be set.

#### Operation Steps:


1. In the menu bar, click **Maintain** →  **Part collection setting** to open the **Part Collection Setting** dialog box:



2. Set the part length.
3. Check **Enabled**.
4. Click **Confirm**.

#### Related Tasks:

Edit the required collection actions in **NcConfig** → **Configuration** → **Flow Edit**, the example is shown in the following figure:



Save, and the parts collection is turned on at this time. Different parts collection actions are used according to different lengths.

#### Precautions:

1. If you only use the same part collection action, you can set the length to be the same as the upper limit of the Y-axis.
2. The cutoff and parts collection actions in the flow edit are both actions after the parts cutoff. If there are two edit actions at the same time, the parts collection action is executed first, and the action after the cutoff is executed.
3. You can use parts collection for unloading, and the action after cutoff generally does not need to be configured.


## 7.2 External Device


### 7.2.1 Monitoring

Real time monitoring of the following information:


- Motion speed of each axis
- Port voltage value of Lambda controller and expansion board

#### Operation Steps:

1. In the menu bar, click **Maintain** →  **monitoring** to open the **Monitoring** dialog box:



2. Click **Analog** to switch pages to view the Lambda controller and expansion board.



### 7.2.2 Laser Monitor

Check the status of the laser driver, such as power, temperature, water flow, mode, alarm, etc.

#### Prerequisite:

- Make sure that the laser driver is in good condition.
- Ensure that NcStudio software communication is normal.

#### Operation Steps:

1. In the menu bar, click **Maintain** →  **Laser Monitor**:



- If there is a specific path in the **Laser Device Program Path** of the system parameter **Advanced Function Parameter** → **Laser Device Path**, directly open the upper computer software of the laser.
- If the parameter Laser Device Program Path does not exist, the file selection dialog box will pop-up to select the path of the upper computer software of the laser device.

### 7.2.3 Lubricate Screw

The lead screw shall be lubricated after the machine tool runs for a period of time.

There are two methods:

- Auto: The system can automatically perform lubrication during machining according to the set parameters by setting parameters.
- Manual: Manually control the machine tool to perform lubrication.

#### Operation Steps:

- Auto




- In the menu bar, click **Set** → to open the **System Parameter** dialog box:

The screenshot shows the 'System Parameter' dialog box with a tree view on the left and a table of parameters on the right. The tree view is expanded to 'View All' → 'External Device' → '3.1 Lubricate'. The table below shows the parameters for this section.

Name	Value	Unit	Effective
<b>2.0.0 Jog Speed</b>			
Manual Low(X)	6000	mm/min	Immediately
Manual Low(Y)	6000	mm/min	Immediately
Manual Low(Z)	1200	mm/min	Immediately
Manual Low(B)	5	r/min	Immediately
Manual Low(W)	120	mm/min	Immediately
Manual High(X)	18000	mm/min	Immediately
Manual High(Y)	18000	mm/min	Immediately
Manual High(Z)	1800	mm/min	Immediately
Manual High(B)	16	r/min	Immediately
Stepping speed(X)	6000	mm/min	Immediately
Stepping speed(Y)	6000	mm/min	Immediately
Stepping speed(Z)	1200	mm/min	Immediately
<b>2.2.0 Machining Accuracy</b>			
CurveError	0.05	mm	Immediately
<b>3.1 Lubricate</b>			
Lube Type	0		Immediately
LubricateTime	10	s	Immediately
Auto Lube Interval for Solid O	100	h	Immediately
Auto Lube Dist.	1000	m	Immediately
Enable Lube Pressure Detectic	No		Immediately
Lube Pressure Detection Dela	5	s	Immediately

Operator: [Dropdown]  
Name: Manual Low(X)  
Value: 6000 mm/min  
Description: XThe default axis speed in manual mode.

- In the parameter tree on the left, select the node **View All** → **External Device** → **3.1 Lubricate**. Lubrication parameters and parameter information are displayed on the right:




- c. Set manufacturer parameters **Lube Type**:
  - **0**: Do not enable auto lube
  - **1**: Auto lube (time)
  - **2**: Auto lube (distance)
- d. Set the following parameters according to the selected lubrication type:
  - **Lubricate Time**
  - **Auto Lube Interval for Solid Oil Pump**: Set when the lubrication type is **Auto Lube (Time)**.
  - **Auto Lube Dist.:** Set when the lubrication type is **Auto Lube (Distance)**.
  - **Enable Lube Pressure Detection**
  - **Lube Pressure Detection Delay**

After setting, the auto lube interval for solid oil pump/auto lube distance interval of the system every time. Auto open lube port duration **Lubricate Time**.

• Manual

- a. In the menu bar, click **Maintain** → **Lube** to open the **Lube** dialog box:



- b. Set the corresponding parameters.
- c. Click **Start**, and the system starts to execute lubrication action, and displays the lubricated times.


### 7.2.4 Adjust Air Pressure

Adjust air pressure means to correct the analog output of gas, so that the actual air pressure is consistent with the analog output.

DA refers to converting digital quantity into analog quantity.

#### Operation Steps:

1. In the menu bar, click **Maintain** →  to open the **Adjust Air Pressure** dialog box:



**Gas DA Calibration**

Gas DA output can be calibrated through conducting gas DA output, measuring actual pressure and fill the value into the table.



Select Gas Type: **Air** (dropdown) | **Gas ON** (indicator)

Set: Data Group No. **10** | **Confirm** |  Auto fill-in | DA Output in Order: **3 s**

	DA Output		Output Next	Actual Pressure
1	0.0 V	<input checked="" type="radio"/>	Output	0.000 bar
2	0.0 V	<input checked="" type="radio"/>	Output	0.000 bar
3	0.0 V	<input checked="" type="radio"/>	Output	0.000 bar
4	0.0 V	<input checked="" type="radio"/>	Output	0.000 bar
5	0.0 V	<input checked="" type="radio"/>	Output	0.000 bar
6	0.0 V	<input checked="" type="radio"/>	Output	0.000 bar
7	0.0 V	<input checked="" type="radio"/>	Output	0.000 bar
8	0.0 V	<input checked="" type="radio"/>	Output	0.000 bar
9	0.0 V	<input checked="" type="radio"/>	Output	0.000 bar
10	0.0 V	<input checked="" type="radio"/>	Output	0.000 bar

Enable  | Import | Export | Update | Exit

2. In the **Select Gas Type** area, select the target gas.
3. In the **Set** area, set the data group no. and click **Confirm**.  
By default, the number of data groups is 10. In the **Data** area, there are 0 to 9 rows of data.
4. Perform different operations according to different ways of filling **DA Output** column data.
  - Auto: Check **Auto Fill-in** and click **Confirm**.
  - Manual: In the **DA Output** column, fill in the values in turn.
5. Perform different operations according to the way to fill in the **Actual Pressure** column data.

- Automatically output analog quantity according to the set time interval: Click the **Space** input box to input the set value, and click **DA Output in Order** in turn.
- Manual:
  - i. In the **Data** area, select the target data and turn it on , Select **Gas Type** area  is highlighted, gas output. The current display value of the proportional valve is the actual air pressure value.
  - ii. Fill the displayed value of the proportional valve into the corresponding **Actual Pressure** column.

#### 6. Enable.

- Check: Do adjust air pressure. It is recommended to check when the DA output data is inconsistent with the actual air pressure data.
- Uncheck: Do not adjust air pressure.

#### 7. Click **Update**.

#### Related Tasks:

- Export: Click **Export** to save the current data locally.
- Import: Click **Import** to import the locally saved data into the current **Adjust Air Pressure** dialog box.

### 7.3 Tool

#### 7.3.1 Reconnect Manually

It is applicable to the system with bus configuration. After the communication between the system and the drive is disconnected, the communication with the drive can be reestablished through manual reconnection.

#### Operation Steps:

1. In the menu bar, click **Maintain** → .

#### 7.3.2 One-click Cutoff

One-click cutoff. Use large graphic technic to cutoff at the current Y-axis coordinate position.


**Warning:** The section that is forbidden to be executed is not closed or irregular tube, otherwise there is danger.

#### Prerequisite:


Ensure that the section of the current machining document is consistent with the actual clamped tube.

#### Operation Steps:

1. In the menu bar, click **Maintain** →  to open the **One-click Cutoff** dialog box:



2. Select the rotational direction.
3. Check **Whether to Execute Centering Before Cutoff** as required.
4. Click **Start** to pop up a prompt box:



5. Click **Yes** to start the cutoff operation.


### 7.3.3 Custom Instructions Debug

Whether the custom instructions debug are reasonable. The customized instructions are configured in **NcConfig** → **Configuration** → **Flow Edit**.

**Note:** If the process is written incorrectly, the machine tool may be damaged. Please stop debugging in time when executing.

#### Operation Steps:

1. In the menu bar, click **Maintain** → **Custom Instructions Debug** to enter the manufacturer password and open the **Custom Instructions Debug** dialog box:



2. Select the instruction in the **Debugee** drop-down box.
3. Click **Execute** to check whether the instruction is reasonable.


### 7.3.4 Disable Action of Flow Edit

Disable or enable action of flow edit to include user defined instructions.

This function supports saving the current shielding action as custom configuration, which is convenient for the next call, and 10 configurations can be saved. It supports setting to proof mode, that is, all flow edit actions are disabled by default.

#### Operation Steps:


1. In the menu bar, click **Maintain** → **Disable Action of Flow Edit** to open the **Disable Action of Flow Edit** dialog box:





The actions in the **General** tab are user defined commands.

2. Select **Configuration** from the drop-down list. If select **Proof Mode**, all flow edit actions will be disabled by default and can modify.

In the selected configuration, double-click the configuration name to modify the configuration name.



3. Disable or enable action of flow edit as required.
  - Disable: That is, the button is set to the  state.
  - Enabled: That is, the button is set to the  state.
4. Click **Save** to save the current flow action disabled data to the selected configuration.
5. After the settings are complete, click **Apply**.


### 7.3.5 Trial Run

At the initial commissioning stage of the machine tool, trial run is required to ensure the stability of the motion of each axis of the machine tool.

The system provides two methods:

- User defined trial: Used for external devices such as aging chucks. The action executed is the command action of the **User Defined Trial** configuration edited by the process.

The instruction action configuration entry is: **NcConfig** application **Configuration** → **Flow Edit** object **Custom Aging**.




- Axis aging: Used for the movement of each axis of aging machine tool. Configure shaft parameters and control aging time through the **Trial Run** dialog box to start aging.

#### Prerequisite:

To ensure the safety of the machine tool, before aging the machine tool, make sure that all axes have executed [Execute Return to Mechanical Origin or Set Datum](#).

#### Operation Steps:

1. In the menu bar, click **Maintain** →  **Trial Run** to open the **Trial Run** dialog box:



- Depending on the method selected, select to perform the following operations:
  - If you select custom aging, check **Enabled** in the **Custom Aging** area.
  - If axis aging is selected, select the axis to be aged in the **Axis** area, and set the starting/ending position and the first/second/third stage speed of aging.
- In the **Control** area, set the time of the first/second/third aging stage.
- At the bottom of the dialog box, check **Shield Collision and Cutting Head Alarm** as required.

**Warning:** There is a risk of cutting head collision, please use with caution!

- Click **Start**, and the machine tool begins to age.  
During machine tool aging, click **Stop** to stop machine tool aging.

### Related Tasks:


To view the machine tool aging history, click **History**.

### 7.3.6 MDI

The user can freely input and execute up to seven simple programming instructions in this area to realize rapid movement, change the system state or carry out simple machining.

### Operation Steps:

- In the menu bar, click **Maintain** → **MDI** to open the **MDI** dialog box:






2. Select the target command line, enter the command in the input box, and use ; (semicolon) to wrap.
3. Click **Execute** corresponding to the line, and the system will automatically execute the entered instructions.

### 7.3.7 Machine Maintenance Regular Reminder

As an essential function of machine tools, machine tool maintenance reminder can remind customers to maintain machine tools. The current machine tool maintenance reminder functions are as follows:

- Supports custom maintenance reminder content. For the default maintenance reminder content, it can also be changed through manual editing permissions.
- All content supports import and export, which is convenient for batch updates, just import the content directly without manual editing again.
- Distinguish between the permission of the manufacturer and the operator. When some important maintenance content needs to be canceled under the permission of the manufacturer (confirmed by the manufacturer), the permission of the operator cannot be reset at will to avoid damage to machine components.

#### Function Entry:

1. In the menu bar, click **Maintain** →  to open the **Machine Maintenance Regular Reminder** dialog box:

Machine Maintenance Regular Reminder

No.	Name	Maintenance Cycle	Unit	Progress	
1	X-axis dustcloth	1	Day(s)	9%	
2	Waste Carriage	1	Day(s)	9%	
3	X-axis protective plate	1	Day(s)	9%	
4	Head of cutting head and QBH	1	Day(s)	9%	
5	Gas circuit component and pipeline	2	Day(s)	4%	
6	Water pipe	2	Day(s)	4%	
7	Optoelectronic switch	3	Day(s)	3%	
8	Container for automatic lube	10	Day(s)	0%	
9	Lateral bracing in the middle of machine bed	20	Day(s)	55%	
10	Strainer for chiller	20	Day(s)	55%	
11	Filter element for air compressor	20	Day(s)	55%	
12	Guide rail, slider and ball screw for Z-axis	80	Day(s)	13%	
13	Guide rail, gear and rack for X-axis and Y-axis	80	Day(s)	13%	
14	Meshing clearance between gear and rack	200	Day(s)	5%	Verify the ver
15	Coolant device	180	Day(s)	6%	

Manufacturer

### Information Displayed on the Page:

Parameter	Description
Name	The name of the maintenance item must be unique.
Maintenance cycle/unit	Choose between time/distance periods. <ul style="list-style-type: none"> <li>▪ Time period description: How many days should the maintenance be carried out; The number of days is the world time obtained by computer.</li> <li>▪ Distance period description: The machine tool needs to be maintained every few meters; The distance adopts the machine tool movement distance.</li> </ul>
Progress	The extent to which the maintenance cycle is progressing.
Notify type	Choose between alarm/notification. <ul style="list-style-type: none"> <li>▪ Alarm: The progress is displayed in red, and the alarm dialog box pops up.</li> <li>▪ Notification: The progress is displayed in red and a "warning" log is generated.</li> </ul>
Description	The service items were described and the maintenance contents were required to be clarified. There was no misunderstanding.
Permission	Choose between operator/manufacture. Differentiate operations with different permissions. Reminder content for machine tool maintenance with manufacturer permission: <ul style="list-style-type: none"> <li>▪ Operator permissions cannot be reset.</li> <li>▪ After reaching 100% progress, you need to enter the manufacturer's password to confirm completion.</li> </ul>

### Function Operation Instructions:

- **Manufacturer**: Operation authority selection. If it is not checked, it means that it is the operator right now, and only the maintenance content items of view history and reset the operator right can be checked.
- History: Display reset maintenance items, prompt/alarm content and completion status.
- Reset: Start the progress of an existing maintenance item from zero.
- Edit: Modify an existing maintenance item.
- Add: Add a maintenance item.
- Delete: Delete existing maintenance items.
- Export: Save the content of the current maintenance item to the current computer, the format is .dat, and the file name customization.
- Import: Import the content of the local maintenance item into the software in the format of .dat.

### 7.3.8 Encoder Detection

It is used to detect whether the encoder feedback is consistent with the motor rotation mode, and automatically calculate the PG frequency division ratio, so as to avoid affecting the second-generation flying cut and follow-up effects, and the inconsistency between the

actual coordinates of the machine tool and the software coordinates under the non-servo alarm E-stop state.


Only applicable to non-bus control systems.

**Prerequisite:**

- The drive parameters are set correctly.
- The pulse equivalent of each axis, axis direction and the number of command pulses per cycle have been set correctly.
- The X-axis and Y-axis have been moved to the middle of the machine tool stroke, and there is enough stroke for detection.

**Operation Steps:**

1. In the menu bar, click **Maintain** →  to open the **Encoder Detection** dialog box:





- **(Optional: )** Set XY moving distance and B step distances in the **Set** area.
    - XY moving distance: The default distance is 10mm, which is generally set as a long pitch to minimize the error of detection.
    - B step distances: Suggest to use 180deg.
2. In the **Control Panel** area, click **Start**.  
If **Automatically Write Detection Values after Detection** is checked, the feedback data results will auto written into the system parameters.

**7.3.9 Track Error Measurement**

Through multi axis linkage, the difference between transmission and feedback tracks is displayed, which is the basis for subsequent adjustment of driver parameters.


**Operation Steps:**

1. In the menu bar, click **Maintain** →  to open the **Track Error Measurement** dialog box:



2. Set track speed in the **Basic Track Parameters** area.
3. Set graphic.
  - a. Select a graphic type from the **Test Type** drop-down box.
  - b. Depending on the selected graphic, do the following:
    - The test type is **Roundness Test** or **Rectangularity Test**:
      - i. In the **Graphic Parameters** area, set parameter information.
      - ii. Click **Draw** to display the corresponding graphic in the middle drawing area.
    - The test type is **Custom Track Test**:
      - Draw: Click the corresponding graphic button in the **Track Error Measurement** dialog box, and then draw a graphic in the drawing area.
      - Import: In the **Graphic Parameters** area, click **Import DXF** to select a file.
- Click **Start Sampling**, and you can see the test track in the **Track Error Measurement** dialog box. If the measurement type is **Roundness Test**, the results are displayed in the **Result Parameters** area.

Effect picture:





## 8 System Management

### 8.1 Switch Language

The software supports more than ten languages.

#### Operation Steps:

1. In the menu bar, click **About** →  to select the language to be switched, and the restart prompt box pops up:





2. Click **Restart Software** to restart the software.

### 8.2 Switch Unit

Currently, the software supports metric and inch systems.

#### Operation Steps:

1. In the menu bar, click **About** →  to select the unit to be switched, and the restart prompt box pops up:





2. Click **Restart Software**, and it will take effect after the software is restarted.

### 8.3 Switch Theme

Currently, the software supports white and black themes.

#### Operation Steps:

1. In the menu bar, click **About** →  to select the theme to be switched, and the restart prompt box pops up:




2. Click **Restart Software**, and it will take effect after the software is restarted.

## 8.4 Modify Password

Modify the manufacturer password, which is only used to view and modify the manufacturer parameters.

### Operation Steps:

1. In the menu bar, click **About** →  to pops up the **Modify Password** dialog box:




2. Enter the old password, the new password set, and confirm the new password.
3. Click **Modification**.

## 8.5 Installation Package


Generating a complete installation program in the current NC system is conducive to backing up the system files and saving the stable version of the system software.

### Operation Steps:

1. In the menu bar, click **About** →  to open the **Packup Tool** dialog box:



2. Modify the installation package name and select the storage path of the installation package.
3. **(Optional: )** Click **Advanced** to set the following parameters:



**Packup Tool** [Close]

Installer name: 2000-TS-15.023.20\_Beta-2023\_07\_11\_13\_40\_46

Installer path: C:\Users\wangjiefeng\Desktop [Browse...]

**Advanced Settings:**

Language: 中文(简体) [v]

Auto Boot: Do Not Auto Boot [v]

Parameter Migrate:  Keep local manufacturer parameters  
 Keep local user parameters  
Other:  Support Language Selection  
 Start The Software After Installation  
 Check Setup Environmet

Note: The above advanced settings are the default values of each item during the software installation process.

[Back] Advanced [Pack up]





Parameter	Description
Language	Supports more than ten languages.
Parameter migrate	<ul style="list-style-type: none"> <li>▪ Keep all local parameters.</li> <li>▪ Keep only machine-specific parameters.</li> <li>▪ Fresh installation: Do not retain any parameters, and use the initial parameters of the software.</li> </ul>
Auto boot	Whether to start the software automatically when starting up.
Support language selection	Whether Chinese or English is supported during installation.
Create a desktop shortcut	The computer desktop creates a shortcut icon for the installation package.
Start the software after installation	Start the software automatically after installation.
Check setup environment	Before installing the software, check whether the environment of the current computer system meets the software operation requirements. If not, you can choose to install the basic environment package.

4. Click **Pack Up**.

After the installation package is created, view the generated installation package under the selected storage path.

## 8.6 System Button

Description:

Button	Description
 Show Desktop	Minimize the system software interface and display the current computer desktop.
 Restart Software	Shut down the system software and start it again.
 Shutdown System	Shut down the system software and the current computer.
 Restart System	Turn off the system software, and start the computer after turning off the current computer.

## 8.7 Register Board

Register board to specifies the usage time of the system.

Before register board, make sure that the machine tool is in idle or emergency stop state.

Follow these steps to register board:

1. [Get Register Code.](#)
2. [Use Duration of Register Board.](#)

### 8.7.1 Get Register Code

**Prerequisite:**

1. Get the account number and company information record.
  - a. Select one of the following methods to get the account:
    - Contact local sales.
    - Call our customer service number: 400-882-9188.
  - b. To put on records, fill in "Registration Confirmation Letter", seal and send it to Weihong company. Weihong company records the information in the confirmation letter you have returned.


**Operation Steps:**

1. In the menu bar, click **About** →  to open the **NcStudio** dialog box:






2. Record the device number.  
The device number changes with the number of registrations, which can be determined by the last three digits of the number.  
For example, when the number of registrations is 0, the last three digits are 000; When the number of registrations is 1, the last three digits are 001.
3. Scan the QR code at the lower left corner to enter **WEIHONG** WeChat official account.
4. Click **Service** → **Registration** → **Activate Account**, enter the mobile phone number, and get the temporary login password.  
The temporary login password is sent to the entered mobile phone number in the form of SMS. Please check the SMS.
5. Return to the login interface, enter the temporary login password to log in, fill in the information according to the following prompts, and get the register code:



### Related Tasks:


If you need to reset the password, click  to enter the account management interface to reset the password.

### 8.7.2 Use Duration of Register Board

#### Prerequisite:

[Get Register Code.](#)

#### Operation Steps:

1. In the menu bar, click **About** →  to open the **NcStudio** dialog box.
2. Click **Register**, and input the registration code.
3. Click **Confirm**.

After registration, restart the software to take effect.

When using the software later, you can view the remaining time of registration in the **NcStudio** dialog box.

### 8.7.3 FAQs

After the registration time expires, the following **Register** dialog box will pop up directly when the software is opened. If you want to continue using it, please register again.

If the following information appears in the **Register** dialog box, it means that the currently used board does not match the software, please contact the manufacturer in time.

## 9 Appendix

### 9.1 Instructions for Use of Catch Slag

#### 9.1.1 Function Background

During the cutting process, the laser or slag will affect the opposite side of the cutting. After cutting, the surface of the workpiece will turn black, and the perfect effect cannot be achieved. To solve this problem, the cutting process often uses an iron rod placed in the center of the tube to receive excess laser energy or slag, so as to achieve a bright effect on the part.

However, there are some problems with this solution:

1. Need manual intervention operation.
2. When cutting the whole tube, the iron plate cannot be stretched out to the light outlet.

In order to solve the above problems, the software supports the research and development of the catch slag function.

#### 9.1.2 Noun Definition

**Telescopic Shaft:** The control device that controls the extension or retraction of the slag rod.

**Lifter Shaft:** Control the up and down movement of the slag rod.

**Cylinder Catch Slag:** The telescopic shaft 1 is the catch slag equipment controlled by the cylinder, and it is considered that the other catch slag shafts are all controlled by the cylinder.

**Servo Catch Slag:** Telescopic shaft 1 is a servo controlled catch slag equipment, and other catch slag shafts may be controlled by cylinder or not enabled.


#### 9.1.3 Overall Debug Process

Configure catch slag hardware configuration in NcConfig → software configuration related parameters of catch slag position → complete configuration and machining

#### 9.1.4 Configure Catch Slag Hardware Configuration in NcConfig

##### 9.1.4.1 Parameter Debug Entry


Configuration entry: **NcConfig** → **Machine Parts** → **Slag Dam**



## 9.1.4.2 Catch Slag Mode Selection and Parameter Debug


### 9.1.4.2.1 IO Catch Slag Debug

Enable the slagging function in the catch slag interface, select IO for the control mode of telescopic rod 1. Set the stretching-out and shrink actions, ports and related delays according to the actual machine port. Save it.




### 9.1.4.2.2 Servo Catch Slag Debug

Before using the servo catch slag function, you need to enable the expansion axis first.




Enable the slagging function on the catch slag interface, and select servo as the control mode of catch slag rod 1. Select the extended axis serial number corresponding to the corresponding hardware device from the extended axis drop-down box. Save it.



### 9.1.4.3 Lifter Debug


#### 9.1.4.3.1 IO Lifter Debug

Select enabled in the lifter area of the catch slag interface, and select IO as the control mode. Set up and down actions, ports and related delays according to the actual machine tool port. Save it.



#### 9.1.4.3.2 Servo Lifter Debug

Before using the servo catch slag function, you need to enable the expansion axis first.




Select enabled in the lifter area of the catch slag interface, and select servo as the control mode. Select the extended axis serial number corresponding to the corresponding hardware device from the extended axis drop-down box. Save it.

### 9.1.5 Software Configuration Related Parameters of Catch Slag Position


#### 9.1.5.1 Function Entry

Software menu bar **Set** → **Advanced** → **Slag Catching**



### 9.1.5.2 IO Catch Slag Debug

When the catch slag mode is selected as IO in NcConfig, entering the slag connection debugging interface is the IO debugging interface, as shown as follow:



#### 9.1.5.2.1 Posture Switching


Posture switching refers to manually simulating the position and state of the catch slag rod and lifter rod in different machining stages when the software is in an idle state.

- **Waiting for Machining Posture**
  - Definition: The preparation posture of the catch slag equipment before machining
  - Posture entry timing: Through flow edit to call command, such as before automatic loading.
  - Posture switching action: The telescopic rod is shrunk, the lifter rod is lowered, and the two actions are performed simultaneously. The in-position signal is detected during the opening of the port. If the in-position signal is not received within the corresponding delay, the software stops and error prompt is reported.
- **Slag Catching Pose**

- Definition: The device goes deep into the inside of the tube and holds the position when catch slag
- Posture entry timing:  
Before primitive cutting starts. It may be switched from < waiting for machining posture> or <unloading pose>
- Posture switching action:  
The lifting port of the lifter rod is opened, and the telescopic rod is stretched out. The in-position signal is detected during the opening of the port. If the in-position signal is not received within the corresponding delay, the software stops and error prompt is reported.
- **Unloading Pose**
  - Definition: The action when taking off the parts on the catch slag rod
  - Posture entry timing:  
After cutoff is completed, the length sent forward by the next part length will hit the lifter rod
  - Posture switching action:  
The cutting head is raised → the telescopic rod is shinked at the same time → the unloading action is completed. If there are parts in the future, continue to switch to the catch slag posture.

### 9.1.5.2.2 User Habit

- **No-slag Cutting Mode**  
When this item is checked, the software will make the following settings:
  - Unloading with catch slag equipment;
  - Shield the support on material discharge side;
  - Shield parts collection action.
- **Display Prompt Requiring Confirmation of the Slag Catching Rod Size during the First Cutting after the Machining File is Changed**  
When this item is checked, the software detects the size confirmation prompt when switching drawings and executing machining.




### 9.1.5.3 Servo Catch Slag Parameter Setting


#### 9.1.5.3.1 Function Entry

In menu bar **Set** → **Advanced** → **Slag Catching** → **Setting of Servo Slag Catching Parameters**





The interface is displayed as follows:



### 9.1.5.3.2 Position Parameter Setting

1. Enable manufacturer permissions;
2. Determine the datum position and avoidance position of the elevating shaft according to the actual machine tool structure (if you need to set different datum positions for different sizes of tubes, use the datum advanced calibration function);
3. Determine the travel lower limit and travel upper limit according to the movement range of the telescopic shaft;
4. Determine the datum position value of the telescopic shaft according to the required positioning position of the telescopic shaft before machining.

### 9.1.5.3.3 Posture Switching Parameter Setting

#### Catch Slag Row-reaching into Tube Position:

1. The elevating shaft is positioned to the datum position, and the telescopic shaft is quickly positioned to "close to the tube position"
2. Slowly position the telescopic shaft to the "reaching into tube position";  
The elevating shaft rises to the catch slag position:  
Catch slag position = datum position + Max (tube radius - tube thickness – catch slag rod radius – catch slag height, 0)
3. Position the telescopic shaft to the "cutting position"

#### Unloading Pose:

1. Lift the cutting head
2. The telescopic shaft moves to the unloading position at the same time




3. Complete the unloading action. If there still have parts in the future, continue to switch to the catch slag posture

According to the above actions, set the posture switching parameters.


### 9.1.5.4 Commissioning of Slag Catching

#### 9.1.5.4.1 Function Entry

In menu bar **Set** → **Advanced** → **Slag Catching** → **Commissioning of Slag Catching**




The interface is displayed as follows:



#### 9.1.5.4.2 User Habit

- **No-slag Cutting Mode**  
When this item is checked, the software will make the following settings:
  - Unloading with catch slag equipment;
  - Shield the support on material discharge side;
  - Shield parts collection action.
- **Display Prompt Requiring Confirmation of the Slag Catching Rod Size during the First Cutting after the Machining File is Changed**  
When this item is checked, the software detects the size confirmation prompt when switching drawings and executing machining.



## 9.2 Tube Support Material User Instruction

This chapter is only for the operator to use the tube support material function, and does not involve specific debugging steps and parameters. If you need debugging steps and specific parameters, please see "Tube Support Material Debugging Manual".

### 9.2.1 Prerequisites for the Use and Effective of Tube Support Material Manual Rise

- The tube support material function is enabled.
- The Y-axis has returned to the origin and there is an origin mark, otherwise the tube support material cannot rise normally.
- The Y-axis coordinate is not in the descending range of the current support material rod.

### 9.2.2 Prerequisites for the Use and Effective of Tube Support Material Manual Auto Rise

- The tube support material function is enabled.
- The Y-axis has an origin mark and auto rise is enabled.
- The tube type display is not Unknown.
- There is no shielding in the flow edit (tube support material automatic rise).
- The leveling is completed or the unleveled automatic follow is allowed in the parameter settings.
- Servo-type tube support material requires each servo to have an origin mark.
- There is no tube support material alarm, otherwise lifting is prohibited.

### 9.2.3 Prerequisites for the Use and Effective of Tube Support Material Manual Auto Drop

- Turn off the tube support material function.
- The Y-axis has entered the descending coordinate and descending interval of tube support material.

## 9.2.4 The Main Interface of the Servo Tube Support Material Function

Servo roller debug X

### Position Monitor

Axis	WCS	Feedback
W2	0.000	0.000
W1	0.000	0.000

### Parameter

1. Follow state, fast idling safety protection

Limit rotation speed (safe speed)

Over the safe speed, avoid to a safe position

Safe speed:  r/min

safety distance:  mm

2.  Blanking holders return to safe position after unloading material

3. Manual speed:  mm/min

4.  Follow after leveling

5. Minimum length of long parts:  mm

6.  Include the roller shaft when making all axes go to origin

### Locate

1. Ensure tube diameter:  mm;

2. Move bracket close to tube surface.

3. Click [Origin Set].

Step

W2 W1

+   -  

UpVelocity:  mm/min

DwVelocity:  mm/min

Please clamp circular tube and ensure it has been fixed.

Enable Vslot  

Enable Linear Fit  

### Mode

1. Follow mode: follow-up on for roller carrier shaft and roller carrier shaft moves close to tube surface.

2. Separate mode: follow-up off for roller carrier shaft, and roller carrier shaft stays at current position.

Feed mode:  Follow mode    Separate Mode


Blank mode:  Long part follow    Short part follow

### 9.2.4.1 Parameter Interpretation

1. Safe speed: The maximum speed at which the support material shaft can respond in time.
2. Safety distance: When there is an edge tube cutting, the tube support material drops to the relative distance from the circumscribed circle of the tube free running.
3. Manual speed: Tube support material manual rise and fall speed.
4. Follow after leveling: It is checked by default. If it is not checked, when switching to non-circular tube cutting, the servo roller shaft will take effect and follow automatically after the tube is centered.
5. Minimum length of long parts: Distinguishes length values for long and short parts.
6. Include the roller shaft when making all axes go to origin: Return to the origin function, when the to mach is clicked, the roller shaft also returns to the origin.
7. Locate:

- a. Ensure tube diameter. This size needs to be consistent with the actual calibrated tube size when calibrated and positioned.
- b. Move bracket close to tube surface: Manually click + on the support material roller shaft, and slowly move in the positive direction until it is close to the lower surface of the tube, and the tube at this time cannot sag.
- c. Click origin set: When the roller shaft is close to the lower surface of the tube, click the origin set to set the base following coordinates.
- d. Up velocity and down velocity: The free run rising and falling speed setting value of the tube support material servo roller shaft. It has nothing to do with the roller shaft follow speed.

### 9.2.5 Bracket Debugging Interface



#### 9.2.5.1 Parameter Interpretation


8. Long-distance dry running strategy: None: If there is no other action, the dry run of the Y-axis in the down range will adopt the state of speed limit. In this case, if the parameters are not adjusted properly, it is easy to cause the tube support material to not fall in time, resulting in an alarm. Lower in advance: When the Y-axis reaches the limit position of the tube support fall, stop at the original position, and continue to move forward when the tube support material falls to the right position.
9. When the software is started: You can choose whether the tube support material will always keep not keep the current state.
10. When the software is closed: You can choose whether the tube support material will always keep not keep the current state.
11. Material feed side bracket debugging: It can manually make the feed side cylinder bracket up and down, but the Y-axis coordinate is not in the down range.
12. Bracket 1: Close the rear card, when the nearest bracket at the origin. Bracket 2: The second bracket close the first bracket. Bracket 3: The bracket near the front card.

13. Material discharge side bracket debugging: It can manually make the discharge side cylinder bracket up and down.
14. Bracket 1: The bracket near the front card. Bracket 2: The second bracket close the first bracket. And so on.


### 9.2.6 The Overall Use Process of Tube Support Material

The usage process is as follows:

- **Pure Cylinder Tube Support Material:**



- **Servo Type Tube Support Material:**



### 9.2.7 Troubleshoot Common Alarms

#### 9.2.7.1 Tube Support Material Cannot Rise Normally

1. Whether there is an origin mark on the Y-axis, and the Y-axis is not in the down range of the tube support material
2. Whether tube support material function is shielded
3. Whether the servo roller shaft has an origin mark
4. Whether the drop in position port is configured, and the in position port has no signal

#### 9.2.7.2 Alarm when the Tube Support Material Drop in Position and the Signal is not in Position

1. Check whether the signal port has a signal
2. Whether the roller shaft is at the origin
3. The Y-axis has exceeded the limit position of the tube support material, and the signal of drop in position is not in position

#### 9.2.7.3 Roller Following is Invalid

1. Y-axis without BMW logo
2. Support material axis without BMW logo
3. No leveling and centering
4. Follow is not enabled

#### 9.2.7.4 Lower in Advance is Invalid

1. Lower in advance function is not enabled
2. Lower in advance does not take effect on manual jog motion

#### 9.2.7.5 Servo Support Material Coordinate is Wrong

1. The current machining tube and the drawing are inconsistent with the tube size
2. After importing a new drawing, it is not saved


## 9.3 Tube Support Material Shield Function Use Instruction

### 9.3.1 Function Background

In order to flexibly apply the tube support material function on the feed side and the outlet side, when the tube support material function needs to be shielded in production, the tube support material function can be completely shielded or shielded according to the custom.


### 9.3.2 Function Entry

**Menu Bar** → **Maintain** → **Tube Support Debugging**, as shown as the following:



### 9.3.3 Application Process

1. Check the brackets that need to be shielded, and click **Confirm** to exit the tube support debugging interface.



- Click **Shield** on the right side of the software, as shown as following.



- Machining, at this time, the tube support material has been shielded, and it is no longer up, down and follow.

### 9.3.4 Precautions


- After the tube support material is shielded, the up and down of the support material in the flow edit will also be shielded.
- The flow edit cannot configure the tube support material in position signal, otherwise the alarm will appear.

## 9.4 Special Pull Material Function Use Instruction

This chapter is only used for debugging personnel to use and configure the special pulling function. According to different models, cooperate with the process edit function to achieve reasonable and correct use of the special pulling function.


### 9.4.1 Model Classification

#### 9.4.1.1 Single Y Pushing Modle




- The travel of the Y-axis is short, and the cutting head is fixed
- Back chuck can be connected
- The Y-axis moving direction is negative to the left and positive to the right

## 9.4.1.2 Single Y Pulling Modle



- Moving the cutting head to the left is positive, to the right is negative
- Pulling device pull material cutting


## 9.4.1.3 Double Y Pulling Modle



- Can realize zero tail cutting function
- A pulling shaft is used for pull material, for heavy tubes, and a Y-axis is used for cutting.
- The moving direction of the pulling shaft is negative direction to the left, and positive direction to the right
- Moving the cutting head to the left is positive, to the right is negative



## 9.4.1.4 Double Y Pushing Modle




- A pulling shaft is used for pushing material, for heavy tubes, and a Y-axis is used for cutting.
- The moving direction of the pulling shaft is negative direction to the left, and positive direction to the right
- The Y-axis of the cutting head moves to the left is positive, and to the right is negative

## 9.4.2 Function Application Background

The tube is generally very long. At present, there are many rear chucks on the market that move the tube from the direction of the feed axis, which requires a long Y-axis travel. Some customers have designed the machine tool with cutting head that can segment the tube. The tube can be cut in sections to reduce the size of the machine tool to achieve the purpose of cutting long tubes. That is to say, it is possible to cut long tubes with a small machine tool. Based on this background, the special pulling function has been developed.

## 9.4.3 Determination of Machine Coordinate System and Direction

No matter what kind of machine tool, the machine coordinate system and direction are clear and fixed. The following picture is for reference:




**9.4.4 Software Version**

- Single Y pushing modle: TU1000, TU2000, TU3000
- Single Y pulling modle: TU1000, TU2000, TU3000
- Double Y pushing modle: TU3200, TU6000
- Double Y pulling modle: TU3200, TU6000

**9.4.5 Detailed Explanation of Special Pulling Function**

**9.4.5.1 Machining Process**




**9.4.5.2 Parameter Configuration**

According to different model configuration parameters and edit process actions.

**Operation Steps:**

1. Enter the configuration console and configuration entry: *C:\Program Files\Weihong\NcStudio\Bin*. Find NcConfig.
2. According to different models and device types, configure parameters and configure related actions in flow edit:
  - [Single Y Pushing \(Chuck Type\)](#)
  - [Single Y Pushing \(Chuck Device Type\)](#)
  - [Single Y Pulling \(Chuck Type\)](#)
  - [Single Y Pulling \(Chuck Device Type\)](#)
  - [Double Y Pulling \(Chuck Type\)](#)
  - [Double Y Pulling \(Chuck Device Type\)](#)
  - [Double Y Pushing \(Chuck Type\)](#)
  - [Double Y Pushing \(Chuck Device Type\)](#)
3. In the software, configure the function parameters



### Parameter interpretation:

- Pull shaft: The single Y pulling model defaults to Y, no need to change.
- Pull speed: The speed of the Y-axis when pull material is different from the speed of the Y-axis.
- Pull accelerated: The acceleration of the Y-axis when pull material is different from the G00 acceleration of the Y-axis.
- Effective area: The maximum range for machining a single primitive. For example, the effective machining area is 100, and if the length of a certain contour is greater than 100, it will not be machined.
- Truncation area: The maximum range from the cutoff line to the upper limit of the Y-axis. When this function is turned on, the cutoff line can be cut off close to the chuck, which is more stable.
- Tail length: The distance from the clamped tube to the cutting head when the rear chuck travels to the maximum Y travel.

- Clamp length: This parameter is meaningless for single Y pushing model. Is 0.
- Slip distance: After each pulling, the tube fittings will have a certain length error due to external factors. This parameter can be used to improve the length error and be set according to the actual situation.
- Machine efficiency first: The material pulling time is less, and the machining efficiency is relatively high, but because the pulling is triggered during cutting, the relative accuracy is reduced.
- Part precision first: There are many times of pulling, and the machining efficiency is low, but it can ensure that materials will not be pulled during cutting.
- Know tube length pull mode: The tube length is fixed, use the tube length parameters and drawings to determine whether to start machining.
- Tube length: Cut the length of the tube, this option does not take effect when the indeterminate length tube mode is selected.
- Unknow tube length pull mode: It is used when the length of the tube is not fixed, and it is judged whether the machining can be continued according to the limit port of the pull material. This function can only be selected after the pull limit is configured. The port configuration entry is as follows:

Axis	Limit	Port
W5Axis	Negative Limit	Phoenix.G.Limit[...]
W5Axis	Positive Limit	Phoenix.G.Limit[...]
W6Axis	Negative Limit	Phoenix.G.Limit[...]
W6Axis	Positive Limit	Phoenix.G.Limit[...]
W7Axis	Negative Limit	Phoenix.G.Limit[...]
W7Axis	Positive Limit	Phoenix.G.Limit[...]
W8Axis	Negative Limit	Phoenix.G.Limit[...]
W8Axis	Positive Limit	Phoenix.G.Limit[...]
W9Axis	Negative Limit	Phoenix.G.Limit[...]
W9Axis	Positive Limit	Phoenix.G.Limit[...]
W10Axis	Negative Limit	Phoenix.G.Limit[...]
W10Axis	Positive Limit	Phoenix.G.Limit[...]
W11Axis	Negative Limit	Phoenix.G.Limit[...]
W11Axis	Positive Limit	Phoenix.G.Limit[...]
	Material pulling position limit	Phoenix.G.Pull[...]

- Check enable pull tube, and the pull tube function will take effect.
- Centering after pull: After checking this option, the centering will be performed automatically after each pull.

### 9.4.5.3 Single Y Pushing (Chuck Type)



1. Find the chuck parameters and configure the chuck jaw parameters:

The screenshot shows the 'ChuckSetting' configuration window. It includes a diagram of a chuck with a workpiece. The configuration fields are as follows:

- Clamping or unclamp the chuck in alarm mode:**
- Chuck type:**  Single IO chuck,  Double IO chuck,  Custom chuck,  External control chuck
- Jaw external control:** Clamping input port, Unclamping input port
- Jaw parameter:** Clamping action: Open, Clamping in position time: 3000 ms, Clamping output port: Phoenix.G.LD21E-04.Y08, Clamping in position input port, Unclamping action: Open, Unclamping in position time: 3000 ms, Unclamping output port: Phoenix.G.LD21E-04.Y09, Unclamping in position input port
- Torque parameter:** DA output port, DAmmaximum value: 10 v
- Other parameters:** Motor response time: 1000 ms, Extra output time after in position: 0 ms,  Turn off the output port in position

2. Configure related actions in flow edit:

The following is only the basic configuration. If there are other actions that need to be configured, they can be freely configured in the flow edit.



#### 9.4.5.4 Single Y Pushing (Chuck Device Type)

1. Find the clamp unit setting and configure related parameters:

## Position Controlled Device:

Device 1 **Device 2**

---

Configuration function

Pulling clamping  Rotate Assist Clamp

---

Device type

position control  IOControl

---

Clamping plate

Clamping minimum tube length:

---

Clamping axis

Extended axis:

---

Disable

Device shield input port:

---

Enabled

- Clamping minimum tube length: After the pulling function is stopped, the maximum distance that the clamping plate can be opened to avoid interference between the tube and the clamping device.
- Extended axis: Select the servo controlled axis for pulling.
- Device shield input port, servo pulling can not be configured.

## IO Control Device:

Configuration

ClampUnit Setting

Device 1 **Device 2**

---

Configuration function

Pulling clamping  Rotate Assist Clamp

---

Device type

position control  IOControl

---

Clamping plate

Clamping minimum tube length:

---

IOPort

Clamping action:  Clamping output port:

Clamping in position time:  ms Clamping in position input port:

Unclamping action:  Unclamping output port:

Unclamping in position time:  ms Unclamping in position input port:

---

Disable

Device shield input port:



---

Enabled

Device shield input port: When there is a signal at this port, the clamping plate is always in the open position and cannot be clamped.


2. Configure related actions in flow edit:

The following is only the basic configuration. If there are other actions that need to be configured, they can be freely configured in the flow edit.




### 9.4.5.5 Single Y Pulling (Chuck Type)

1. Find the chuck parameters and configure the front and rear jaw parameters:









## 2. Configure related actions in flow edit:

The following is only the basic configuration. If there are other actions that need to be configured, they can be freely configured in the flow edit.





### 9.4.5.6 Single Y Pulling (Chuck Device Type)

Find the parameters of the clamping device and configure the relevant parameters. For details, please see [Single Y Pushing \(Chuck Device Type\)](#).




1. Configure related actions in flow edit:


The following is only the basic configuration. If there are other actions that need to be configured, they can be freely configured in the flow edit.




9.4.5.7 Double Y Pulling (Chuck Type)

1. Find the chuck parameters and configure the front and rear jaw parameters:






2. Configure extended axis: Check enable extended axis and select the main axis. If there are synchronous axes, continue to add extended axes among the slave axes.





3. Configure related actions in flow edit:  
The following is only the basic configuration. If there are other actions that need to be configured, they can be freely configured in the flow edit.




1: For the double Y pulling mode, the front chuck must be opened before pulling back. Write in the edit object cutting head avoid before pulling.

2: If there are already cutting parts falling down or in the front chuck at this time, the parts need to be removed manually to prevent interference before continuing to pulling.




### 9.4.5.8 Double Y Pulling (Chuck Device Type)

1. Configure extended axis: Check enable extended axis and select the main axis. If there are synchronous axes, continue to add extended axes among the slave axes.





Find the parameters of the clamping device and configure the relevant parameters. For details, please see [Double Y Pulling \(Chuck Device Type\)](#).

2. Configure related actions in flow edit:  
The following is only the basic configuration. If there are other actions that need to be configured, they can be freely configured in the flow edit.





1: For the double Y pulling mode, the front chuck must be opened before pulling back. Write in the edit object cutting head avoid before pulling.

2: If there are already cutting parts falling down or in the front chuck at this time, the parts need to be removed manually to prevent interference before continuing to pulling.




### 9.4.5.9 Double Y Pushing (Chuck Type)


1. Find the chuck parameters and configure the front and rear jaw parameters:



2. Configure extended axis: Check enable extended axis and select the main axis. If there are synchronous axes, continue to add extended axes among the slave axes.





3. Configure related actions in flow edit:  
The following is only the basic configuration. If there are other actions that need to be configured, they can be freely configured in the flow edit.



1: For the double Y pushing modle, the front chuck must be opened before pulling back. Write in the edit object cutting head avoid before pulling.


2: If there are already cutting parts falling down or in the front chuck at this time, the parts need to be removed manually to prevent interference before continuing to pushing.





### 9.4.5.10 Double Y Pushing (Chuck Device Type)


1. Configure extended axis: Check enable extended axis and select the main axis. If there are synchronous axes, continue to add extended axes among the slave axes.



Find the parameters of the clamping device and configure the relevant parameters. For details, please see [Double Y Pushing \(Chuck Device Type\)](#).


2. Configure related actions in flow edit:


The following is only the basic configuration. If there are other actions that need to be configured, they can be freely configured in the flow edit.



1: For the double Y pushing mode, the front chuck must be opened before pulling back. Write in the edit object cutting head avoid avoid before pulling.

2: If there are already cutting parts falling down or in the front chuck at this time, the parts need to be removed manually to prevent interference before continuing to pushing.






#### 9.4.6 Precautions for Using the Special Pull Material Function

- The machining length of a single primitive cannot exceed the effective machining area.
- Forward and backward across primitives are not supported.
- The pull material shaft of the double Y pulling and pushing models is the extension axis, not the Y-axis.
- For rear chuck pushing models, the parameter of pulling clamping length is meaningless and can be directly set to 0.



## 10 Shortcut Key List

When using the **NcStudio-V15 Laser Cutting Control System**, you can refer to the following list to get familiar with the shortcut keys of the software for easy operation.

Or get the shortcut key description on the system software: In the menu bar, click **About** →  **ShortCut Key Info**.

## Shortcut Key List

Shortcut Key	Function	Shortcut Key	Function
F1	Show shortcut keys	Ctrl + C	Copy
F2	E-stop	Ctrl+ V	Paste
F5	Set workpiece origin	Delete	Delete
F8	Simulate	Ctrl + Z	Undo
F12	Clear track	Ctrl + Y	Redo
Alt + 0	Ports setting	Ctrl + G	Gallery
Num+	Zoom in	Ctrl + T	Shape check
Num-	Zoom out	Ctrl + 1	Instant setting
Num*	Fit to window	Ctrl + 2	Layer setting
Ctrl + N	New	Ctrl + J	Combine
Ctrl + O	Open	Ctrl + W	Set lead-in/out line
Ctrl + S	Save	Ctrl + Q	Start cut point
Ctrl + I	Import	Ctrl + P	System parameters
Ctrl + A	Select all	Ctrl + D	Set machining direction
Ctrl + Shift + A	Select invert	Ctrl + E	Auto set machining order
Shift + A	Clear selected	Ctrl + R	Set kerf compensation
Ctrl + X	Cut	End	Middle current point

## Legal Notices

The term “Software Product” includes all copies of the licensed software and its documentation. This license agreement is a legal agreement between You (either an individual, a legal entity or any affiliated companies or other entities) and Weihong Electronic Technology Co., Ltd. (hereinafter referred to as Weihong Company). By installing, copying, or otherwise using the Software Product, you agree to be bound by the terms and conditions of this license. Unless otherwise stated in this agreement, you shall not use, copy, revise, rent, or transfer the Software Product or any part of the Software Product for any other purposes.

## Requirements of Use

1. You may install for use one copy of the Software Product on a single machine;
2. You may make a copy of the Software Product for archive or backup purposes and the copy is to be used on this machine only;
3. You may transfer the Software Product and the license agreement to a third party, provided that the third party accepts the terms and conditions stated in this agreement, with prior express permission from Weihong Company;
4. When transfer confirmed, you shall transfer all the copies of the original documents and the supplementary documents to the third party or destroy all the copies untransferred;
5. You can use the Software Product on a network server or intranet server only if it is stipulated in explicit terms that you are allowed to use the Software Product on a network server or intranet server, or you have purchased license for each node and terminal using the Software Product;
6. You may NOT sublicense, assign or transfer the license agreement;
7. You may NOT or direct any third party to reverse engineer, decompile or disassemble the Software Product;
8. You may NOT copy or transfer the Software Product or any part of the Software Product unless otherwise expressly stated in this agreement;
9. The license agreement shall be terminated automatically upon you transfer the Software Product or copies of all or part of the Software Product to a third party.

## Intellectual Property Rights Notice

The Software Product and all intellectual property rights therein (including but not limited to any all copyrights, patents, trademarks, and publicity rights) are owned by Weihong Company. The Software Product is protected for Weihong Company on the basis of Chinese copyright law and international treaty provisions as well as on the basis of other laws and agreements regarding intellectual property. You are not allowed to remove the copyright statement made in the Software Product, and guarantee that you shall copy the copyright statement in all copies of the Software Product or of any part of the Software Product. You are obliged to stop any form of illegal copying of the Software Product and accompanying materials.

Weihong Company can update the Software Product at any time. You can pay real-time attention to Weihong Company's official website.

## Termination

This license may be terminated by Weihong Company at any time once you violate any terms or conditions made in this agreement. Once the license is terminated, you are

obliged to destroy all the copies of the Software Product or return them to Weihong Company.

Now, we affirm that you have already read through this agreement and understood it thoroughly and agreed to comply with all of the terms and conditions of this agreement strictly.

Weihong Electronic Technology Co., Ltd.

SPECIALIZED / CONCENTRATED / FOCUSED



Shanghai Weihong Electronic Technology Co., Ltd.

Address: No. 1590, Huhang Rd., Fengxian, Shanghai, China, 201401

Hot-line: 400 882 9188

Website: [www.weihong.com.cn/en](http://www.weihong.com.cn/en)